OWNER'S MANUAL

ELECTRIC CHAIN HOIST RNER2B & RNER2D SERIES

1 - 5 Ton Capacity

Code, Lot and Serial Number

This equipment should not be installed, operated, or maintained by any person who has not read and understood all the contents of this manual. Failure to read and comply with the contents of this manual can result in serious bodily injury or death, and/or property damage.





Table of Contents

2
4
6
79
100
131

Introduction

This RNER2 Hazardous Locations (Haz Loc) electric hoist is designed and manufactured for the purpose of lifting and lowering a load within hazardous work environments that include explosive gas and/or dust equipped with pressure resistant containers and other hazardous locations. The RMR2 hazardous locations motorized trolley is designed and manufactured for the purpose to move the lifted load laterally in combination with the electric hoist equipped with the same hazardous location construction.

This Owner's Manual is intended for those operating the HARRINGTON RNER2 hazardous locations electric hoist and qualified personnel (* personnel with expertise).

Other than this manual, a Parts List is also available for the qualified persons. Assign the qualified persons and use these materials for inspection and repair. Please contact the nearest distributor or HARRINGTON for these materials

Servicing and/or repair of the RNER2/RMR2 hoist and trolley shall be performed by a Qualified Person ONLY. Incorrect servicing or repair practices could result in death or serious injury, and property damage.

Mandatory

Disclaimer

- HARRINGTON shall not be liable for any damage incurred thereof due to natural disaster such as fire, earthquake and lightning, conduct by third party, accident, willful conduct or negligence by customer, erroneous use and other use exceeding the operational condition.
- HARRINGTON shall not be liable for any incidental damage due to the use or non-use of the product such as the loss of business profit, suspension of business and damage of the lifted load.
- HARRINGTON shall not be liable for any damage arising from negligence of the contents in the Owner's Manual and the use of the product exceeding the scope of its specification.
- HARRINGTON shall not be liable for any damage arising from the malfunction due to the combination of the product with other devices in which HARRINGTON is not concerned.
- HARRINGTON shall not be liable to supply the spare parts for the product for which it has passed for 15 years since the discontinuation of the product.

Restriction on Use

- Equipment described herein is not designed for and **MUST NOT** be used for lifting, supporting, or transporting people, or lifting or supporting loads over people.
- The product described herein is designed for materials handling work such as lifting/lowering and traveling a load in environments with explosive gas and dust.
- Do not assemble the product into machinery not for materials handling, as a part of it.

Operators

- Read carefully this Owner's Manual and the instruction manuals of related products, fully understand their contents, and the use and operate the product.
- Be sure to wear the proper clothing and protective equipment when using and operating the product.

Operating Conditions and Environment – Hazardous Locations RNER2B -

Gas: Class I Division 1

Group C (example: Ethylene) and Group D (example: Propane)

Gas: Class I Division 2

Group B (example: Hydrogen), Group C (example: Ethylene) and Group D (example: Propane)

Dust: Class II Division 1 Group F (example: Coal dust), Group G (example: Grain dust) Dust: Class II Division 1 Group F (example: Coal dust), Group G (example: Grain dust)

A WARNING

RNER2B not to be used in a hazardous location where GAS Class I Division 2 Group B (ex: Hydrogen) is combined with DUST Class II Division 1 or Dust Class II Division 2.

RNER2D -

Gas: Class I Division 2 Group B (example: Hydrogen), Group C (example: Ethylene)

Safety Precautions

Improper use of electric chain hoists causes danger such as drop of lifted load. Read this Owner's Manual carefully before installation, operation and maintenance. Use the product after understanding the product knowledge, safety information and precautions.

This Owner's Manual classifies the safety information and precautions into categories of "DANGER" "WARNING" and "CAUTION".

Also read the instruction manual of the device associated with electric chain hoist, and follow the described contents.

Description of Signal Words				
	Indicates an imminently hazardous situation which, if not avoided, <i>will</i> result in <i>death or serious injury</i> , and property damage.			
	Indicates an imminently hazardous situation which, if not avoided, <i>could</i> result in <i>death or serious injury</i> , and property damage.			
	Indicates an imminently hazardous situation which, if not avoided, <i>may</i> result in <i>minor or moderate injury</i> , and property damage.			

Further, the event described in CAUTION may result in serious accidents depending on the situation. The DANGER, WARNING and CAUTION describe important contents. Please follow the instructions carefully. After reading, please keep this manual at hand for future use by the user.

Description of Safety Symbols



Means "Prohibited" or "You must not do". Prohibited action is shown in the circle or described near the circle. This Owner's Manual uses \bigotimes as the general prohibition.



Means "Mandatory Action" or "You must do". Required action is shown in the circle or described near the circle.

This Owner's Manual uses **U** as the general instruction.

General Matters on Handling and Control

Prohibited	 This product shall not be disassembled and/or repaired by a person that is not qualified. Other than this manual, Disassembly/Assembly Manual and Parts are provided for the qualified personnel. Perform the disassembling and repair by the qualified person in accordance with these materials for maintenance. Do not modify the product and its accessories. 					
	Failure to comply with these instructions may result in death or serious injury.					
	 Understand the contents of the Owner's Manual sufficiently. Then operate the Electric chain hoist. Warning label is affixed to each part of the product. Follow the instruction described in the warning label. 					
Mandatory	Failure to comply with these instructions may result in death or serious injury.					

	Acaution					
Prohibited	• Do not drag or drop the product when carrying. Otherwise it causes damage or flaw of the electric chain hoist, bodily injury or loss of property due to the drop of the lifted load.					
Mandatory	 When discarding the product, disassemble it not to be used and discard in accordance with the ordinances of local government or the rules specified by the business entity. Ask the local government or the relevant section for the details. Refer to "Disassembly/Assembly Manual" for disassembling, or contact Harrington Hoists directly. (This product uses oil. MSDS (Materials Safety Data Sheet) sheets are available. Contact Harrington.) Carry out daily inspection by user. Carry out inspections (monthly, annual) by qualified personnel. Keep a record of the inspection.					
	Failure to comply with these instructions may result in death or serious injury.					

Chapter 1

Handling the Product

This chapter describes mainly how to use, assemble and install, and the check after installation. It also describes the daily inspection items before use.

• For Operators and Qualified Personnel

Type and Names of Each Parts Opening the Package Product Specification and Operational Environment How to Use

- Daily Inspection of Electric Chain Hoist (Hook Suspended Type)
- Daily Inspection of Motorized Trolley (RMR2)
- Daily Inspection of Manual Trolley (RTSG)
- How to Operate the Push Button Switches
- Operation
- How to Sling the Load Properly
- How to Suppress the Swinging of a Load
- Precautions After Work
- For Qualified Personnel and Installers

Workflow of Assembling and Installation Assembling

- Checking Power and Power Cable Installation
- Connecting Power and Power cable
- Installing the Hook suspended Type (hoist only)
- Installing the Trolley Combined Model

Check after Installation

Type and Names of Each Part

Hook Suspended Type (RNER2)

• Electric chain hoist dedicated for elevation





• Warning labels are affixed to each part other than those listed above. Be sure to follow the instructions on the label.

Failure to comply with the contents of the label may result in death or serious injury.

Motorized Trolley Type (RNER2M)

• Electric Chain Hoist combined with motorized trolley (RMR2) for elevation and traveling motion





• Warning labels are affixed to each part other than those listed above. Be sure to follow the instructions in the label.

Failure to comply with the contents of the label may result in death or serious injury.

Manual Trolley Type (RNER2G)

• RNER2G : The electric chain hoist equipped with the geared trolley (RTSG) enabling fine adjustable lateral motion of the load by pulling the hand chain.





Warning labels are affixed to each part other than those listed above. Be sure to follow the instructions in the label.

Failure to comply with the contents of the label may result in death or serious injury.

Opening the Package

Checking the Product

- Make sure that the indication on the package and the product coincide with your order.
- Make sure that the product is not deformed and damaged due to the accident during transportation.

Packaging

Parts packaged with the Electric Chain Hoist

```
Load Chain
Owner's Manual
```



Nameplate Indication

Nameplate Indication of Electric Chain Hoist



① Operational Environment

Indicates the operational environment where this product can be used. Use the product within this scope.

For details, refer to "∎Operational Environment". (P17) ② …

```
Capacity Ex. 1t
```

The maximum mass of the load that can be imposed on the product. The mass of the hook is excluded. (3)

Size...Body size Ex. Body size D, RNER2-D The size of the electric chain hoist body to support the load. Three models of D, E and F are provided.

(4) Duty Class, H4

The grade of an electric chain hoist specified by ASME.

A guidepost of durability. (5)

CODE...Product model Ex. RNER2-

```
010SD
```

A code to indicate the model No. of the product, capacity and lifting speed.

6 CHAIN SIZE...Load Chain size

Ex. DAT-7.7×21.4mm

The alphabet and the figures indicate the JIS grade, wire diameter and chain pitch respectively.

- ⑦ LOT No. Manufacture No. to identify the time of Manufacture and the production lot.
- (8) SERIAL No. Serial number to indicate the manufacturing sequence of the product.
- (9) MFG. Month.YEAR...Manufacture month and year
- (10) LIFTING SPEED
- (11) Warnings
- This section indicates warnings with regard to handling of the product in a Hazardous Locations environment. Refer to P17 for details.
- 12 V, Hz, A...Frequency, voltage, current Indicates the measurements for these values when certification testing was performed.

Opening the Package (continued)

Code of RNER2

			co	DE		
		RNE	R2B	RNER2D		
Capacity	Body Size	Dual spe	ed model	Dual spe	ed model	
		Standard speed	Low speed	Standard speed	Low speed	
1t	RNER2-D	RNER2B- 010SD	RNER2B-010LD	RNER2D- 010SD	RNER2D-010LD	
1.5t	RNER2-E			RNER2D- 015SD	—	
01	RNER2-D	_	RNER2B- 020CD	_	RNER2D- 020CD	
2t	RNER2-E	RNER2B- 020SD	RNER2B-020LD	RNER2D- 020SD	RNER2D-020LD	
2.5t	RNER2-F	RNER2B- 025SD		RNER2D- 025SD	—	
3t	RNER2-E	RNER2B- 030CD	_	RNER2D- 030CD	—	
5t	RNER2-F	RNER2B-050LD		RNER2D-050LD	_	



Nameplate Indication Motorized Trolley

(1) Capacity Ex. 1t The maximum mass of the load that can be imposed on the product. The mass of the hook is excluded.

- ② CODE...Product model Ex. RNER2-010S A code to indicate the model No. of the product, capacity and lifting speed.
- ③ LOT No. Manufacture No. to identify the time of Manufacture and the production lot.

Serial number to indicate the manufacturing sequence of the product.

(4) SERIAL No.

- (5) MFG. Month.YEAR...Manufacture month and year
- 6 TRAVELING SPEED
- ⑦ V, Hz, A...Frequency, voltage, current Indicates the measurements for these values when certification testing was performed.
- (8) Warnings

This section indicates warnings with regard to handling of the product in hazardous locations environment. Refer to P17 for details.

Code of RMR2

	C	ODE
	RMR2B	RMR2D
Capacity	Dual speed model	Dual speed model
	Standard speed	Standard speed
1t	RMR2B-010SD	RMR2D-010SD
1.5t		
2t	RMR2B-020SD	RMR2D-020SD
2.5t		
3t	RMR2B-030SD	RMR2D-030SD
5t	RMR2B-050SD	RMR2D-050SD

Nameplate Indication of Manual Trolley



1 Capacity Ex. 1t, 2t

The maximum mass of the load that can be imposed on the product. The mass of the hook is excluded.

- ② CODE...Product model Ex. RTSG010 A code to indicate the model No. of the product, capacity and lifting speed.
- ③ MODEL-LOT No.

Manufacture No. to identify the time of manufacture and the

production lot. ④ SERIAL No.

Serial number to indicate the manufacturing sequence of the product.

Opening the Package (continued) Checking the Marks



• Be sure to check that the Load Chain has "RH-DAT" or "FT-DAT" mark on it and the chain size is appropriate for the RNER2B/D model you are using. (See the following table.). The Load Chain of other models (such as model RES or etc.) or different rating cannot be used.

Mandatory

Use of the Load Chain of other model or other rating may result in death or serious injury due to the drop of the lifted load.

	Code	Load Chain size : diameter (mm)	Mark pitch	The mark (RH-DAT) to indicate the model of the Load Chain is indicated on it at an equal spacing. Make sure that the Load Chain is of a chain size (wire diameter) appropriate for RNER2 referring to the table in the left.
	RNER2B-010LD/RNER2D-010LD			
1	RNER2B-010SD/RNER2D-010SD	7.7	20 Links	Mark sitah
	RNER2B-020CD/RNER2D-020CD			Mark pitch
	RNER2B-015SD/RNER2D-015SD			
	RNER2B-020LD/RNER2D-020LD	10.2	16 Links	RH-DAT
	RNER2B-020SD/RNER2D-020SD			Second mark First mark Second mark
	RNER2B-025SD/RNER2D-025SD	11.2	12 Links	Front side : RH-DAT Front side : Original Lot No. of the
	RNER2B-030CD/RNER2D-030CD	10.2	16 Links	Load Chain (4 digits)
	RNER2B-050LD/RNER2D-050LD	11.2	12 Links	Back side : H-23 Back side : HARRINGTON

Recording the Product No.

Fill in the table in the right with product's Lot No., Serial No. (described in the product nameplate), date of purchase and the name of the sales See shop where you purchased the product.
 * When requesting repair or Na

right with	ltom	Electric chain	Motorized	Manual trolley
Serial No.		hoist	trolley	······································
product				
purchase				
he sales	Serial No.			
urchased	Date of purchase			
epair or	Name of the sales shop			

ordering a chain hoist part,

please inform us of these pieces of information together.

Recording the Initial Value

• When opening the package, fill in the table in the right with the opening dimension "a" between embossed marks on the Bottom Hook, the width of the hook "b" and the thickness of the hook "c". (These values are used for checking. Record the value for the top hook of RNER2 when it is used individually.) Embossed marks





Dimension a	mm
Dimension b	mm
Dimension c	mm
Dimension a	mm
Dimension b	mm
Dimension c	mm
	Dimension b Dimension c Dimension a Dimension b

Product Specification and Operational Environment

The operational environment of the electric chain hoist and motorized trolley is as follows:

Standard Specification

Usage location Operating Voltage Intermittent ratings	: Class I Division 1, Class I Division 2, Class II Division 1 For Indoor Use Only : DC12V : RNER2 series (Capacity): 40/20%ED (at 120/240 rev/h) : RMR2 series (Capacity): 27/13%ED (at 80/160 rev/h)							
Grade * 1	: ISO-M5 or M4, FEM-2	2m or 1Am, A	SME-H4					
Operation	: Push button switch o 5- Push Button Switch			witch set for hoist only and manual trolley type /				
Power supply method	Power supply through o							
	HARRINGTON Yellow		to Munsell 7.2	2YR6.5/14.5)				
Noise level	RNER2 85dB or less (A	scale: measu	ired at 1 m av	vay from the Electric				
	chain hoist)							
	RMR2 85dB or less (A s	cale: measur	ed at 1 m awa	ay from the Electric				
	chain hoist)							
	150% of the capacity or							
Protection	Hoist IP54, Push button I	P65						
Product	Motor Insulation	Voltage	e range					
category	Class	ass 50Hz 60Hz						
	_	—	208V					
200V Class	F	_	230V					
		380V						

460V

575V

NOTE

Operate the electric chain hoist with the rated voltage.

F

F

• Do not use the electric chain hoist exceeding the intermittent ratings.

* Grade

400V Class

500V Class

	Co		GRADE		
	RNER2B	RNER2D			
Capacity (t)	Dual speed	Dual speed	ISO	ASME	FEM
1	RNER2B-010SD	RNER2D-010SD			
1	RNER2B-010LD	RNER2D-010LD	M5	H4	2m
1.5	RNER2B-015SD	RNER2D-015SD	1015		2.11
	RNER2B-020CD	RNER2D-020CD			
2	RNER2B-020SD	RNER2D-020SD			
	RNER2B-020LD	RNER2D-020LD	-		
2.5	RNER2B-025SD	RNER2D-025SD	M4	H4	1Am
3	RNER2B-030CD	RNER2D-030CD			
5	RNER2B-050LD	RNER2D-050LD			

Product Specification and Operational Environment (continued)

• ISO

ISO 4301 specifies the total operating hour (service life) of gears and bearings according to the loading status. For example, the total operating hour (service life) of the mechanism when it is constantly applied with the capacity is 1,600 hours for M5. The total operating hour is 6,300 hours when operated with a medium load.

		То	tal operating hour	h	
Loading status*	800	1600	3200	6300	12500
Light				M4	M5
Medium			M4	M5	
Heavy		M4	M5		
Ultra heavy	M4	M5			

* Rate of loading

Light : A case where the capacity is rarely applied. Usually, the hoist is used with a light load.

Medium: A case where the capacity is applied considerably frequently. Usually, the hoist is used with a medium load. Heavy: A case where the capacity is applied considerably frequently. Usually, the hoist is used with a heavy load. Ultra heavy: A case where the capacity is applied constantly.

ASME HST

		Operation time ratings at K=0.65Uniformly distributed work periodsInfrequent work periodsMax. on time, min / hrMax. No. starts / hrMax. on time from cold start, minMax. No. of starts7.6 (12.5%)7515100				
Hoist duty class	Typical areas of application	distributed work work p				
		time, min /		from cold start,		
H2	Light machine shop fabricating, service,and maintenance; loads and utilization randomly distributed; capacitys infrequently handled.	7.6 (12.5%)	75	15	100	
H3	General machine shop fabricating, assembly, storage, and warehousing; loads and utilization randomly distributed.	15 (25%)	150	30	200	
H4	High volume handing in steel warehouses, machine shops, fabricating plants and mills, and foundries; manual or automatic cycling operations in heat treating and plating; loads at or near capacity frequently handled.	30 (50%)	300	30	300	

• The grade symbols are identical to those of ASME HST-1M. (Performance standard for Electric Chain Hoist)

	FEM Relation between ISO-and FEM-Denominations											Class of		erage operating	Calculated total
1 Dm	1 Cm	1 Br	n 1	Am	2 m	3 m	4 m	5	m			operating time		time per day (in hours)	operating time (in hours)
M 1	M 2	M 3	3 N	14	M 5	M 6	M 7	M	8			V0.06	т0	<0.12	200
Class of operation time									V0.12	Т1	<0.25	400			
	Load Cubic mean		V0.06	V0.02	V0.25	V0.5	V1	V2	V3	V4	V5	V0.25	т2	<0.5	800
Load spectrum			Т0	T1	T2	Т3	T4	T5	Т6	Т7	Т8	V0.5	Т3	<1	1,600
spectrum	value	2		Ave	erage o	peratio	n time j	per day	in hou	rs		V1	Т4	<2	3,200
			≤0.12	<0.25	<0.5	<1	<2	<4	<8	<16	>16	V2	Т5	<4	6,300
1 L1	K<0.50		_	-	1 Dm	1 Cm	1 Bm	1 Am	2 m	3 m	4 m	V3	Т6	<8	12,500
2 L2	0.50 <k<< td=""><td>0.63</td><td>_</td><td>1 Dm</td><td>1 Cm</td><td>1 Bm</td><td>1 Am</td><td>2 m</td><td>3 m</td><td>4 m</td><td>5 m</td><td>V4</td><td>т7</td><td><16</td><td>25,000</td></k<<>	0.63	_	1 Dm	1 Cm	1 Bm	1 Am	2 m	3 m	4 m	5 m	V4	т7	<16	25,000
3 L3	0.63 <k<(< td=""><td>0.80</td><td>1 Dm</td><td>1 Cm</td><td>1 Bm</td><td>1 Am</td><td>2 m</td><td>3 m</td><td>4 m</td><td>5 m</td><td>_</td><td>V5</td><td>Т8</td><td>>16</td><td>50,000</td></k<(<>	0.80	1 Dm	1 Cm	1 Bm	1 Am	2 m	3 m	4 m	5 m	_	V5	Т8	>16	50,000
4 L4	0.80 <k<:< td=""><td>1.00</td><td>1 Cm</td><td>1 Bm</td><td>1 Am</td><td>2 m</td><td>3 m</td><td>4 m</td><td>5 m</td><td>_</td><td>_</td><td colspan="3">* The grade symbols are identical to those of FEM 9.511.</td></k<:<>	1.00	1 Cm	1 Bm	1 Am	2 m	3 m	4 m	5 m	_	_	* The grade symbols are identical to those of FEM 9.511.			

• The grade symbols are identical to those of FEM 9.511. (Rules for Design of Serial Lifting Equipment: Classification of Mechanisms)

• NEMA

Component	Hois	t Model	Remarks for C1D2 Hoist
Component	C1D1	C1D2	Remarks for CTD2 Holst
Control Box	Pressure Explosion-Proof (NEMA7/NEMA9)	Pressure Explosion-Proof (NEMA7/NEMA9)	Complies with NEMA7/NEMA9 due to the same pressure and explosion resistance as the C1D1 hoist.
Terminal Box Set	Pressure Explosion-Proof (NEMA7/NEMA9)	Non-ignition explosion-proof (NEMA grade not evaluated)	Due to difference in cable ground, it is treated as a non-explosion-proof container without a NEMA grade.
Barrier Relay Box	Pressure Explosion-Proof (NEMA7/NEMA9)	Pressure Explosion-Proof (NEMA7/NEMA9)	Compatible with NEMA7/NEMA9 because it is equivalent to the C1D1 hoist.
Motor	Pressure Explosion-Proof (NEMA7/NEMA9)	Non-ignition explosion-proof (NEMA grade not evaluated)	Pressure explosion-proof for gases C and D, non- ignition explosion-proof for gases B.
Motor Terminal Box Set	Pressure Explosion-Proof (NEMA7/NEMA9)	Non-ignition explosion-proof (NEMA grade not evaluated)	Due to the difference in cable ground, it is treated as a non-explosion-proof container without a NEMA grade.

Operational Environment

Model	RNER2B	RNER2D				
Ambient temperature	-20°C —	+40°C				
Gradient of beam	No gradient in travel beam (for the hoist with trolley)					
Ambient humidity	85 % or less (no	condensation)				
Elevation	Elevation 1000 m or less					
Oxygen concentration	21 vol% or less					
Gas Temperature rating	T4 *	T4 *				
Dust Temperature rating	T4 *	-				
Non-conforming environment	A place with considerable amount of acid, alkali and salt A place with metal dust	A place with a plenty of powder and dust of general substances A place with considerable amount of acid, alkali and salt				

* Surface temperature of 135 degrees centigrade or less

Note: The product described herein is not intended for installation or use in applications where ignitable concentrations of

flammable gases, vapors, combustible dusts, or ignitable fibers are present continuously or for long periods of time.

RNER2B/D Division-Zone Comparison Chart

					Divisi	on 1				Division 2			
	Division System	Explosive at	tmosphere exi long t	ously or for a	Explosive atmosphere may be generated when equipment and facilities are in good condition.				Explosive atmosphere may be generated when equipment and facilities are in abnormal condition.				
		Gr. D	Gr. C	Gr. B	Gr. A	Gr. D	Gr. C	Gr. B	Gr. A	Gr. D	Gr. C	Gr. B	Gr. A
Gas		Propane	Ethylene	Hydrogen	Acetylene	Propane	Ethylene	Hydrogen	Acetylene	Propane	Ethylene	Hydrogen	Acetylene
		-	-	-	-	✓	✓	-	-	✓	✓	✓	-
		Zone 0				Zone 1				Zone 2			
	Zone	Gr. II A	Gr. II B	Gr	. II C	Gr. II A	Gr. II B	Gr	. II C	Gr. II A	Gr. II B	Gr	. II C
	System	Propane	Ethylene	Hydrogen	Acetylene	Propane	Ethylene	Hydrogen	Acetylene	Propane	Ethylene	Hydrogen	Acetylene
		-	-	-	-	✓	\checkmark	-	-	\checkmark	\checkmark	\checkmark	-

					Divisi	on 1				Division 2			
		Explosive atmosphere exists continuously or for a long time.				Explosive atmosphere may be generated when equipment and facilities are in good condition.				Explosive atmosphere may be generated when equipment and facilities are in abnormal condition.			
	Division System		Gr. G	Gr. F	Gr. E		Gr. G	Gr. F	Gr. E		Gr. G	Gr. F	Gr. E
			Grain Flour	Carbon Powder	Metal Powder		Grain Flour	Carbon Powder	Metal Powder		Grain Flour	Carbon Powder	Metal Powder
Dust			-	-	-		\checkmark	✓	-		✓	✓	-
		Zone 20				Zone 21				Zone 22			
		Gr. III A	Gr. I	II B	Gr. III C Gr. II		Gr. III B Gr. III C			Gr. III A	Gr.	III B	Gr. III C
	Zone		Non-con	ductive	Conductive		Non-conductive		Conductive		Non-conductive		Conductive
	System	Combustible Flyings	Grain Flour	Carbon Powder	Metal Powder	Combustible Flyings	Grain Flour	Carbon Powder	Metal Powder	Combustible Flyings	Grain Flour	Carbon Powder	Metal Powder
		-	-	-	-	~	~	\checkmark	-	✓	\checkmark	\checkmark	-

Gas	Division	Division1 can be used in environments where both gas and dust are present
and	System	Division2 can be used in the presence of both gas and dust, except for hydrogen
Dust	Zone System	No Mixing

 \checkmark = hoist complies

How to Use

RNER2 Series Electric Chain Hoist has products that can travel/traverse when combined with a trolley. Their push button switches for operation differ in the size and the operating method. Check the product model of the hoist and use it properly.



- The qualified personnel shall check the result of daily inspection. • When informed of an abnormality of the electric chain hoist, the qualified person shall take immediately
- When carrying out inspection and repair, secure the environment for safe work without electric shock and falling.

18

Failure to comply with these instructions may result in bodily injury or property damage.



• Do not open the cover in the presence of explosive atmosphere.

Failure to comply with this instruction may result in death or serious injury.

- To reduce the risk of ignition of hazardous atmospheres, disconnect the equipment from the supply
- To reduce the risk of ignition of hazardous atmospheres, conduit runs must have a sealing fitting

Failure to comply with these instructions may result in death or serious injury.

🗥 WARNING

- Do not use the Hook without a Hook Latch or damaged Hook.
- - Do not use the Load Chain with the Bottom Hook without smooth motion.

Prohibited

 Do not use the Load Chain when its brake does not function securely even without load, or when the stopping distance is too long.

• Do not use the product if it moves oppositely to the direction indicated on the push button switch.

• Do not use this equipment in environments that fall outside of the applicable scope.

Failure to comply with these instructions may result in death or serious injury.



(When any abnormality was found during inspection, turn off the power, indicate "FAILURE" and ask the

Mandatory• Check the slinging devices for no abnormality.

Failure to comply with these instructions may result in death or serious injury.



• Do not use the product with an illegible nameplate or warning label affixed

Failure to this instruction may result in the injury or the property

Prohibite



- When using the product for the first time, affix the labels indicating East, West, North and South on the
- Check the contents of the work and make sure that the electric chain hoist has proper performance for
- Mandator Check the contents of the work and operate the electric chain hoist at a place enabling to look out the
 - When looking out the operating area is difficult, arrange the monitor near the place for safety.
 - Operate the electric chain hoist at a place with firm foothold without danger of falling, stumbling, slipping
 - Before moving the load, warn all the surrounding people.
 - Even if the crane or the electric chain hoist is permanently installed and used for the same purpose repeatedly, check the contents of the work and make sure that the work does not exceed the capacity on
 - · Appoint the qualified person or competent personnel among the qualified personnel for operation of cranes and electric chain hoists. Indicate the name of the personnel on a place with legibility.

Daily Inspection of Electric Chain Hoist (Hook Mounted)



Mandatory

Neglecting to carry out daily inspection may result in death or serious injury.

Appearance

Item	Check method	Criteria	Action
Unauthorized modification	 Check visually. 	 Confirm no unauthorized modifications have been made to the hoist and trolley. 	Restore to original conditions.
Appearance of Nameplates and Warning labels	• Check visually.	 The nameplates that indicate the hoist model, speed and motor data should be legible and securely attached to the hoist. Warning labels should be legible and securely affixed to their respective locations. 	Perform cleaning and/or repair. If required replace it with a new nameplate or label. When replacement of a new nameplate or label is required, please contact HARRINGTON and provide the information from "Recording the Product serial Number." (P13) such as Lot No. and Serial No.
Housing and Mechanical Components	• Check visually.	 Hoist components including load blocks, suspension housing, chain attachments, clevises, yokes, suspension bolts, shafts, gears, bearings, pins and rollers should be free of cracks, distortion, significant wear and corrosion. Evidence of same can be detected visually or via detection of unusual sounds or vibration during operation. 	Replace the parts with deformation, damage, flaw, cracks, rust or corrosion.
Cable damage	• Check visually.	 No deterioration or damage on exterior covering 	Replace the cable.
Bolts, Nuts, Split pins, and Rivets	• Check visually and or using proper tools.	 Confirm all bolts, nuts and split pins are present and fastened securely. WARNING Ensure that all nuts, bolts, and split pins are sufficiently fastened, Missing Hardware of any kind could result in death or serous injury, and property damage. 	Tighten or replace bolts, nuts, split pins, and rivets as required.
Cleanliness	• Check visually.	 No excessive buildup of dirt, dust or debris 	Remove any dirt, dust and debris by cleaning.

[•] Carry out daily inspection before use. (When any abnormality is found during inspection, turn off the power, indicate "FAILURE" and ask a qualified person for repair.)

Load Chain

Item	Check method	Criteria	Action
Elongation of Pitch	Check visually	No apparent elongation	Refer to Load Chain (P55) of Chapter 2, Frequent inspection.
Abrasion of Wire Diameter	• Check visually	No apparent abrasion	Refer to Load Chain (P55) of Chapter 2, Frequent inspection
Deformation, Flaw, Entanglement	 Check visually Flaw Crack Crack Check visually for no foreign matter such as attached weld splatter. 	 No deep notch No deformation such as twist No attached weld splatter No entanglement No crack 	Replace the Load Chain.
Rust, Corrosion	Check visually	• No apparent rust and corrosion	Replace the Load Chain.
Twist	• Check visually	• No capsized link at Bottom Hook of double type Load Chain	Untwist the Load Chain.
Lubrication	Check visually	 To be oiled adequately 	Apply oil.
Mark	• Check visually	 Check the mark pitch and the indication. (Refer to "Checking the Marks" (P13) 	Replace the Load Chain.

Top Hook/Bottom Hook

ltem	Check method	Criteria	Action
Opening of the Hook	Check visually	• No apparent opening of the Hook	Carry out the inspection item of Top and Bottom Hook (P56) of Frequent inspection.
Abrasion	• Check visually	• No apparent abrasion	Carry out the inspection item of Top and Bottom Hook (P56) of Frequent inspection.
Deformation, Flaw, Corrosion, Rust	• Check visually	 No apparent deformation, flaw, corrosion, and rust 	Carry out the inspection item of Top and Bottom Hook (P56) of Frequent inspection.
Hook Latch	 Check visually and check the movement of the Hook Latch. 	 The Hook Latch is mounted securely inside the Hook opening. Latch should not be deformed. WARNING • Do not use the Hook without the Hook Latch. Use of the Hook without the Hook latch may result in death or serious injury. Prohibited 	Replace the Hook Latch.
Hook movement (Rotation)	Check visually and rotate the Hook by hand. Neck	 No apparent gap between the Bottom Yoke and the shank (at the neck). The Bottom Yoke rotates in both directions equally. The Bottom Yoke rotates smoothly. 	Replace the Hook.

Item	Check method	Criteria	Action
Movement of the Idle	Check the Idle Sheave by moving	<u> </u>	Replace the bearing of the
Sheave			Idle Sheave.
		• When checking, wear gloves and be careful for your finger not to be caught. Mandatory Otherwise it may result in injury.	
		The Idle Sheave rotates smoothly. The Idle Sheave does not rotate	
		smoothly when bearing is damaged or sheave shaft is deformed.	
		The Load Chain moves smoothly.	
		Move the Load Chain by hand	
Bottom Yoke	• Check visually.	No loosened bolt or nut	Attach the Bottom Hook to the Load Chain securely.

Peripheral parts of the body

Item	Check method	Criteria	Action
Chain Spring	Check visually	• No apparent shrinkage or compression	Carry out the inspection item of Chain Spring (P62) of Periodic inspection.
Cushion Rubber	• Check visually Cushion Rubber Stopper	 No apparent shrinkage or compression No peel off, crack of deformation of rubber Rubber Steel plate 	Replace the Cushion Rubber.

Pressure Resistant Containers within Hazardous Locations (Controllers, Barrier Relay Boxes, Motors)

Be careful of the following as it may cause serious accident igniting outer gas and/or dust with passage of inner flame due to damage of joint surface of pressure resistant containers.

ltem	Check method	Criteria	Action
Condition around joint surfaces	• Check visually	 No rust and corrosion Clean No damage No damage on paint No grease leakage Marce and the second sec	 Remove rust Remove by cleaning Replace the container Repaint Reapply the appropriate grease Refer to the technical material in the Appendix for how to apply to grease on joint surfaces of Pressure resistant containers.

Push Button Switch

ltem	Check method	Criteria	Action
Switch body	• Check visually	 No deformation, damage and no loosened screw Label indication of the push button switch can be seen clearly. 	Clean and repair the label or replace with a new label. Affix the label securely.

Function and Performance

• Check the following item with no load.

Item	Check method	Criteria	Action
Operational Check	• Press the push button and check each operation.	 The Load Chain can be wound smoothly. The Electric chain hoist moves in the same direction as that of the push button operation. When the operation is stopped, the motor stops immediately. When the Emergency Stop Button is pressed, all hoist motions stop. When operating other push button while the Emergency Stop Button is pressed, the hoist does not start operation. When canceling the Emergency Stop Button, the hoist operates normally. 	Refer to Chapter 3 "Guidance on Troubleshooting" (P80 to P81)
Brake	 Press the push button and check the operation of the Brake. 	 When stopping the operation, the Brake is applied immediately, and the Bottom Hook shall stop immediately. (Guideline: The travel of the Load Chain is within 2 to 3 links.) 	Carry out the inspection in accordance with the items in Chapter 2 "Periodic inspection" Electromagnetic Brake (P67).
Limit Switch	 Press the push button and check the operation of the Limit Switch. 	 When the hoist is operated to the upper or lower limit, the motor automatically stops. 	Replace the Limit Switch. Disassemble the actuator of the Limit Switch to clean.

Check for no Abnormal Sound	Press the push button and check the operation. NOTE	 No abnormal sounds or vibrations during operation. 	Replace the abnormal part. Apply oil on the Load Chain.
	 Sound is also an important check point. Always be careful for the noise of the electric chain hoist. 	• No unusual sound from the Load Chain when hoisting a load.	Check the Load Chain. (Refer to P20)

Daily Inspection of Motorized Trolley (RMR2)

Item	Method	Criteria	Action
Unauthorized modification	• Check Visually	 No authorized modification visible to the naked eye. 	Restore to original conditions.
Nameplates and Labels	Check Visually	 Securely affixed to the hoist and can be seen clearly. 	Clean and repair the label or replace with a new label.
Deformation and damage, flaw, crack, rust and corrosion of each part	• Check Visually Control box	• No apparent deformation, damage, flaw, crack, rust and corrosion Frame Gear case Motor cov	Replace the parts with deformation, damage, flaw, crack, rust and corrosion
Cable damage	Check Visually	 No deterioration or damage on exterior covering. 	Replace the cable
Deformation and damage of the cable entry	• Check Visually	• No deterioration or damage	Replace
Loose or missing bolts, nuts and split pins	• Check Visually	 Bolts, nuts and split pins are fastened securely. A WARNING Confirm all split pins are present and securely fastened. Mandatory Missing split pin may result in death or serious injury. 	Fasten bolts, buts and split pins securely.
Cleanliness	Check Visually	• No excessive buildup of dust or dirt.	Remove dust and dirt by cleaning.

Pressure Resistant Containers with Hazardous Location Construction (Controllers, Barrier Relay Boxes, Motors)

WARNING Be cautious, as damage to the joint surface of pressure-resistant containers may ignite outer gas or dust, causing a serious accident and injury or death.

Item	Check method	Criteria	Action
Condition around joint surfaces	• Check visually	 No rust and corrosion Clean No damage No damage on paint No grease leakage MARNING Apply grease on joint surfaces after opening covers or disassembling motors according to the procedure described in Technical Material of Mandatory Appendix. Failure to comply with this instruction may result in death or serious injury. 	 Remove rust Remove by cleaning Replace the container Repaint Reapply the appropriate grease Refer to the technical material in the Appendix for how to apply to grease on joint surfaces of Pressure resistant containers.

Function and Performance

• Check the following item with no load.

ltem	Check method	Criteria	Action
Indication of Nameplates and Labels	• Check visually	 No peel off. Indication can be seen clearly. 	Clean and repair label or replace with a new label.
Deformation and damage of each part	• Check visually	 No apparent deformation and corrosion No apparent deformation on the Frame 	Replace the deformed or damaged part.
Item	Check method	Criteria	Action
Operational Check	Press the push button to check the operation.	 To travel smoothly. No meandering and vibration. The electric chain hoist moves in the same direction as that of the push button operation. When the operation is stopped, the motor stops immediately. When the Emergency Stop Button is pressed, all hoist motions stop. When operating other push button while the Emergency Stop Button is pressed, the hoist does not start operation. When canceling the Emergency Stop Button, the hoist operates normally. 	Refer to Chapter 3 "Guidance on Troubleshooting" (P80 to P81)
Brake	 Press the push button to check the operation of the Brake. 	 When the operation is stopped, the Brake is applied and the motor stops immediately. 	Carry out the inspection in accordance with the items in Chapter 2 "Periodic inspection" Electromagnetic Brake (P67).

1

Daily Inspection of Manual Trolley (RTSG)

Appearance

ltem	Check method	Criteria	Action
Loosened or fallen off bolts, nuts		 Bolts, nuts and split pins are fastened securely WARNING 	Fasten bolts, nuts and split
and split pins		• Even a drop off of a split pin may cause of drop of the body. Be sure to check it.	pins securely.
		Mandatory Drop off of split pin may result in death or serious injury.	

Function and Performance

• Check the following item with no load.

Item	Check method	Criteria	Action
Operational Check	 Check the traveling motion of the electric chain hoist by moving it manually. 	 To travel smoothly. No meandering and vibration. 	Carry out Chapter 2 "Periodic inspection"

1

How to Operate the Push Button Switches

Do not hang the Push Button Switch Cord on other object, or pull the cord strongly.
 Do not use the Push Button Switch if its button does not operate smoothly.
 Do not bundle or tie the cord for the adjustment of its length.

Prohibited Failure to comply with this instruction causes bodily injury or loss of property.



• When taking hand off the Push Button Switch after operation, do not throw it. Be careful not to hit other worker with the Push Button Switch.

Failure to comply with this instruction causes bodily injury or loss of property.

3-Push Button Switch Set

3-Push Button Switch Set is equipped with a lock type emergency stop button and lift/lower push buttons. Two-step push button switch is mounted as Lift/lower push button. Refer to the operation method of the corresponding specification.



5-Push Button Switch Set

5-Push Button Switch Set is equipped with a lock type emergency stop button and lift/lower push buttons. Two-step push button switch is mounted as Lift/lower push button switches. Refer to the operation method of the corresponding specification. Moving direction of the trolley is expressed as East/West for traversing motion in the operational instruction of the Push Button Switch Set.

Push Button Switch Set.



Operation

General

Do not use the electric chain hoist exceeding the ratings (intermittent rating) of the lifting motor and the maximum start-up frequency.

Do not use the electric chain hoist by the voltage other than the rated voltage.

Prohibited• Do not use the Emergency Stop Button for ordinary stop operation.

- If you notice any abnormal noises, sparks, or unusual odors while this equipment is operational, immediately stop the work and turn the equipment off.
- Do not open the access panels to electrical instruments while this equipment is operational.
- Do not allow the hook to strike against other objects.

Failure to comply with these instructions may result in death or serious injury.



· Follow the operating environment and conditions for the electric chain hoist.

Failure to comply with this instruction may result in death or serious injury.

Mandatory

Slinging



Lifting/Lowering





In Abnormality or Failure





- If the electric chain hoist is damaged or abnormal noise or vibration occurs, stop the operation immediately.
- If the electric chain hoist moves in the direction opposite to the indication on the Push Button Switch, stop the operation immediately.
- Mandatory
- When the twist, entanglement, crack, deformation, attachment of foreign matters or abnormal engagement of the Load Chain and the Gear is observed, stop the operation immediately.
 - When any abnormality is observed during the operation, indicate "FAILURE" and contact qualified personnel.
 - When the power is interrupted, secure safety and contact qualified personnel.
 - Failure to comply with these instructions may result in death or serious injury.

How to Sling the Load Properly



Sling the load at the center line of the hook shaft.



Improper hook position of the lifted load or the sling

Angle exceeding 120° Angle Too side



Hook latch unable to close



Point loading the tip of the hook

How to Suppress the Swinging of a Load



Swinging of a load makes it difficult and dangerous to move the trolley. The basics of operation are not to make a load swing. To do that keep the following instructions.

• Do not lift a load in an inclined direction.

120° or less

- Start slowly when traveling the load.
- Do not lift suddenly.

Even if you keep the above instructions, the lifted load may swing at the start and the stop of the electric chain hoist. Following operation can reduce the swing of the lifted load.

Operation

- 1) Press the Traverse Button. (Fig. a)
- 2) When the trolley starts to move, the lifted load delays a bit. (Fig. b)
- 3) Release the button a bit before the time when the lifted load swings to the center position.
- 4) When the lifted load comes to the position just beneath the electric chain hoist, press the button again and continue to traverse the load. (Fig. c)



(to be continued)

Precautions After Work

A CAUTION

• Do not store the electric chain hoist in an overloaded state.

Failure to comply with these instructions can cause bodily injury or loss of property.

Prohibited



• Store the electric chain hoist with the power off.

• Indicate "FAILURE" on the electric chain hoist when it requires repair and do not use it.

- Wipe off dust and water, apply oil at the neck of the Hook and the Load Chain and store the hoist.
 Confirm there is no dirt, debris or moisture on the load chain, limit switch and chain container before placing in storage.
- The storage location should be clean and dry.
- The hoist/trolley should be covered when not in use.

Failure to comply with these instructions can cause bodily injury or loss of property.

NOTE

- Keep the pendant push buttons clean and free from dirt, dust, debris and oil.
- When storing the electric chain hoist for an extended time, it is recommended to operate the hoist without load intermittently to maintain lubrication and effective brake operation.
- When putting the electric chain hoist on the floor, first remove the Chain Container. Otherwise, the Chain Container may be damaged.
- When not using the electric chain hoist, raise the Bottom Hook to a height not to hinder people passing by.
 Determine the place to store the electric chain hoist in advance.

Workflow of Assembling and Installation

The steps required for assembling and installing the product by qualified personnel are outlined below. To avoid rework and ensure a smooth and efficient process, please review the workflow carefully before beginning the assembly and installation process.



Checking Power and Power Cable

Checking the Power

•



• Check that the rating of the breaker satisfies the specification required by the electric chain hoist.

Check that the source voltage satisfies the rated voltage of the electric chain hoist.

Failure to comply with this instruction may result in death or serious injury.

Mandatory 200V Class

Code		RNER2 only		RNER2M combination	
RNER2B	RNER2D	Wire size (mm²/AWG)	Capacity of fuse and circuit breaker (A)	Wire size (mm²/AWG)	Capacity of fuse and circuit breaker (A)
RNER2B-010LD	RNER2D-010LD				
RNER2B-010SD	RNER2D-010SD				
RNER2B-015SD	RNER2D-015SD		15		20
RNER2B-020CD	RNER2D-020CD				
RNER2B-020LD	RNER2D-020LD	2/14		2/14	
RNER2B-020SD	RNER2D-020SD				
RNER2B-025SD	RNER2D-025SD		30		30
RNER2B-030CD	RNER2D-030CD				30
RNER2B-050LD	RNER2D-050LD				

400V Class

C	Code		RNER2 only		combination
RNER2B	RNER2D	Wire size (mm²/AWG)	Capacity of fuse and circuit breaker (A)	Wire size (mm²/AWG)	Capacity of fuse and circuit breaker (A)
RNER2B-010LD	RNER2D-010LD				
RNER2B-010SD	RNER2D-010SD				
RNER2B-015SD	RNER2D-015SD		10		10
RNER2B-020CD	RNER2D-020CD				
RNER2B-020LD	RNER2D-020LD	2/14		2/14	
RNER2B-020SD	RNER2D-020SD				
RNER2B-025SD	RNER2D-025SD		45		45
RNER2B-030CD	RNER2D-030CD		15		15
RNER2B-050LD	RNER2D-050LD				

500V Class

Co	de	RNE	R2 only	RNER2M combination	
RNER2B	RNER2D	Wire size (mm²/AWG)	Capacity of fuse and circuit breaker (A)	Wire size (mm²/AWG)	Capacity of fuse and circuit breaker (A)
RNER2B-010LD	RNER2D-010LD				
RNER2B-010SD	RNER2D-010SD				
RNER2B-015SD	RNER2D-015SD		5		10
RNER2B-020CD	RNER2D-020CD			0/4.4	
RNER2B-020LD	RNER2D-020LD	2/14		2/14	
RNER2B-020SD	RNER2D-020SD				
RNER2B-025SD	RNER2D-025SD				
			10		10
RNER2B-030CD	RNER2D-030CD				
RNER2B-050LD	RNER2D-050LD				

Checking the Power Cable



• Do not use the cable other than the cable attached to the Body or optional Power Cable. Failure to comply with this instruction causes bodily injury or loss of property.

A CAUTION



• Satisfy the maximum permissible length and core cross section of the Power Cable.

Failure to comply with this instruction causes bodily injury or loss of property.

Mandatory

Refer to the following table for the permissible length and the size of the standard Power Cable. When using cable of a size other than those described in the table, determine acceptable cable length using the following formula.

Permissible length (m) = $\overline{30.8}$

1000x Cross section of one core (mm²)×Rated voltage (V)×0.0230.8Rated current (A)

200V Class

Code		RNER2 only		RNER2M Combination	
RNER2B	RNER2D	Wire size (mm²/AWG)	Permissible length(m)	Wire size (mm²/AWG)	Permissible length(m)
			60Hz		60Hz
			208-230V		208-230V
RNER2B-010LD	RNER2D-010LD	2 /14 (3.5/12)	28 (49)	2/14 (3.5/12)	21
RNER2B-010SD	RNER2D-010SD				
RNER2B-015SD	RNER2D-015SD				
RNER2B-020CD	RNER2D-020CD				(37)
RNER2B-020LD	RNER2D-020LD				
RNER2B-020SD	RNER2D-020SD		15 (26)		13 (23)
RNER2B-025SD	RNER2D-025SD				
RNER2B-030CD	RNER2D-030CD				
RNER2B-050LD	RNER2D-050LD				

Note) The figures in parenthesis () indicate the cable one size larger than the standard size.
400V Class

С	ode		RNER2 only		RNE	ER2M Combina	ition
			Permissibl	e length(m)		Permissibl	e length(m)
RNER2B	RNER2D	Wire size	50Hz	60Hz	Wire size	50Hz	60Hz
		(mm²/AWG)	380V	440-460V	(mm²/AWG)	380V	440-460V
RNER2B-010LD	RNER2D-010LD						
RNER2B-010SD	RNER2D-010SD						
RNER2B-015SD	RNER2D-015SD		93 (162)	96 (168)		64 (112)	71 (124)
RNER2B-020CD	RNER2D-020CD		(102)	(108)		(112)	(124)
RNER2B-020LD	RNER2D-020LD	2/14 (3.5/12)			2/14 (3.5/12)		
RNER2B-020SD	RNER2D-020SD	(0.0/12)			(0.0/12)		
RNER2B-025SD	RNER2D-025SD		59	62		46	50
RNER2B-030CD	RNER2D-030CD		(104)	(109)		(80)	(89)
RNER2B-050LD	RNER2D-050LD						

.

Note) The figures in parenthesis () indicate the cable one size larger than the standard size.

500V Class

Co	de	RNE	R2 only	RNER2M C	ombination
		Wire size	Permissible length(m)	Wire size	Permissible length(m)
RNER2D	RNER2D	(mm²/AWG)	60Hz	(mm²/AWG)	60Hz
			575V		575V
RNER2B-010LD	RNER2D-010LD				
RNER2B-010SD	RNER2D-010SD				
RNER2B-015SD	RNER2D-015SD		73		54
RNER2B-020CD	RNER2D-020CD		(128)		(96)
RNER2B-020LD	RNER2D-020LD	2/14 (3.5/12)		2/14 (3.5/12)	
RNER2B-020SD	RNER2D-020SD	(0.0/12)		(0.3/12)	
RNER2B-025SD	RNER2D-025SD		44		37
RNER2B-030CD	RNER2D-030CD		(78)		(64)
RNER2B-050LD	RNER2D-050LD				

Note) The figures in parenthesis () indicate the cable one size larger than the standard size.

Installation

\bigcirc	 Installation and removal of the electric chain hoist must be carried out by qualified personnel only. Consult the distributor or Harrington for installation or consign the installation work to a special installer or personnel with expertise. Do not install the electric chain hoist in a location that is exposed to rain or water. See Operational Environment (Page 16) Do not install the electric chain hoist within the travel path of other trolleys or any other moving
Prohibited	equipment.
Prohibited	• Do not use the electric chain hoist where contact may occur with other fixed or moving objects.
	Failure to comply with these instructions may result in death or serious injury.
	• When installing or removing the electric chain hoist, follow the instructions in the Owner's Manual.
	 Carry out the work for 10-ohm (or less) grounding and installation of an ground leakage breaker. Travel beam
U	When the installation is completed, carry out "Check after Installation". (See Page 48)
Mandatory	Connect the power after all installation work has been completed and just
	 before the operation check. Mount the stopper at both ends of the travel beam for trolley. <fig. a="">.</fig.>
	 Make sure that the strength of the structure is sufficient to install the electric
	chain hoist and its rated capacity.
	Perform installation work in an area that provides stable footing. Failure to comply with these instructions may result in death or serious injury.
	[A]
	Connect the Power Cable to a properly sized power supply.
Mandatory	Failure to comply with this instruction causes bodily injury or loss of property.

Connecting Power and Power Cable

When connecting the Power Cable to the power, connect the cable in accordance with the following instructions.

- Connect the electric chain hoist to the power through a breaker.
- Connect the electric chain hoist in the correct phase. (When "Check after Installation (P48)" is completed, carry out the operation check for the correct phase.)
- Ground wire is a green colored covered cable. Carry out 10-ohm (or less) grounding work.
- Use correct breaker and Power Cable referring to Checking the Power and the Power Cable (P36) for the breaker capacity, Power Cable length and its size.

The applicable fittings are as follows:







Installing the Hook Suspended Type (hoist only)

Checking Installation Method and Place



When using an electric chain hoist suspended (as a single unit) without combination with a trolley, make sure that the Hook Latch of the Top Hook closes securely.
Install the electric chain hoist so that the Top Hook can swing freely.

Failure to comply with these instructions may result in death or serious injury.

Installing the Trolley Combined Model

Mounting the Hoist to the Travel Beam

- 1) Make sure that the dimensions of the Trolley Flange matches the size of the beam to which the trolley is installed.
- 2) Make sure that the beam is level and secure.
- 3) Install the electric chain hoist combined with the trolley from the end of the beam. Securely re-install the trolley end stop on the beam.



Checking the Number and Positions of the Assembled Adjusting Collars

When installing a trolley to the beam, the length of the Lifting Shaft (width between frames) must be adjusted in accordance with the beam width. Wrong number or position of collars may result in the drop of the electric chain hoist. Insert the correct number of collars with correct ratings and for beam width at the correct positions by referring to the following table.

										Nur	nber	of A	djust	ing S	pace	ers											
	il flange width	(in)	2 ⁵ / ₁₆	2 ¹ / ₂ 2 ⁵ / ₈	2 ⁷ /8 2 ¹⁵ /16	3	3 ¹ /4	3 ⁹ / ₁₆	3 ⁷ /8	3 ¹⁵ /16	4	4 ³ / ₁₆	4 ⁵ / ₁₆	4 ⁷ / ₁₆	4 ¹¹ / ₁₆ 4 ³ / ₄	4 ¹⁵ / ₁₆	5	5 ³ / ₁₆	5 ⁵ / ₁₆	5 ³ /8	5 ⁵ /8	5 ¹¹ / ₁₆ 5 ³ / ₄	6	6 ¹ /8	6 ⁵ / ₁₆	6 ⁷ / ₁₆	6 ¹¹ / ₁₆
Capacity (t)	Parts Name	(mm)	58	64 66	73 74	75 76	82	90 91	98	100	102	106	110	113	119 120	125	127	131	135	137	143	149 150	153	155	160	163	170
	Thin	Inner	1+2	2+3	4+4	1+0	1+2	2+3	0	1+	-0	1+2	2+2	2+3	3+4	4+4	4+1	5+1	2-	+2	3+3	4+4	4+1	1+1	2+2	2+3	3+0
	spacer	Outer	5	3	0	7	5	3	8	7	7	5	4	3	1	0	3	2	4	1	2	0	3	6	4	3	5
	Thick	Inner				0						1-					1-	+2		2+	-2		2+3		3+3		3+4
1	spacer	Outer			ļ	5							3				0	2		1			0		3		2
l '	Fixing	Inner																							C		
	spacer	Outer																							2	2	
	Thick	Inner		0													+1										
	spacer L	Outer		2													0										
	Thin	Inner			<u> </u>	<u> </u>	1+2		3+4	0	1+0	1+1	1+2	2+2		4+4		1+1	1+2	\vdash	3+3	4+0		1+1		2+2	3+3
	spacer	Outer			<u> </u>	\sim	5	3	1	8	7	6	5	4	2	0	7	6	5	4	2	4	3	6	5	4	2
	Thick	Inner				\sim					(1+1			1-			2+		
2	spacer	Outer				\sim					Ę	5							3				2		1		
	Fixing spacer	Inner		\geq	\geq	\leq																					
	Thick	Inner		_	<u> </u>	<u> </u>		0										1-	۰ 1								
	spacer L	Outer			<u> </u>	<u> </u>		2										()								
	Thin	Inner			_		1+2		3+4	0	1+0	1+1		2+2		4+4		1+1		2+2				1+1	1+2		
	spacer	Outer			_	<u> </u>	5	3	1	8	7	6	5	4	2	0	7	6	5	4	2	4	3	6	5	4	2
	Thick	Inner			<u> </u>	<u> </u>					(1+1				+2		2+		
3	spacer	Outer			\geq	\geq					Ę	5							3			2	2		1		
	Fixing spacer	Inner																									
	Thick	Inner	0															1-	⊦1								
	spacer L	Outer		_	_	_		2										()								
	Thin	Inner								0	1+0	1+1	1+2	2+2	3+3	0	1+0	1+1	2-	+2	3+3	4+0	4+1	1+1	2+2	2+3	3+0
	spacer	Outer								8	7	6	5	4	2	8	7	6	4	1	2	4	3	6	4	3	5
5	Thick	Inner													(0-	+1		1+1		1+2
	spacer	Outer													3	3							2		1		0
	Thick	Inner										(1-						
	spacer L	Outer										2	2								()					

NOTE: 1) Description for inner spacers

Adjusting spacer arrangement for Low Head Suspension (Beam flange width 58-170mm)

For example :0+1

0 : The number of spacers on the left side of the shaft

1 : The number of spacers on the right side of the shaft

2) Adjustment of trolley width

Refer to Page 41.

Adjust the dimensions of trolley by appropriately increasing or decreasing the number of inner or outer adjusting spacers shown in the above table.

נשר	us	sung s	pace		Tan	yen					Tea		usp				am	na	ige			175	-00		<u>'''</u>			
											Nu	mber	of A	djust	ing S	Space	ers											
<u>ا</u>		l flange vidth	(in)	6 ⁷ /8	7	7 ^{1/} 16 7 ^{1/} 8	7 ¹ /4 7 ^{5/} 16	77/8	8	8 ^{7/} 16	8 ^{11/} 16	9	91/8	97/8	10	10 ¹ /8	101/4	10 ³ /8	10 ¹ /2	11	11 ¹ /8	11 ¹ /4	11 ³ /8	11 ⁵ /8	11 ³ /4	11 ¹³ /16	117/8	12
and an and the	5 1	Parts Name	(mm)	175	178	180 181	184 185	200	203	215		229	232	250	254	257		264	267	279		286	289	295	298	300	302	305
		Thin	Inner	4+4	4+1	1+1	1+2	4+4	5+0	2+3	3+4	1+1	1+2	4+0	1+1		2+2	2+3	3+3	1+1		2+2	2+3	3+0	4+0	4-	-1	4+2
		spacer	Outer	0	3	6	5	0	3	3	1	6	5	4	6	5	4	3	2	6	5	4	3	5	4	3	}	2
		Thick	Inner	3+3	3+4		0		0+1	1-	-	2-		2+3			3+3				4+	-4				4+5		
	1	spacer	Outer	3	2		9		8	7	7	Ę	5	4			3				1	1				0		
		Fixing	Inner	<u> </u>)												1+1											
		spacer	Outer	2	2												0											
		Thick	Inner													1+1												
┢	_	spacer L	Outer	4.4	4.4	4.4	4.0	4.4	4.0	0.0	0.0	4.4	4.4	4 . 4	4.4	0	4.0	0.0	0.0	4.4	4.0	0.0	0.0	0.0	0.4	4.4	4.4	F . 4
		Thin spacer	Inner Outer		1+4	1+1		4+4	1+0 7		3+3 2		1+1 6	4+4	4+1 3			2+3		4+1 3	1+2 5	2+2 4		3+3		4+4 0	4+1 3	5+1
		· .		0 2+2	3	6	5 0	0		3 1+1	2	3 1+2	0 2-	0	3	2 2+3	1	3 3+	2	3 3+4	э	4	3	2 +4	1	0	3	2
		Thick spacer	Inner Outer	2+2	0		9			7		6	2-			2+3 4		3		2			4-	-)
	2	Fixing		-						1		0	<u>``</u>	,						2								,
		spacer	Inner				\geq	<u> </u>										1-	+1 									
L		Thick	Inner													1+1												
		spacer L	Outer													0												
		Thin	Inner	4+4	1+4	1+1		4+4			3+3			4+4				2+3						3+3				
		spacer	Outer	0	3	6	5	0	7	3	2	3	6	0	3	2	1	3	2	3	5	4	3	2	1	0	3	2
		Thick spacer	Inner	2+2	3+2 0		0			1+1 7		1+2 6	2- t			2+3 4		3+		3+4				+4				⊦5)
	3	Fixing	Outer	-			9			/		0	;)		4				2							(,
		spacer	Inner			<u> </u>	<u> </u>											1-	⊦1 									
L		Thick	Inner													1+1												
		spacer L	Outer													0												
		Thin	Inner	4+4			4+3	4+4			3+4			4+4	1+1			2+3						4+3				5+1
		spacer	Outer	0	3	2	1	0	7	3	1	6	5	0	6	5	4	3	2	2	5	4	3	1	0	4	3	2
	5	Thick	Inner			1+2		2+2		3+3			4+4				5+5			5+6			6+6				6+7	
	-	spacer	Outer	1	0	1	0	9		7			5				3			2			1				0	
		Thick spacer L	Inner													1+1												
		spacer L	Outer													0												

Adjusting spacer arrangement for Low Head Suspension (Beam flange width 175-305mm)

NOTE: 3) Spacer arrangement example



Adjusting spacer arrangement for Lug Suspension

		<u> </u>											diuot	him a C	2000												
										NU	mber		ujusi	ung a	pace	=15											
۱ <u>ا</u>	il flange width	(in)	2⁵/ 16	2 ¹ / ₂ 2 ⁵ / ₈	2 ⁷ /8 2 ¹⁵ /16	3	3 ¹ /4	3 ⁹ /16	3 ⁷ /8	3 ¹⁵ /16	4	4 ³ / ₁₆	4 ⁵ / ₁₆	4 ⁷ / ₁₆	4 ¹¹ / ₁₆ 4 ³ /4	4 ¹⁵ / ₁₆	5	5 ³ / ₁₆	5 ⁵ /16	5 ³ /8	5 ⁵ /8	5 ¹¹ / ₁₆ 5 ³ /4	6	6 ¹ /8	6 ⁵ / ₁₆	6 ⁷ / ₁₆	6 ¹¹ / ₁₆
Capacity (t)	Parts Name	(mm)	58	64 66	73 74	75 76	82	90 91	98	100	102	106	110	113	119 120	125	127	131	135	137	143	149 150	153	155	160	163	170
	Thin					_				0	1+0	1+1	1+2	2+2	3+3	0	1+0	1+1	2-	+2	3+3	4+0	4+1	1+1	2+2	2+3	3+0
E	spacer									8	7	6	5	4	2	8	7	6	4	1	2	4	3	6	4	3	5
5	Thick											()					1-	+1			1.	+2		2+2		2+3
	spacer											Ę	5					(3			:	2		1		0

										Nu	mber	of A	djust	ting S	Space	ers											
	l flange vidth	(in)	6 ⁷ /8	7	7 ¹ / ₁₆ 7 ¹ / ₈	7 ¹ /4 7 ⁵ /16	7 ⁷ /8	8	8 ⁷ /16	8 ¹¹ /16	9	9 ¹ /8	9 ⁷ /8	10	10 ¹ /8	10 ¹ /4	10 ³ /8	10 ¹ / ₂	11	11 ¹ /8	11 ¹ /4	11 ³ /8	11 ⁵ /8	11 ³ /4	11 ¹³ /16	11 ⁷ /8	12
	Parts Name	(mm)	175	178	180 181	184 185	200	203	215	220	229	232	250	254	257	260	264	267	279	283	286	289	295	298	300	302	305
	Thin		4+4	4+1	5+1	4+3	4+4	1+0	2+3	3+4	1+1	1+2	4+4	1+1	1+2	2+2	2+3	3+3	5+1	1+2	2+2	2+3	4+3	4+4	4+0	4+1	5+1
5	spacer		0	3	2	1	0	7	3	1	6	5	0	6	5	4	3	1	2	5	4	3	1	0	4	3	2
5	Thick		2+2		2+3		3+3		4+4			5+5				6+6			6+7			7+7				7+8	
	spacer		1	0	1	0	9		7			5				3			2			1				0	

Checking the Number and Positions of the Assembled Adjusting Collars

When installing a trolley to the beam, the length of the Lifting Shaft (width between frames) must be adjusted in accordance with the beam width. Wrong number or positions of collars may result in the drop of the electric chain hoist. Insert the correct number of collars with correct ratings and for beam width at the correct positions by referring to the following table.

										Nu	mber	of A	djust	ting S	Space	ers											
	il flange width	(in)	2	2 ⁵ /16	2 ¹ / ₂ 2 ⁵ / ₈	2 ⁷ /8 2 ¹⁵ /16	3	3 ¹ /4	3 ⁹ /16	3 ⁷ /8	3 ¹⁵ /16	4	4 ³ / ₁₆	4 ¹⁵ / ₁₆	4 ⁷ / ₁₆	4 ¹¹ / ₁₆ 4 ³ / ₄	4 ¹⁵ / ₁₆	5	5 ³ /16	5 ⁵ /16	5 ³ /8	5 ⁵ /8	5 ⁷ /8 5 ¹⁵ / ₁₆	6	6 ¹ /8	6 ⁵ / ₁₆	6 ⁷ / ₁₆
Capacity (t)	Parts Name	(mm)	50	58	64 66	73 74	75 76	82	90 91	98	100	102	106	110	113	119 120	125	127	131	135	137	143	149 150	153	155	160	163
	Thin	Inner		3+3	0+0	1+1	1+2	2+3	0+0	1+1	1+2	2+2	2+3	3+3	3+4	0+1	1+2	2+2	1+1	1+2	2+2	3+3	0+0	0+1	1+1	1+2	2+2
	spacer	Outer		2	8	6	5	3	8	6	5	4	3	2	1	7	5	4	7	6	5	3	9	8	7	6	5
1	Thick	Inner		0+0	1+1	1+1	1+1	1+1	2+2	2+2	2+2	2+2	2+2	2+2	2+2	3+3	3+3	3+3	0+0	0+0	0+0	0+0	1+1	1+1	1+1	1+1	1+1
	<u> </u>	Outer		6	4	4	4	4	2	2	2	2	2	2	2	0	0	0	5	5	5	5	3	3	3	3	3
	Fixing spacer	Inner		-	_	-	-	-	_	-	-	_	_	-	-	_	_	_	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1
	Thin	Inner						2+2	3+4	0+1	1+1	1+2	2+2	2+3	3+3	0+0	1+1	1+2	2+2	2+3	3+3	0+0	1+1	1+2	1+1	1+2	2+2
	spacer	Outer						3	0	6	5	4	3	2	1	7	5	4	3	2	1	7	5	4	7	6	5
2	Thick	Inner						0+0	0+0	1+1	1+1	1+1	1+1	1+1	1+1	2+2	2+2	2+2	2+2	2+2	2+2	3+3	3+3	3+3	0+0	0+0	0+0
	-	Outer						6	6	4	4	4	4	4	4	2	2	2	2	2	2	0	0	0	11	11	11
	Fixing spacer	Inner						-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	1+1	1+1	1+1
	Thin	Inner						1+2	3+3	0+0	0+1	1+1	1+2	2+2	2+3	3+4	0+1	1+1	1+2	2+2	2+3	3+4	1+4	1+5	1+1	1+2	2+2
	spacer	Outer						7	4	10	9	8	7	6	5	3	9	8	7	6	5	3	5	4	7	6	5
3	Thick	Inner						2+2	2+2	3+3	3+3	3+3	3+3	3+3	3+3	3+3	4+4	4+4	4+4	4+4	4+4	4+4	5+4	5+4	0+0	0+0	0+0
		Outer						5	5	3	3	3	3	3	3	3	1	1	1	1	1	1	0	0	11	11	11
	Fixing spacer	Inner						-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	1+1	1+1	1+1
	Thin	Inner									0+0	0+1	1+1	1+2	2+2	3+3	0+0	0+1	1+1	1+2	2+2	3+3	0+0	0+1	1+2	1+2	2+2
	spacer	Outer									8	7	6	5	4	2	8	7	6	5	4	2	8	7	6	5	4
5	Thick	Inner									0+0	0+0	0+0	0+0	0+0	0+0	1+1	1+1	1+1	1+1	1+1	1+1	2+2	2+2	2+2	2+2	2+2
	spacer	Outer									5	5	5	5	5	5	3	3	3	3	3	3	1	1	1	1	1
	Fixing spacer	Inner									-	-	-	-	-	_	-	-	-	-	-	-	-	-	-	-	-

										N	umb	er of	Adju	stin	g Spa	acers	5											
	il flange width	(in)	6 ¹¹ / ₁₆	6 ⁷ /8	7	7 ¹ / ₁₆ 7 ¹ / ₈	7 ¹ /4 7 ⁵ /16	7 7/8	8	8 ⁷ /16	8 ¹¹ / ₁₆	9	9 ¹ / ₈	9 ⁷ /8	10	10 ¹ /8	10 ¹ /4	10 ³ /8	10 ¹ / ₂	11	11 ¹ /8	11 ¹ /4	11 ³ /8	115/8	11 ³ / ₄	11 ¹³ /16	117/8	12
Capacity (t)	Parts Name	(mm)	170	175	178		184 185	200	203	215	220	229	232	250	254	257	260	264	267	279	283	286	289	295	298	300	302	305
	Thin	Inner	3+3	0+0	0+1		1+2	4+4	4+5	2+3	3+3	4+5		0+0	0+1	1+1	1+2	<u> </u>	2+3	4+5	1+1	1+2	2+2	3+3	3+4	4+4	4+5	1+5
	spacer	Outer	3	9	8	7	6	1	0	4	3	0	7	9	8	7	6	5	4	0	7	6	5	3	2	1	0	3
1	Thick	Inner	1+1	2+2	2+2	2+2	2+2	2+2	2+2	0+0	0+0	0+0	1+1	2+2	2+2	2+2	2+2	2+2	2+2	2+2	3+3	3+3	3+3	3+3	3+3	3+3	3+3	4+3
	_ · _	Outer	3	1	1	1	1	1	1	7	7	7	5	3	3	3	3	3	3	3	1	1	1	1	1	1	1	0
	Fixing spacer	Inner	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1
	Thin	Inner	3+3	0+0	0+1	1+1	1+2	0+0	0+1	2+3	3+3	4+5	1+1	0+0	0+1	1+1	1+2	2+2	2+3	4+5	1+1	1+2	2+2	3+3	3+4	4+4	4+5	1+5
	spacer	Outer	3	9	8	7	6	9	8	4	3	0	7	9	8	7	6	5	4	0	7	6	5	3	2	1	0	3
2	Thick	Inner	0+0	1+1	1+1	1+1	1+1	2+2	2+2	2+2	2+2	2+2	3+3	4+4	4+4	4+4	4+4	4+4	4+4	4+4	5+5	5+5	5+5	5+5	5+5	5+5	5+5	6+5
		Outer	11	9	9	9	9	7	7	7	7	7	5	3	3	3	3	3	3	3	1	1	1	1	1	1	1	0
	Fixing spacer	Inner	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1
	Thin	Inner	3+3	0+0	0+1	1+1	1+2	0+0	0+1	2+3	3+3	4+5	1+1	0+0	0+1	1+1	1+2	2+2	2+3	4+5	1+1	1+2	2+2	3+3	3+4	4+4	4+5	1+5
	spacer	Outer	3	9	8	7	6	9	8	4	3	0	7	9	8	7	6	5	4	0	7	6	5	3	2	1	0	3
3	Thick	Inner	0+0	1+1	1+1	1+1	1+1	2+2	2+2	2+2	2+2	2+2	3+3	4+4	4+4	4+4	4+4		4+4	4+4	5+5	5+5	5+5	5+5	5+5	5+5	5+5	6+5
		Outer	11	9	9	9	9	7	7	7	7	7	5	3	3	3	3	3	3	3	1	1	1	1	1	1	1	0
	Fixing spacer	Inner	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1
	Thin	Inner	3+3	0+4	1+4	1+1	1+2	0+0	0+1	2+3	3+3	0+1	1+1	0+0	0+1	1+1	1+2	2+2	2+3	0+1	1+1	1+2	2+2	3+3	3+4	4+4	1+4	1+5
	spacer	Outer	2	4	3	6	5	8	7	3	2	7	6	8	7	6	5	4	3	7	6	5	4	2	1	0	3	2
5	Thick	Inner	2+2	3+2	3+2	0+0	0+0	1+1	1+1	1+1	1+1	2+2	2+2	3+3	3+3	3+3	3+3	3+3	3+3	4+4	4+4	4+4	4+4	4+4	4+4	4+4	5+4	5+4
	<u> </u>	Outer	1	0	0	9	9	7	7	7	7	5	5	3	3	3	3	3	3	1	1	1	1	1	1	1	0	0
	Fixing spacer	Inner	-	-	-	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1	1+1

NOTE) 1) Take note the numbers on spacers of inner side as follows.

Example of 0 + 1 0 + 1

Number on side plate G or S Number on side plate SN

2) Adjustment of trolley width

See clause 3–3.

Adjust the dimensions by appropriately increasing or decreasing the number of inner or outer adjusting spacers, without strictly adhering to the number in the above table.

3) The spacers are delivered in different colors as follows:

Type A: Thick Spacer and Thin Spacer in yellow, and Fixing Spacer in white

Type B: Thick Spacer and Thin Spacer in white, and Fixing Spacer in black



Building	0.01	/ ajaoang oo		11111/	
		1t	1.5t / 2t	2.5t / 3t	5t
	Α	12.5	12.5	12.5	12.5
Collars	в	34	39.4	43.4	61.4
	С	27.6	33	37	55
	Α	3.2	3.2	3.2	-
Spacers	в	35	43	47	-
	С	25.5	32.5	36.5	-

Dimensions of Adjusting Collars (Unit : mm)

18/43/80.5

34

27.6

25



7.5/37.5

-

-

54

Collars/Spacers/Fixing collars

*1) The width of fixing collars (A) may vary depending on different beam width.

Mounting the Stopper

Α

в

С

Fixing collars

(*1)

Suspension shaft

diameter

Be sure to mount the stoppers at both ends of the beam to prevent the trolley/hoist from dropping. Decide the mounting position in accordance with the size of the wheel.

16.5/41.5

39.4

33

32

39.5/64.5

43.4

37

36

If the customer wishes to make the stopper themselves, please refer to the following figures.





(Unit : mm)

Capacity		~	2t	-		2t ~ 5t	
Beam width	100	125	150	175	125	150	175
Material dimensions	L-50x50x6	L-50x50x6	L-65x65x8	L-75x75x9	L-50x50x6	L-65x65x8	L-75x75x9
н	80	80	80	80	100	100	100
E	50	50	65	75	50	65	75
F	40	50	65	75	50	65	75
G	50	50	50	50	60	60	60
С	30	30	35	40	30	35	40
К	65	t2+50	t2+50	t2+50	t2+60	t2+60	t2+60
d	<i>Ф</i> 14	<i>Ф</i> 14	<i>Φ</i> 14	<i>Φ</i> 14	<i>Φ</i> 18	<i>Φ</i> 18	<i>Ф</i> 18
Bolt size	M12x50x50	M12x55x55	M12x55x55	M12x60x60	M16x65x65	M16x65x65	M16x65x65

NOTE) Dimension K is for the case to use combining the hoist with the motorized trolley.

When using the hoist combined with a manual trolley, mount the stopper in accordance with the bumper position.

• When using T-shape Cable Hanger

Install the additional stopper for T-shape Cable Hanger at the end of one rail.



Power Cable Layout for Motorized / Manual trolley type

• In the standard specification, the Cable Hanger is provided. T-shape Cable Hanger and angle type Cable Hanger are also available as optional parts. T-shape Cable Hangers can be applicable to curved beam; however, the application method differs depending on the condition such as radius of curvature. In this case, contact Harrington.



Check after Installation

Wrong assembling or installation causes death or serious injury. To prevent such danger check the following.

Check items

Make sure that the following are completed:

- No bolts, nuts, split pins are missing. Tightening and assembling are completed.
- Strain Relief Cable for Push Button Switch Cord is securely fastened and able to endure pulling forces instead of the Push Button Switch Cord.
- The Power Cable is fixed to the Cable Support.
- · Source voltage is the rated voltage. Rated voltages are as follows.

200V class: 208V (60Hz), 230V(60Hz) 400V class: 380V (50Hz), 460V(60Hz) 500V class: 575V (60Hz)

• Grounding Wire is connected securely.

• When using with a Trolley Check the

following:

- The electric chain hoist and the trolley are connected correctly.
- The stoppers for trolley are securely mounted to Travel Beam where the Trolley travels.
- The surface of Travel Beam shall be free of dirt, debris, paint, and oil. The surface of the Travel Beam must be bare metal. Do not paint. There is no obstacle for the trolley to travel. The Travel Beam is set to a level.

Operational Check

Carry out the operational check in accordance with Daily inspection (P23, 25, 26).

Chapter 2

Inspection

This chapter describes frequent inspection items and periodic inspection items.

Refer to Chapter 1 for the "Handling the Product". Inspection is the first step of safety. Carry out daily inspection, frequent inspection and periodic check.

Outline of Contents50

Outline of Contents

- Table of Contents
- Safety Precautions General Matters related to Inspection
- Frequent Inspection......54
 General Matters on Frequent Inspection
 Electric Chain Hoist (RNER2) Frequent Inspection
 - Appearance
 - Bolts, nuts and splits pins
 - Load Chain
 - Elongation of Pitch Abrasion of wire diameter Opening and Abrasion of the Hook
 - Deformation, Flaw, Corrosion
 - Top Hook, Bottom Hook
 - Peripheral parts of the Body
 Chain container
 - Pressure Resistant Containers with Hazardous Location Construction (Controllers, Barrier Relay Boxes, Motors)
 - Gaps in joint areas on surface Installation bolts

 - Cable retraction opening and closing parts
 - Oil
 - Oil Leakage Oil Plug
 - Push Button Pendant
 - Push Button Pendant Body Push Button Pendant Cord
 - Power Supply
 - Power Cable
 - Cable Hanger
 - Messenger Wire
 - Function and Performance
 - Abnormal Noise
- Motorized Trolley (RMR2) Frequent Inspection......60
 - Appearance
 - Bolts, nuts and splits pins
 - Travel beam
 - Oiling (to wheel gearing)
 - Oil
 - Oil Leakage
 - Pressure Resistant Containers with Hazardous Location Construction (Controllers, Barrier Relay Boxes, Motors)
 - (Refer to Electric Chain Hoist (RNER2) Frequent Inspection)
 - Push Button Pendant, Power Supply
 (Refer to Electric Chain Hoist(RNER2) Frequent Inspection)
 Manual Trolley (RMR2) Frequent Inspection60
 - Appearance
 - Combination
 - Travel beam
 - Oiling (to wheel gearing)

- Periodic Inspection......61 General Matters on Periodic Inspection Electric Chain Hoist (RNER2) Periodic Inspection
 - Peripheral parts of the Body
 - Chain Guide A
 - Chain type
 - Chain Spring
 - Stopper
 - Limit Lever
 - Chain Pin (double type only)
 - Connection Yoke D (double type only)
 - Deformation of mounting hole for the Chain Pin Shaft Retainer Clip
 - Pressure Resistant Containers with Hazardous Location Construction (Controllers, Barrier Relay Boxes, Motors)
 - Consistency between nameplate indication and operational environment
 - The operational environment must conform with the nameplate indication as to hazardous location, temperature rating, gas type, dust type, etc.
 - Condition of joint areas on surfaces
 - Cable retraction opening
 - Unused lead wire
 - Grounding
 - Wiring
 - Electrical insulators
 - Fuse
 - Moving parts on the limit shaft
 - Between the fan and the fan cover
 - Certificate of conformity for barrier relay
 - Wiring inside the barrier relay box
 - Oil
 - Oil Leakage
 - Oil amount and color/stain
 - Electromagnetic Brake
 - Appearance
 - Gap
 - Driving Mechanism
 - Hub Joint
 - Bearing
 - Load Gear, Gear B, Pinion
 - Friction Clutch
 - Abrasion and flaw of the Load Sheave
 - Abrasion and flaw of the Idle Sheave
 - Electrical Equipment
 - Electrical Parts
 - Wiring
 - Contamination and attachment of foreign matter

earing)

•	Electric Characteristics Measurement
	Source Voltage
	Insulation Resistance
	Grounding Resistance
•	Function and Performance
	Operational Check
	Brake
Mo •	torized Trolley (RMR2) Periodic Inspection73 Brake
	Appearance
	Abrasion of Brake Pad
•	Body Components
	Wheel
	Side Roller
	Lifting Shaft
	Suspender Connection Yoke
	Gear Frame Packing
	Gears and Motor Shaft
	Bearing
•	Travel Beam
	Beam Surface
	Deformation and Abrasion
	Beam Mounting Bolt
	Stopper
•	Relay Cable Appearance
	Pressure Resistant Containers with Hazardous Location
•	Construction (Controllers, Motors)
	(Refer to Electric Chain Hoist (RNER2) Periodic Inspection)
•	Function and Performance
	Operational Check
	Brake
	Abnormal Noise
Ма	nual Trolley (RTSG) Periodic Inspection77
•	Body Components
	Wheel
	Lifting Shaft
	Suspender
•	Travel Beam
	Beam Surface
	Deformation and Abrasion
	Beam Mounting Bolt
	Stopper
•	Function and Performance
	Operational Check
	Abnormal Noise

Reference Daily inspection is described in Chapter 1 "How to Use the Product". Refer to the following daily inspection items and their relevant pages. Daily Inspection of Electric Chain Hoist (Hook Suspended Type) Appearance Unauthorized modification Indication of nameplates and labels Deformation and damage of body and each part Cable damage Loose or missing bolts, nuts, and split pins Cleanliness Load Chain Elongation of Pitch Abrasion of Wire Diameter Deformation, Flaw, Entanglement Rust, Corrosion Twist Lubrication Mark **Top Hook/Bottom Hook** Opening of the Hook Abrasion Deformation, Flaw, Corrosion, Rust Hook Latch Hook movement (Rotation) Movement of the Idle Sheave Bottom Yoke Peripheral parts of the body Chain Spring Cushion Rubber **Pressure Resistant Containers with** Hazardous Location Constructions (Controllers, **Barrier Relay Boxes, Motors)** Condition around joint surfaces **Push Button Switch** Switch body **Function and Performance Operational Check** Brake Limit Switch Check for no Abnormal Sound Daily Inspection of Motorized Trolley (RMR2) Appearance Unauthorized modification Indication of Nameplates and Labels Deformation, damage, flaw, crack, rust and corrosion of each part Cable damage Loosened or fallen off bolts, nuts and split pins Cleanliness **Pressure Resistant Containers with** Hazardous Location Constructions (Controllers, **Barrier Relay Boxes, Motors)** Condition around joint surfaces **Function and Performance Operational Check** Brake Daily Inspection of Motorized Trolley (RTSG) Appearance Indication of Nameplates and Labels Deformation and damage of each part Loosened or fallen off bolts, nuts and split pins...26 **Function and Performance Operational Check**

Safety Precautions

General Matters related to Inspection

	Do not open the cover in the presence of explosive atmosphere.
()	Failure to comply with this instruction may result in death or serious injury.
Prohibited	
	 To reduce the risk of ignition of hazardous atmospheres, disconnect the equipment from the su opening.
	 Keep assembly tightly closed when in operation.
Mandatory	 Cover joints must be cleaned before replacing cover. To reduce the risk of ignition of hazardous atmospheres, conduit runs must have a sealing fitting connected within 18 inches of the enclosure.
	Failure to comply with these instructions may result in death or serious injury.
\bigcirc	 Disassembly and assembly of the electric chain block must be performed by a qualified person with training and experience including knowledge of Hazardous Location construction, work on electrical facilities, related regulations, and the general principles for the classification of hazardous locations.
Prohibited	Do not use the part exceeding the service limit or criteria and the parts other than genuine part for
	HARRINGTON electric chain hoist.
	 Even if the part is genuine HARRINGTON part, it cannot be used for other model. Refer to Disassembly/Assembly Manual (Annex) for the correct use of the part. Do not brush against the chain container, to prevent static electricity. Do not allow the hook to strike against other objects.
	 Do not adjust or disassemble the Electromagnetic Brake and the Friction Clutch. Do not adjust the set nut. When lubricating the Friction Clutch, use HARRINGTON genuine oil (manufacturer specified oil).
	 Do not carry out the inspection of electric chain hoist with a lifted load.
	 Do not use the electric chain hoist removing the cushion rubber, the chain spring and the stopper.
	 Turn off the main power when carrying out the inspection.
	 When using oils such as gear oil and grease, avoid places with fire or sparks.
	Failure to comply with these instructions may result in death or serious injury.
0	 Confirm that there is no explosive gas present before opening the lid. Do not open the covers while the power supply is turned on. Put the electric chain hoist on the floor or work bench when performing the repair and
Mandatory	disassembling of the electric chain hoist.
	Even if each component of the electric chain hoist does not exceed the service limit, replace
	the part exceeding the total operating hours derived from the grade indicated on the electric chain hoist and the load factor.
	 Do not use the electric chain hoist when any abnormality is observed during the inspection.
	Indicate "FAILURE" on the hoist and contact qualified personnel and or Harrington for repair.
	After completion of the inspection (frequent, periodic), perform the functional check and make
	sure that the electric chain hoist operates correctly.
	• When performing the functional check, be sure to perform the capacity test after no load test.
	Failure to comply with these instructions may result in death or serious injury.

t (1990) t	 Before performing any maintenance on the hoist/trolley, de-energize the supply of electricity to the equipment, and lock and tag the supply device in the de-energized position when performing
	the inspection.
	When a crane is operated erroneously during the inspection, it may result in the accident such as fall- off of parts and tools and downfall.
•	 Wear appropriate personal protection equipment (PPE) such as safety goggles and gloves depending on the work contents. Otherwise, it may result in injury due to spraying oil or sharp edges of a part. Pay attention to work method, work procedure and work area. If the product or part is heavy, it may cause hand injury or back strain. Use extra caution when working on unstable scaffolding or elevated heights. Wear a helmet and safety harness when carrying out high lift work. Otherwise, it may result in injury or accident. Keep the hoist/trolley surface and work surface free of oil. Otherwise, it may result in injury due to dropping of the product or overturning. Keep the work area clean when disassembling the product. Assembling or combining parts other than genuine Harrington parts may result in damage to the product or possible accident due to defective operation.

NOTE

• When performing the frequent inspection, carry out the daily inspection at the same time.

• When performing the periodic inspection, carry out the frequent inspection at the same time.

• When any abnormality is detected during inspection due to erroneous use, instruct the operator on the correct use of the electric chain hoist.

Ex. (1) Damage to chain guide A from excessive chain contact (Cause: excessive side pull during lifting)

(2) The deformation of the Cushion Rubber and the Chain Spring (Cause: excessive use of the limit switch)

Frequent Inspection

General Matters on Frequent Inspection

• Check the electric chain hoist as installed, either standing on the floor or positioned close to the hoist, as needed.



Mandatory

NOTE

When performing the frequent inspection, carry out the daily inspection at the same time.

- Refer to Appendix "Technical Material" (P104) for the structure of the product and the name of each part.
- Refer to the technical material in the Appendix for how to apply grease on joint surfaces of Pressure resistant containers.



Apply grease on joint surfaces after opening covers or disassembling motors according to the procedure described in Technical Material of Appendix.

Failure to comply with this instruction may result in death or serious injury.

Mandatory

Electric Chain Hoist (RNER2) Frequent Inspection

Appearance

ltem	Check method	Criteria	Action
Bolts, nuts, and split pins	Check visually	 No rust, corrosion on bolts, nuts, and split pins. 	Replace any rusty or corroded hardware.

Load Chain

- Check the Load Chain after removing the oil on the chain.
- Use the needle head caliper (point caliper) to measure the sum of pitches and wire diameter.
- Apply oil on the Load Chain after inspection.
- Application of lubricant influences the life of the Load Chain considerably. Use HARRINGTON genuine lubricant or equivalent (industrial lithium grease: consistency No.0)
 - Release all loads from the Load Chain. Apply the lubricant to the linking portion of the Load Chain that engages the Load sheave and the Idle Sheave and the linking portion of the Load Chain.
 - After application of the lubricant lift/lower the electric chain hoist without load to spread the lubricant on the Load Chain.

ltem	Check method	Criteria	Action
Elongation of Pitch	 Measure the elongation of pitch with point caliper. 	NOTE	Replace the Load Chain.
	(Measure the sum of pitches of 5 links)	 Pay special attention when checking the engaging point of the Load Sheave and the Idle Sheave. The limit value of the following "Sum of pitches of five links" must not be exceeded. 	
Abrasion of wire diameter	• Measure the wire diameter (d) with point caliper.	The limit value of the following "Wire diameter of the Load Chain" must not be exceeded. NOTE	Replace the Load Chain.
	d	When the abrasion of the Load Chain is observed, be sure to check the abrasion of the Load Sheave and the Idle Sheave also. (Refer to "Periodic Inspection", "Load Sheave" (P69)	

Load Chain Pitch and Wire Diameter for Each Capacity

Code		Load Capacity Chain		Sum of 5 Links (inch (mm))		Load Chain diameter (inch (mm))		
DNEDOD	DNEDAD	(Ton)	diameter	Do not exceed	I the limit	Do not exc	eed the limit	
RNER2B	RNER2D		(mm)	Standard	Limit	Standard	Limit	
RNER2B-010LD	RNER2D-010LD	4	ф7 7.4	4.05 (400.0)	4.20 (444.0)	0.00 (7.7)	0.07 (0.0)	
RNER2B-010SD	RNER2D-010SD	I	Φ7.7×1	4.25 (108.0)	4.38 (111.2)	0.30 (7.7)	0.27 (6.9)	
RNER2B-015SD	RNER2D-015SD	1 1/2	Φ10.2×1	5.63 (143.0)	5.80 (147.2)	0.40 (10.2)	0.36 (9.2)	
RNER2B-020CD	RNER2D-020CD		Φ7.7×1	4.25 (108.0)	4.38 (111.2)	0.30 (7.7)	0.27 (6.9)	
RNER2B-020LD	RNER2D-020LD	2	* 40.0.1		5 00 (4 47 0)	0.40.(40.0)		
RNER2B-020SD	RNER2D-020SD		Ф10.2×1	5.63 (143.0)	5.80 (147.2)	0.40 (10.2)	0.36 (9.2)	
RNER2B-025SD	RNER2D-025SD	2 1/2	Φ11.2×1	6.18 (157.0)	6.37 (161.7)	0.44 (11.2)	0.40 (10.1)	
RNER2B-030CD	RNER2D-030CD	3	Ф10.2×1	5.63 (143.0)	5.80 (147.2)	0.40 (10.2)	0.36 (9.2)	
RNER2B-050LD	RNER2D-050LD	5	Φ11.2×1	6.18 (157.0)	6.37 (161.7)	0.44 (11.2)	0.40 (10.1)	

Top Hook, Bottom Hook

ltem	Check method			Criteria			Act	ion
Deformation and Wear of the Hook	• Check visually and measure with vernier caliper.	Man	• Cor b, a Che datory The o dimensi	CAUTION mpare the dime nd c with those eck that they ar criteria use of the Hoo ons exceeding sult in bodily inju	e when new. e within the · ks with thes the criteri	e	Replace th	ne Hook
		Measur (mm) Dime	ension a	Limit v lot to exceed the burchasing				
		• Follo value tolera RNER2	ension c wing table es. Please ance becau	Vear not to excer s shows the no be aware that use of forging. rvice Limit or C	ominal stand these value	es include		
	Code		Capacity	Dimension a		sion b	Dimen	
	RNER2B RN	ER2D	(Ton)	(inch (mm)) Standard	(inch Standard	(mm)) Limit value	(inch) Standard	(mm)) Limit value
		2D-010LD	1	1.97 (50.0)	0.89 (22.5)			1.16 (29.5)
	RNER2B-015SD RNER	2D-015SD	1 1/2	2.36 (60.0)	1.04 (26.5)	0.99 (25.2)	1.44 (36.5)	1.37 (34.7)
	RNER2B-020LD RNER RNER2B-020SD RNER	2D-020CD 2D-020LD 2D-020SD	2	2.72 (69.0)	1.24 (31.5)	1.18 (29.9)	1.71 (43.5)	1.63 (41.3)
		2D-025SD 2D-030CD		2.87 (73.0)	1.26 (24.5)	1 20 (22 8)	1 97 (47 5)	1 79 (45 1)
		2D-030CD 2D-050LD		3.27 (83.0)	1.36 (34.5) 1.67 (42.5)		1.87 (47.5) 2.20 (56.0)	1.78 (45.1) 2.09 (53.2)
Deformation, Flaw, Corrosion	Check visually.	 No di No di No si No si No ai 	eep gouge amaged or ubstantial o ttachment	such as bend s or large nick loose bolts, n corrosion of foreign matter damaging co	s uts, and spl ter such as		Replace th	ne Hook.

Peripheral parts of the Body

• Use check stand to check the electric chain hoist from the close point.

ltem	Check method	Criteria	Action	
Chain Container	• Check visually.	 To be mounted to the body securely No damage, tears, abrasions, or deformation Ensure no foreign matter is inside the Chain Make sure that the lift of the Load Chain is capacity of the Chain Container. Marchain Container. Do not use damaged Chain Container Warning Mandatory capacity larger than the lift of the Load Chain. Use of a damaged or undersized chain container may result in death or serious injury due to drop of the Load Chain. 	n Container.	Replace the Chain Container. Discard the foreign matter in the Chain Container.

Pressure Resistant Containers with Hazardous Location Construction (Controllers, Barrier Relay Boxes, Motors)

A WARNING Be cautious of the following, as it may cause a serious accident: damage to the joint surface of pressure-resistant containers can allow the inner flame to pass through, potentially igniting outer gas and/or dust.

ltem	Check method	Criteria	Action
Gaps in joint areas on surfaces	• Check visually.	• No expanding gaps.	Replace the lid.
Installation bolts	Check visually.	Correct factory installed hardware.No rust, corrosion	Replace the bolts.
Cable retraction opening and	Check visually.	 No damage to the cable retraction opening. Appropriate type 	Replace the part.
closing parts	Check with tools.	No looseness in the cable holder installation area.	Tighten the cable holder.

Oil

Item	Check method	Criteria	Action
Oil Leakage	Check visually.	 To have no leakage of gear oil from packings, oil seals or oil plugs. 	Replace Packing, Oil Seal, or Oil Plug.
Oil Plug	Check visually.	• To have no deterioration of damages.	Replace Oil Plug.

Push Button Switch

ltem	Method	Criteria	Action
Push Button Switch Body	• Check visually and by operating	 No damage, deformation or loose bolts. Push Button Pendant operates smoothly. Emergency Stop Button operates properly. 	Replace the Push Button Switch.
Push Button Pendant Cord	Check Visually	 Push Button Pendant Cord is securely connected The Strain relief cable is tied with the body so that the Push Button Pendant Cord is not strained directly even if the Push Button Pendant is pulled. 	Connect the Push Button Pendant Cord and the Strain Relief to the body properly.
		<image/>	Replace the Push Button Pendant Cord.

Power Supply

Item	Method	Criteria	Action
Power Cable	Check Visually	 Power Cable to have enough length To have no damage To be connected securely 	Replace the Power Cable.
Cable Hanger	Check visually and by moving by hand. Messenger Wire Cable Hanger Power Cable	 To have no damage To move smoothly To be mounted at equal intervals Appropriate interval 5 ft. (1.5 m) 	Re-mount the Cable Hangers so there is no hinderance to move
Messenger Wire	Check Visually	 To have no sag No interference or abrasion to adjacent components. 	Remove the sag.

Function and Performance

ltem	Check method	Criteria	Action
Abnormal Noise	Noise gear, motor and the Load Chain during operation without load.	 Mechanisms should be properly adjusted and should not produce unusual sounds when operated. Hoist components including the Motor and Brake should not emit noise during operation. 	Replace the abnormal part.
	Sound is also an important check point. Always listen for suspicious noises not normal to the operation of the electric chain hoist.	 Load Chain should not emit cracking noise when hoisting a load. 	Check the Load Chain. (Refer to P55.)

Motorized Trolley (RMR2) Frequent Inspection

Appearance

ltem	Check method	Criteria	Action
Bolts, nuts and split pins	• Check visually.	• No rust, corrosion on bolts, nuts and splits pins	Replace rusted and corroded hardware.
Travel Beam	• Check visually.	To have no considerable deformation and damage	Check items in accordance with "Travel Beam" described in Chapter 2 "Periodic Inspection".
Lubrication (to the gears of wheel)	• Check visually.	To be lubricated adequately	Apply lubrication to gears.

Oil

Item	Check method	Criteria	Action
Oil Leakage	• Check visually.	 To have no leakage of gear oil from packings, oil seals or oil plugs. 	Replace Packing and Oil Seal.

Pressure Resistant Containers with Hazardous Location Construction (Controllers, Motors) Carry out the inspection referring to "Frequent Inspection Items" of the electric chain hoist (RNER2).

Push Button Switch, Power Supply

Carry out the inspection referring to "Frequent Inspection Items" of the electric chain hoist (RNER2).

Manual Trolley (RTSG) Frequent Inspection

Appearance

Item	Check method	Criteria	Action
Combination	 Shake the manual trolley to check 	 The manual trolley shakes lightly to right and left. 	Combine the electric chain hoist and the manual trolley securely.
Travel Beam	• Check visually.	 To have no considerable deformation and damage. 	Check items in accordance with "Travel Beam" described in Chapter 2 "Periodic Inspection". (P77)
Oiling (to the gears of wheel)	• Check visually.	• To be oiled adequately.	Apply oil to gears.

Periodic Inspection General Topics for Periodic Inspection

• Put the electric chain hoist on the floor or work bench when inspecting the electric chain hoist.

Mandatory

- After completion of the periodic inspection, perform the functional check and make sure that the electric chain hoist operates correctly.
 - \cdot Wear insulating gloves when measuring voltage.
 - When measuring the electric characteristics (insulation resistance, but except voltage measurement), turn off the power.

Failure to comply above instructions may result in death or serious injury.

NOTE

When performing the periodic inspection, carry out the daily inspection at the same time.

- Disassemble the electric chain hoist and check that it is assembled correctly without abnormal parts.
- Refer to Appendix "Technical Material" for the structure of the product and the name of each part.
- Refer to the technical material in the Appendix also for how to apply grease on joint surfaces of Pressure resistant containers (controllers, barrier relay boxes, and motors).

Apply grease on joint surfaces after opening covers or disassembling motors according to the procedure described in Technical Material of Appendix.

Failure to comply with this instruction may result in death or serious injury.



Be sure to adhere to all torque guidelines for Pressure resistant containers (controllers, barrier relay boxes, and motors).

Confirm gap is correct with feeler gauge for Pressure resistant containers including (controllers, barrier relay boxes, and motors).

Failure to comply with this instruction may result in death or serious injury.

Electric Chain Hoist (RNER2) Periodic Inspection

Peripheral parts of the Body

2

ltem	Check method		Criteria		Action		
Chain Guide A	• Check visually.	and damage	 To have no flaw due to hitting by the Load 				
			CAUTION				
	Chain Guide A	Andatory the about the second	• The flaw due to hitting is caused by wrong use such as lifting a load in an inclined direction. If Mandatory the abrasion is observed on the Chain Guide, the Load Chain may be worn also. Refer to the item of Load Chain Abrasion and check the abrasion.				
		Chain at	ng the check of to prasion may result property damage.				
Cable Classification	• Check visually.	The cable classified	cation must be co	orrect.	Replace the cable.		
Chain Spring	Check visually and measure the dimensions.	(deformation).	CAUTION • The deformation of the Cushion Rubber and the Chain Spring is caused by excessive use				
	Dimensional standard	Limit electr prope Otherwis injury or • Service Limit of					
	C	ode		Length of	Chain Spring		
	RNER2B	RNER2D	Capacity (Ton)	Standard (in (mm))	ch Limit value (inch (mm))		
	RNER2B-020CD	RNER2D-020CD		3.94 (100)	3.73 (95)		
	RNER2B-020LD	RNER2D-020LD	2	2.76 (70)	2.64 (67)		
	RNER2B-020SD	RNER2D-020SD	1	3.35 (85)	3.19 (81)		
	RNER2B-025SD	RNER2D-025SD	2 1/2	2.95 (75)	2.83 (72)		
	RNER2B-030CD	RNER2D-030CD	3	3.35 (85)	3.19 (81)		
	RNER2B-050LD	RNER2D-050LD	5	2.95 (75)	2.83 (72)		

ltem	Check method	Criteria	Action		
Stopper	• Check visually. Cushion Rubber Stopper	 The stopper must be attached securely at the third link from the no load end of the Load Chain. 	Attach the Stopper at the third link.		
Limit Lever	 Check visually and by moving by hand. 	 To have no deformation, damage and abrasion To move freely without any dirt or debris present Actuation of limit lever should stop hois 	Replace the Limit Lever. Disassemble the Limit Lever and clean.		
Chain Pin (double fall hoist only)	 Check visually and measure with vernier caliper. Chain Pin 	To have no apparent deformation and flaw. Service Limit of Chain Pin (Do not fall short of the limit value.) Code RNER2B RNER2D Sta RNER2B-030CD RNER2D-030CD 0.4	Replace the Chain Pin. Diameter d (inch (mm)) andard Limit value 3 (10.8) 0.41 (10.3) 1 (12.9) 0.48 (12.3)		
Connection Yoke D (double fall hoist only) Deformation of mounting hole for the Chain Pin	• Measure the dimensions a and b with vernier caliper.	 The difference between dimensions a (vertical) and b (lateral) must be within 0.5 mm. To have no apparent deformation and abrasion 	Replace the Connection Yoke D.		
Shaft Retainer Clip	• Check visually.	To have no deformation, abrasion and damage To be attached securely without loosening Replace the Retainer Cl			

Pressure Resistant Containers with Hazardous Location Construction (Controllers, Barrier Relay Boxes, Motors)

A WARNING Be careful of the following as it may cause serious accident igniting outer gas and/or dust with passage of inner flame due to damage of joint surface of pressure resistant containers.

Mandatory

Prohibited

- Do not disassemble or assemble this equipment in an environment with a volatile atmosphere.
- Do not damage the joint surfaces.
- Do not tighten bolts or screws more than necessary.

Failure to comply with these instructions may result in death or serious injury.



• When re-assembling the cable retraction area, use packing, washers, and cable clamps that are appropriate for for the cable.

Failure to comply with these instructions may result in death or serious injury.

ltem	Check method	Criteria	Action
Consistency between nameplate indication and operational environment	 Check the operational environment against the nameplate indication. (Refer to "Operational Environment") 	The operational environment must conform with the nameplate indication as to hazardous location, temperature rating, gas type, dust type, etc.	Use the product in the correct environment.
Condition of joint area surfaces	• Remove the lid and check visually.	 No rust. Clean. No damage. Joint area surfaces in good condition. 	 Remove rust. Remove by cleaning. Replace the Pressure Resistant Container Re-apply liquid packing.
Cable Retraction opening	 Disassemble and check. 	 No deterioration in packing. The cable gland sealing compound must be securely filled. 	Replace cable gland parts.
Unused lead wire	Check visually.	• Insulated.	Insulate the lead wire.
Gasket (Motor)	Check visually.	No damage.Gasket in good condition.	Replace the gasket.
Grounding	Check with tools.	 The connection must be robust. The conductor cross-sectional area is sufficient. 	
Wiring	 Check visually. 	Must be surely connected.	
Electrical insulators	Check visually.	• Clean and dry.	

ltem	Check method	Criteria	Action
Fuse	 Check the fuse rating on the secondary side of the transformer in the control box. 	• Must be 1A and 250V.	Replace with a proper fuse.
Moving parts on the limit shaft	• Disassemble and checks.	 Diameter of limit lever pin not less than 15.95mm. Inner diameter of sleeve not greater than 16.07mm. 	Replace the limit lever pin and sleeve. (Replace both even if only one fails the check.)
Between the fan and the fan cover	 Perform hoisting and lowering operations. 	• No rubbing noise between the fan and fan cover.	Replace the fan cover.
Certificate of conformity for barrier relay	• Check visually.	• The barrier relay has a certificate of acceptance.	Replace with an accepted product.
Wiring inside the barrier relay box	 Check if the wiring is correct. 	 Wiring must be the same as shown in the wiring diagrams. 	Connect the wiring correctly.

Oil

ltem	Check method	Criteria	Action
Oil Leakage	• Check visually.	 To have no leakage of gear oil from packings, oil seals or oil plugs. 	Replace the Packing and the Oil Seal.
Oil amount and stain	Check the oil level from the oil	•Oil is filled enough close to the oil check hole.	Replace the Oil.
Oil Plug Inspection Hole	check hole.	 Check the oil level through the oil cap an arrow) for electric chain hoist equip clutch with mechanical brake. (Do not hole at the side. Or, oil leaks out.) Wh level, insert the check bar into the oil bar slightly, to see the oil level. The distance between the hole and th for body size D, 120mm for body size body size F. Gear oil has viscosity and is not contaminated. Refer to "Guidelines and Precautions on Gear Oil Change Cycle" for the replacement of oil. 	oped with the friction open the oil check en checking the oil check hole, tilting the ne oil level is 100mm
		(P97)	

ltem	Check me	ethod	Criter	ia		Action
		•-	Type of gear oil and its an	nount for one l	body size	
		Specification	Code	Gear Oil Amount (ml)	Oil Manufacturer	Oil Type
			RNER2-010LD, 020CD	620		
			RNER2-010SD	680		
		Friction Clutch	RNER2-015SD, 020LD	1300	HARRINGTON genuine oil	HARRINGTON genuine oil
			RNER2-020SD, 030CD	1900	9	9
			RNER2-025SD, 050LD	1900		
			When electricould incre possi	checking the lease of the term of term	ist body is level b evel of gear oil. oil plug without lev the gear oil flows o ential slippery floor f fall resulting in se	eling the ut. The oil leak condition rious injury or Harrington oil

Electromagnetic Brake

ltem	Check method				Action		
Appearance	Appearance • Remove the Brake Cover and check visually.		To have no loose	ened bolt and screw.		Tighten bolts and screws	
			To have no flaw	and damage.			
Oil amount and stain			• Electromagnetic E limit)	Brake Gap Limit (not t	o exceed the	Replace the electromag Brake.	
			Co	de	Dual spee	d model	
		Hub joint	RNER2B	RNER2D	Gap limit (ir	nch (mm))	
		(enlarged: top view)	RNER2B-010LD	RNER2D-010LD			
		Square hub type	RNER2B-010SD	RNER2D-010SD			
Brake		115	RNER2B-015SD	RNER2D-015SD			
Stator		RNER2B-020CD RNER2D-020CD					
			RNER2B-020LD	RNER2D-020LD	0.035(0	0.90)	
ð	(And A has	Spline hub type	RNER2B-020SD	RNER2D-020SD	4		
7		~	RNER2B-025SD	RNER2D-025SD			
	[h494-1]]	[(ξ(]	RNER2B-030CD	RNER2D-030CD			
			RNER2B-050LD	RNER2D-050LD			
(enlarge	Brake gap (enlarged) Side view Gap		Prohibited	• Do not adjus disassemble Electromagn Adjusting or disas Electromagnetic result in death or	the etic Brake ssembling the Brake may		

Driving Mechanism

ltem	Check method	Criteria	Action
Hub Joint	• Check visually.	 To have no apparent deformation and abrasion Hub spring must be seated. 	Replace the Hub and the Electromagnetic Brake.
Bearing	 Check visually and rotate the Bearing by hand. 	 To have no harmful deficiency such as apparent abrasion, flaw and damage. To rotate smoothly. 	Replace the Bearing.
Load Gear, Gear B, Pinion	Disassemble the electric chain hoist and check the splined portions of pinion and gear.	 To have no apparent abrasion To have no damage 	 Replace the Gear. Replace the Pinion. Replace the oil at the same time.
	Spline Motor shaft Rotor		
Friction Clutch / Pawl	Check visually	 Friction Clutch must not have any apparent abrasion, deformation, flaw or damage. Pawl must have no apparent deformation or abrasion. MARNING 	Replace the Friction Clutch. Replace the Pawl.
		• Do not adjust or disassemble the Friction Clutch. Adjusting and disassembling the Friction Clutch may result in death or serious injury. Prohibited	

ltem	Check method		Cri	iteria			Action
Abrasion and	 Disassemble the Load 	• To have r	no apparent al	brasion, d	eformatio	on and	Replace the
flaw of the	Sheave and check it	damage					Load Sheave.
Load Sheave	visually.	J J	neither abrasio	on of the s	sheave po	ocket nor	
a a	 Measure the thickness 		n flaw on the o				
	with vernier caliper.		NOTE				
	Worn portion Worn portion Thickness Thickness at	If the abrasion is observed on the Load Sheave, the Load Chain may be worn also. Refer to the item of Load Chain Abrasion and check the abrasion. • Service limit of the Load Sheave and Idle Sheave (Do not fall under the limit)					
	purchasing	Code Capacity (mm))					
Abrasion and	Disassemble the Load	RNER2B	RNER2D	(Ton)	Standard	Limit	Replace the Idle
flaw of the	Sheave and check it	RNER2B-010LD		1	0.18 (4.5)	0.12 (3.0)	Sheave.
Idle Sheave	visually.	RNER2B-010SD	RNER2D-010SD RNER2D-015SD	1 1/2	(-)	- ()	
	 Measure the thickness 		RNER2D-015SD	1 1/2	-		
	with vernier caliper.	RNER2B-020LD	RNER2D-020LD	2	0.26 (6.5)	0.17 (4.3)	
			RNER2D-020SD	_			
		RNER2B-030CD	RNER2D-030CD	3	-		
	Worn portion	RNER2B-025SD		2 1/2	0.29 (7.3)	0.19 (4.9)	
Crest		RNER2B-050LD	RNER2D-050LD	5	0.20 (1.0)	0.10 (1.0)	
	Thickness Thickness at purchasing						

Electrical Equipment

ltem	Check method	Criteria	Action
Electrical Parts	 Remove the Controller Cover and check the electrical parts visually. 	 To have no damaged or burnt part. To have no loosened bolt. Electrical parts must be mounted securely. 	Replace the damaged or burnt electrical part. Mount the electrical part securely.
		WARNING ONLY USE CONTACTORS SPECIFIED BY THE MANUFACTURER	
		 Even if the above standards are met, replace the oil at least every 5 years. 	
Wiring	-	• Wiring must be fixed to the Electrical	Connect wirings
		Parts securely.	securely.
		 Connectors must be inserted securely. 	Danie a the minimum
		• To have no wire breakage and burning	Replace the wiring with new wiring, referring to Chapter 3 Guidance on Troubleshooting.
Contamination and attachment of foreign matter		No foreign matter or water droplets/moisture present.	Remove the foreign matter.

Electric Characteristics Measurement



• When performing measurements where gas and/or dust exists, utilize a measuring instrument that is intrinsically safe.

Failure to follow these instructions may result in ignition of a hazardous gas or/and dust atmosphere.

Mandatory

	ltem	Check method	Criteria	Action
	Source Voltage	 Measure the voltage with a circuit tester. 		Supply proper voltage.
			AWARNING	
,			• Be careful of electric shock when measuring the voltage. Electric shock may result in death	
			Mandatory or serious injury.	
	Insulation Resistance		• Insulation resistance must be 5 M Ω or higher.	Replace the Body.
	Megohmmeter. (Resistance between energized and non- energized parts Each phase of R(L1), S(L2) and T(L3) and the ground wire)	Megohmmeter.	∆WARNING	
		 Turn off the power when measuring the insulation resistance. 		
			Measuring the insulation resistance without turning off the power may result in death or serious injury.	
	Grounding Resistance Resistance with a ground resistance with a ground resistance meter.		 Source voltage of 10 ohms or less. 	Perform the grounding correctly.
		• Turn off the power when measuring the grounding resistance. Measuring the grounding resistance without turning off the power may result in death		
			or serious injury due to electric shock.	

Function and Performance



• After completion of the inspection of each part, perform the operational check for correct operation.

Neglecting to perform the operational check may result in death or serious injury.

Mandatory

• Perform the following inspections with capacity.

Item	Check method	Criteria	Action
Operational Check	Perform the daily inspection items with capacity. (Refer to Daily inspection Items).	WARNING Be sure to perform the capacity test after completion of the no-load test. Performing the capacity test without prior no-load test may result in death or serious injury. Refer to "Daily inspection Items".	Disassemble the electric chain hoist to check whether it is assembled correctly and confirm it has no abnormal parts.
Brake	 Operate the electric chain hoist while lifting a load and then bring it to a stop. 	 When stopping the operation, the Brake must be applied immediately, and the motor must stop. Up/Down: Stop distance must be 1 % or less of the traveling distance for one minute. 	Disassemble the Brake to check whether it is assembled correctly and confirm it has no abnormal part.
Motorized Trolley (RMR2) Periodic Inspection

Brake

Item	Check method		Criteria			Action
Appearance	 Disassemble the Brake and check it visually. 	 To have no deformation, flaw and damage on the Brake Drum and the Motor Cover. 			Replace the part	
		 To have no deformation and damage on the Brake Spring. 				Replace the part
Abrasion of Brake Pad	• Disassemble the Brake and measure the abrasion.	 Trolley Brake Service Limit (Do not fall under the limit.) 				Replace the Side Roller.
			Outer diamet	er (inch (mm))		
		Capacity (t)	Standard	Limit		
		1				
		1.5, 2	1.45 (36.8)	1.43 (36.3)		
		2.5, 3	1.45 (30.8)	1.43 (30.3)		
		5				

Body Components

Item	Check method			Crit	eria		A	ction
Wheel	 Check visually. Measure dimensions D and d with vernier caliper. Wheel for I · H beam (0.5 to 5 t) 	 To have no considerable deformation and damage Abrasion Limit of Wheel (Do not fall under the limit.) 					Replace Wheel	e the
	Φ_{d}	Capacity			D (inc	h (mm))	d (inch ((mm))
		(Ton)	Beam ty	ype	Standard	Limit	Standard	Limit
	 Measure the outer diameter 	1	I · H	I	3.74 (95)	3.58 (91)		3.44 (87.5)
	with vernier caliper	1 1/2, 2	I · H	1	4.33 (110)			1
		2 1/2, 3	I · H		4.92 (125)	4.65 (118)		
		5	I · H	ł	5.51 (140)	5.20 (132)	5.31 (135)	5.00 (127)
Side Roller	 Check visually. Measure outer diameter of the worn part with vernier caliper. <u>Outer diameter</u> 	and da • Abrasio	mage on Limit ot fall un	of S der t	erable defe ide Roller he limit.) r diameter (Replace Roller.	e the Side
		Capacity	/ (Ton)		ndard	Limit		
	(\bigcirc)	1				1.46 (37)		
		1 1/2	2			1.65 (42)		
		2 1/2				1.65 (42)		
		5	., 0					
Lifting Shaft	 Check visually. Measure the shaft diameter with vernier caliper. Shaft diameter • • • • • • • • • • • • • • • • • • •	52.17 (55)2.13 (54)• To have no considerable deformation and abrasion• The shaft with obvious deformation reaches at the service limit.• Abrasion limit of the shaft is 5 % of its diameter respectively.			Replace Shaft.	e the Lifting		
Suspender Connection Yoke	 Check visually. Measure the diameter of the hole with vernier caliper. 	secure bolt.	ly with th on limit o	he to	ust be com op pin and e hole is 5	the Yoke		e the worn art.

ltem	Check method	Criteria	Action
Gear Frame Packing	• Check visually. Gear Frame Packing	• To have no damage and breakage.	Replace the Gear Frame Packing.
Gears and Motor Shaft	• Check visually.	 To have no apparent abrasion, deformation and damage. 	Replace the Part.
Bearing	 Check visually and rotate the Bearing by hand. 	 To have no harmful deficiency such as apparent abrasion, flaw and damage. To rotate smoothly. 	Replace the Bearing. To replace, contact Harrington.

Travel Beam

Item	Check method	Criteria	Action
Beam Surface	• Check visually.	 To have no paint, oil, or foreign matter. To have no dust and powder due to abrasion 	Clean the Travel Beam.
Deformation and Abrasion	• Check the deformation and abrasion visually and measure them with vernier caliper. I-beam H-beam H -beam	 To have no deformation of beam flange such as twist and shear drop To have no exceeding abrasion of beam surface Service limit of B: up to 95 % of the dimension at purchasing Service limit of c: up to 90 % of the dimension at purchasing 	Replace or repair the Travel Beam.
Beam Mounting Bolt	Check visually.	 To have no loosened bolt or fall-off. 	

Item	Check method	Criteria	Action
	Check visually. Stopper	 The stoppers must be mounted at the both ends of the Travel Beam securely. 	

Relay Cable

ltem	Check method	Criteria	Action
Appearance	 Check the cable surface visually. 	 The Relay Cable has no deformation or damage. To be mounted securely. 	Replace the Relay Cable.

Pressure Resistant Containers with Hazardous Location Construction (Controllers, Motors)

Refer to Electric Chain Hoist (RNER2) Periodic Inspection

Electrical Equipment and Electric Characteristics

Refer to Electric Chain Hoist (RNER2) Periodic Inspection.

Function and Performance



• After completion of the inspection of each part, perform the operational check for correct operation.

Neglecting to perform the operational check may result in death or serious injury.

Mandatory

• Perform the following inspections with capacity.

ltem	Check method	Criteria	Action
Operational Check	 Perform the daily inspection items with capacity. (Refer to "Daily inspection Items". (P24)) 	WARNING Be sure to perform the capacity test after completion of the no-load test. Mandatory Performing the capacity test without prior no-load test may result in death or serious injury. Refer to "Daily inspection Items".	Disassemble the electric chain hoist to check whether it is assembled correctly and has no abnormal part.

Manual Trolley (RTSG) Periodic Inspection

Body Components

ltem	Check metho	d	Criteria					Action		
Brake	 Operate the electrichain hoist with a capacity and then it. 		Brake must be applied immediately ch and the motor must stop.				check w is assen	isassemble the Brake to neck whether the brake assembled correctly. onfirm all parts are prrect.		
Abnormal Noise	 Operate the electrichain hoist while line a load and then britted to a stop. 	ic • To have no abnormal noise Disasser fting • Motor and Brake shall not emit any abnormal noise during operation. whether correctly				mble the ele bist to check tit is assemb (. Confirm al e correct.	bled			
ltem	Method			Discare	d Limit/C	riteria			Actio	n
Wheel	 Check visually. Measure dimensions D and t with vernier caliper. 	the • • To h	 To have no apparent deformation and damage the abrasion of the wheel should not be less than the limit value To have no deformation of contact surface To have no streaks on flange 					Replace the	Wheel.	
		Capacity (Ton) D (mm) d(mm)					mm)	Flange thic	kness (mm)	
		TSP	TSG	Beam H-steel	Standard 2.80 (71)	Limit 2.74	Standard	Limit	Standard 0.137 (4.0)	Limit 0.130 (3.3)
	1~3t 5t		2 ½, 1	I-steel H-steel	3.35 (85)	(69.5) 3.29	-		0.137 (4.0)	0.150 (3.8)
	Measure the outer		2 ½, 3	I-steel H-steel I-steel	3.94 (100)	(83.5) 3.88 (98.5)			0.197 (5.0)	0.169 (4.3)
	diameter with vernier caliper.		5	H-steel I-steel	4.65 (118)	4.41 (112)	113	107	0.378 (9.6)	0.264 (6.7)
Suspension Shaft	 Check visually. Measure the shaft diameter 		shaft with	oparent defe obvious de				vice	Replace the Suspension	
	with vernier caliper. Shaft diameter	 Abrasion limit of the shaft and the hole is 5% of its diameter respectively. 								
Suspender	 Check visually. Measure the diameter of the with vernier caliper. Hole diameter 	and	 The Suspender must be combined securely with the top pin and the Yoke bolt. Abrasion limit of the hole is 5% of its diameter. 				p pin	Replace the	Suspende	

Periodic Inspection (continued)

I ravel Bea								
Item	Check method	Criteria	Action					
Beam Surface	Check visually.	 Beam surface shall be free of paint, oil and foreign matter. To have no dust and powder due to abrasion 	Clean the Travel Beam.					
Deformation and Abrasion	 Check the deformation and abrasion visually and measure them with vernier caliper. I-beam H-beam H-beam H-beam H-beam 	 To have no deformation of beam flange such as twisting or shearing. To have no excessive abrasion of beam surface Service limit of B: up to 95 % of the dimension at purchasing Service limit of c: up to 90 % of the dimension at purchasing 	Replace or repair the Travel Beam.					
Beam Mounting Bolt	Check visually.	 Confirm Bolt is present, installed correctly and properly torqued. 	Tighten the bolts securely.					
Stopper	• Check visually.	 The stoppers must be mounted at both ends of the Travel Beam securely. 	Tighten the Stoppers.					
Eunction a	Function and Performance							

Function and Performance

• After completion of the inspection of each part, perform the operational check for correct operation.

Neglecting to perform the operational check may result in death or serious injury.

Mandatory

• Perform the following inspections with capacity.

ltem	Check method	Criteria	Action
Operational Check	 Perform the daily inspection items with capacity. (Refer to Daily inspection Items.) 	WARNING Be sure to perform the capacity test after completion of the no-load test. Mandatory Performing the capacity test without prior no-load test may result in death or serious injury. Refer to "Daily Inspection Items". (P23)	Disassemble the electric chain hoist to check whether it is assembled correctly and has no abnormal part.
Abnormal Noise	 To make the electric chain hoist travel with a load. 	 No abnormal noises emitted during operation. 	Disassemble the electric chain hoist to check whether it is assembled correctly and has no abnormal part.

Chapter 3

Troubleshooting

This chapter describes the main failure cause and inspection items based on the fault conditions. The repair work (and maintenance work as well) of the electric chain hoist is accompanied with disassembling/assembling work. Refer to the separate "Disassembling/Assembling Manual" for the correct work.

Guidance on Troubleshooting and Safety Precautions

Troubleshooting

- Power
- Circuit breaker (Distribution panel)
- Power Cable
- Motor Brake
- Internal wiring
- Transformer
- Electromagnetic Contactor, Relay
- Fuse
- Barrier relay
- Upper/Lower Limit Switch
- Push Button Switch
- Electric shock
- Friction Clutch
- Hook
- Load Chain
- Load Sheave, Idle Sheave
- Chain Guide A
- Gears and Joints
- Bearing
- Traveling motion of the Trolley (common for motorized / manual trolley)
- Traveling motion of the Trolley (only for motorized trolley)
- Traveling motion of the Trolley (only for manual trolley)

Guidance on Troubleshooting

Guidance on Troubleshooting

Following table is the summary of the main failure causes based on the failure conditions and their inspection items. Refer to the page of each item for the check method, treatment and the details of countermeasure.

• Refer to "Technical Materials" for the product structure and the component name of each part.

Conditions		Main fault contents	Check item	Reference page	
Electric chain	No brake	No	Improper source voltage	Power	83
hoist does not operate	operating sound	electromagnetic	Breakage or burning of	Circuit breaker	83
without load		contactor operating	control circuit	Power Cable	84
		sound	Faulty electrical part	Internal wiring	88
				Barrier relay	90
				Electromagnetic Contactor, Relay	89
				Transformer	88
				Fuse	89
				Upper/Lower Limit Switch	90
				Push Button Switch	91
		Electromagnetic	Breakage or burning of	Motor	85
		contactor operating sound	power circuit,	Brake	86
			Faulty motor or brake	Internal wiring	88
				Electromagnetic Contactor (melted contact points)	89
	Brake operating s	sound	Breakage of driving part	Gears and Joints	97
			Sticking of Bearing	Bearing	98
Electric chain	Does not operate	with a load	Open phase (single phase operation)	Power	83
hoist	(Motor sounds ho			Power Cable	84
operates without load				Motor	85
				Electromagnetic Contactor (melted contact points)	89
			Overload (clutch activated)	Friction Clutch	92
	Operates slowly v	with a load	Voltage drop	Power Cable	84
Operation	Operates differen	tly from the	Negative phase connection	Power Cable	84
does not	indication of the F Switch	Push Button	Wrong connection	Internal wiring	88
match Push Button		pposite direction)		Push Button Switch	91
Switch	Does not operate	when operating	Breakage of control circuit	Internal wiring	88
	any one of the Pu	ish Button Switch		Push Button Switch	91
			Faulty electrical part	Electromagnetic Contactor	89
				Upper/Lower Limit Switch	90
Does not stop	Does not stop ev	en if the Push	Melted contact point	Electromagnetic Contactor	89
normally	Button Switch is r			Barrier relay	90
	Too long (or shor distance	t) stopping	Abrasion of brake lining	Brake	86
	Does not stop at	the upper/lower	Negative phase connection	Power Cable	84
	limit.		Wrong connection	Internal wiring	88
				Push Button Switch	91

	Conditions		Main fault contents	Check item	Reference page
Abnormal noise	Popping sou	Ind	Abrasion of the Load Chain	Load Chain	95
			Abrasion of the Load Sheave	Load Sheave, Idle sheave	97
	Abnormal op	perating sound	Abrasion or breakage of Gear	Gears and Joints	97
			Deterioration of Bearing	Bearing	98
	Brake noise	Sounds when applied (scraping noise)	Dragging	Brake	86
		Sounds when released	Abrasion of brake lining	Brake	86
	Sounds at co (friction nois		Mechanical interference of the beam and the wheel	Traveling motion of the Trolley	98
Unable to	Motorized T	rolley / Manual	Slipping wheel	Traveling motion of the	98
travel	Trolley		Inclined beam	Trolley	
			Pulling a load in an inclined direction (floating wheel)		
			Defective gear engagement		
			Locking of brake		
	Motorized Trolley		Electric system failure (refer to the item of electric chain hoist)		
	Manual Trolley		Defective engagement of the Head Wheel and the Hand Chain		
Uneven tracking on	Motorized Tr Trolley	rolley / Manual	Mechanical interference of the beam and the wheel	Traveling motion of the Trolley	98
beam, abnormal			Wrong adjustment of collar		
sound			Uneven abrasion of the wheel		
			Deformation of the wheel		
			Deterioration of Bearing		
			Deformation and abrasion of the beam		
			Deterioration of the Bearing		
			Abrasion of the Brake Pad		
Hook and tho	se related to H	elated to Hook Deformation Hook		Hook	93
Load Chain a	nd those relate	ed to Load Chain	Abrasion, elongation, twist	Load Chain	95
Electric shock when touching the body and Push Button Switch			Improper grounding, breakage of ground wire	Electric shock	92

Safety Precautions

General Matters on Failure Cause and Countermeasure

• Do not disassemble or repair the electric chain hoist unless you are a qualified person. "Disassembling/Assembling Manual" and "Parts List" are provided separately for the maintenance. Disassembling and repair must be performed by gualified personnel in accordance with these materials for maintenance. Prohibited • When replacing the part, be sure to use the genuine part for HARRINGTON electric chain hoist RNER2, RNER2M and RNER2D. Even if the part is the HARRINGTON genuine part, the part for different model may not be used. Use the correct part in accordance with separate "Disassembling/Assembling Manual". Failure to comply with this content may result in death or serious injury. When any abnormality is observed during the maintenance (repair) of the electric chain hoist, survey the cause by the qualified person and carry out the repair. Be sure to keep the following when repairing the electric chain hoist: Mandatory

- Be sure to turn off the power.
- · Be sure to indicate "INSPECTION".
- · Carry out the repair without lifting a load.
- · Be sure to pay attention to the change of the operating sound of electric chain hoist and trolley.

The change of operating sound is an important factor to judge the failure.

Failure to comply with this content may result in death or serious injury.

Troubleshooting

Power

Symptom	Cause	Action	Main factor	Countermeasure
Electric chain hoist does not operate.	Improper source voltage	Measure the voltage of each phase at the power supply connection. If the source voltage is out of range, check the power receiving facility.	Faulty Facility Power	Check the facilities incoming power.
	Can Can	careful about electric shock when cking the power. relessly checking the supply power		
	may to electric shock	result in death or serious injury due		

Circuit breaker (Distribution panel)

Symptom	Cause	Action	Main factor	Countermeasure
Electric chain hoist does not operate.	Breaker was tripped due to a short circuit.	Replace or repair the short- circuited part.	Cable breakage, burning of electrical parts	Refer to each item of Power Cable, Motor, Brake, Internal Wiring, Transformer and Electromagnetic Contactor.
	Breaker was tripped due to insufficient breaker capacity.	Check the breaker capacity. Replace it if the capacity is insufficient.	Wrong selection of breaker capacity	Use the breaker with proper capacity.
	Breaker was tripped due to over current.	Check the cause of over current and take the necessary countermeasure. (Refer to each item of Power Cable, Motor, Brake, Internal Wiring, Transformer and Contactor.)	Over voltage, low voltage, over load	Refer to each item of Power Cable, Motor, Brake, Internal Wiring, Transformer and Electromagnetic Contactor.

Symptom	Cause	Action	Main factor	Countermeasure
Electric chain hoist does not operate.	Wire breakage (more than	Check the conduction, flaws, crimping of terminals and soldering of plug. When any deficiency is	Excessive force applied on the cable	Support the cable with Cable Support Arm securely.
	two wires)	observed, repair or replace the cable.	Not using flexible cable	Flexible cable is used fo traversing power.
			Twist of wire	Layout the wires without twisting.
			Cable travel is obstructed.	Fix the cable so it does not interfere.
	Wire burning (more than two wires)	Check the cable. Replace if burnt.	Temperature rise due to insufficient cable capacity	Use the cable with prope capacity. (See Page 36.
			Cables are bundled.	Do not bundle wires.
	insertion of plug of the receptacle. Tighten the	Insufficient insertion at the installation	Fix the connector plug to the receptacle securely.	
		coupling ring securely.	Loosening of the fixing thread due to impact or vibration	Use the electric chain hoist and avoid large impacts.
Slow start or unable to start	Insufficient cable capacity	Check the cable size for adequacy. Replace with the proper cable if the cable capacity is insufficient.	Voltage drop due to insufficient cable capacity	Use the cable with prope capacity.
Electric chain hoist operates but unable to lift a load. (single phase status)	Breakage or burning of wire	Refer to the breakage and burning of a	above items.	
For single speed model, the electric chain hoist operates in the	Wrong connection of power line when wiring	Change two wires of power line.	Wrong connection when assembling	Refer to the connection diagram and connect wires correctly.
direction different				
to the push button operation (Reverse phase).		ot change the connection at the Push n Pendant circuit.		
		anges to the wiring at the Push Button y dangerous as the limit switch will not work properly.		

Motor

Symptom	Cause	Action	Main factor	Countermeasure
Motor does not operate.	Motor coil burning (two or more phases)	Measure the coil resistance of each phase. Replace the motor when the resistance of all phases are infinity.	Over current due to over voltage or low voltage	Operate the electric chain hoist at the rated voltage.
			Over current due to overload	Use the electric chain hoist with a load less than the capacity.
			Operation exceeding short time rating or intermittent rating	Check the short time rating and intermittent rating. Use the electric chain hoist within these ratings.
			Excessive inching or jogging operation (consecutive energizing of the contactor)	Do not perform excessive operation.
			Over current due to brake dragging	Refer to the items of Brake.
	Lead wire breakage (more than two lead	breakage (more each phase. Replace the motor when the resistance of all	Lead wire damaged at assembling	Assemble with care.
	wires)		Vibration, impact	Use the electric chain hoist avoiding the impact.
Electric chain hoist operates but unable to lift a load. (single phase status)	Motor coil burning (only one phase)	Measure the coil resistance of each phase. Replace the motor when the resistance of all phases are infinity.	Layer short due to poor insulation of coil (between phases)	Be careful about the intrusion of foreign matter into the motor when assembling.
. ,	Lead wire breakage (only in one lead wire)	Measure the coil resistance of each phase. Replace the motor when the resistance of all phases are infinity.	Lead wire damaged at assembling	Be careful not to have the lead wire caught when assembling.
			Vibration, impact	Use the electric chain hoist avoiding the impact.

Brake



Do not adjust/disassemble the Electromagnetic Brake.

Adjusting or disassembling the Electromagnetic Brake may result in death or serious injury.

Symptom	Cause	Action	Main factor	Countermeasure
Electromagnetic Brake does not operate.	burning the Brake coil. Replace the to	Over current due to over voltage or low voltage	Operate the electric chain hoist at the rated voltage.	
			Excessive inching or jogging operation (consecutive energizing of the contactor)	Do not perform excessive operation.
			Over current due to overload	Use the electric chain hoist with a load less than the capacity.
		PracticeMeasure the brake gap. If the gap exceeds the service limit, reaction of the certormagneticExcessive inching operationDo not perfor excessive operationDrasion of rake Lining xceeding the agnetic traction of the ectromagneticMeasure the brake gap. If the gap exceeds the service limit, replace the electromagnetic brake unit as a wholeExcessive inching operationDo not perfor excessive operation	exceeding short ra time rating or ra intermittent rating e	Check the short time rating and intermittent rating. Use the electric chain hoist within these ratings.
			to open phase	immediately and check the cause of open phase
	Abrasion of Brake Lining (exceeding the magnetic attraction of the electromagnetic brake)			Do not perform excessive operation.
	Electromagnetic lead wire. Replace the wire da	Lead wire damaged at assembling	Be careful not to have the lead wire caught when assembling.	
	Insufficient connection of brake lead wire at insertion terminal	Connect the insertion terminal securely. Replace the loose insertion terminal if any.	Insufficient connection at assembling	Connect the insertion terminal securely at assembling.

Symptom	Cause	Action	Main factor	Countermeasure
Electromagnetic Brake does not operate.		Wrong assembling of packings	Assemble the brake cover packings securely. Replace the packing if deteriorated.	
			Leaving the electric chain hoist in an environment with rich moisture	Operate the electric chain hoist regularly.
			Dew condensation	Pay attention to the use in an environment where the ambient temperature changes rapidly.
	Breakage of rectifier	ctifier rectifier with circuit tester. ov	Over current due to over voltage or low voltage	Operate the electric chain hoist at the rated voltage.
	of the circuit tester Cathode terminal : Positive probe of the circuit tester (measure the resistance in kΩ range) When the resistance is almost zero, the rectifier is normal. In other cases, replace the rectifier.	Cathode terminal : Positive probe of the circuit tester (measure the resistance in kΩ	Excessive inching or jogging operation (consecutive energizing of the contactor)	Do not perform excessive operation.
		zero, the rectifier is normal.	Over current due to overload	Use the electric chain hoist with a load less than the capacity.
		Operation exceeding short time rating or intermittent rating	Check the short time rating and intermittent rating. Use the electric chain hoist within these ratings.	
		0	Over current due to open phase operation	The electric chain hoist cannot lift a load in open phase operation. When any abnormality is observed, stop the operation immediately and check the cause of open phase operation.
Too long (or short) stopping distance (stopping distance may change slightly depending on the temperature.)	Abrasion of brake lining	Measure the brake gap. If the gap exceeds the service limit, replace the electromagnetic brake unit as a whole	Excessive inching operation	Do not perform excessive operation.
Louder operating sounds	Abrasion of brake lining	Measure the brake gap. If the gap exceeds the service limit, replace the electromagnetic brake unit as a whole		Do not perform excessive operation.

Internal wiring

Symptom	Cause	Action	Main factor	Countermeasure
Electric chain hoist does not operate.	Breakage of wire	Check the wire. Repair the wire if broken.	Vibration, impact	Use the electric chain hoist avoiding the impact.
			Lead wire damaged at assembling	Be careful not to have the lead wire caught when assembling.
		Check the terminal. Repair the terminal without conduction.	Improper crimping	Use the proper crimping tool.
	Wrong wiring	Check the wiring in accordance with the wiring diagram. Correct the wiring if it is wrong.	Wrong wiring at assembling	Correct the wiring in accordance with the wiring diagram.
	Loosened terminal screw (results in heat	Tighten the loosened screws.	Insufficient tightening at assembling	Tighten screws securely.
	generation to burn)		Vibration, impact	Use the electric chain hoist avoiding the impact.
	Incomplete connection of plug, connector and insertion terminal	Connect plug, connector and insertion terminal correctly if they are not connected securely. Tighten the lock ring of the connector plug securely.	Incomplete connection at assembling	Connect plug, connector and insertion terminal securely.

Transformer

Symptom	Cause	Action	Main factor	Countermeasure
Electric chain hoist does not operate.	hoist does not breakage of	Measure the resistance of transformer coil. If it is infinity, replace the transformer.	Over voltage	Operate the electric chain hoist with the rated voltage.
(Electromagnetic Contactor does not operate.)	coil		Excessive inching or jogging operation (consecutive energizing of the contactor)	Do not perform excessive operation.
			Over current due to defective operation of Electromagnetic contactor	Refer to the items of Electromagnetic Contactor.
			Vibration, impact	Use the electric chain hoist avoiding the impact.
	Breakage of lead wire	Check the lead wires of the transformer. Repair or replace the transformer if the lead wire has no conduction.	Vibration, impact	Use the electric chain hoist avoiding the impact.

Electromagnetic Contactor, Relay

Symptom	Cause	Action	Main factor	Countermeasure
Electric chain hoist does not stop	Electromagnetic Contact point welding, or fusing	Operate the contactor manually to check the conduction. When the contact point is welded or fused, replace the contactor. When the device is a miniature	Excessive inching or plugging operation (consecutive impression of start rush current)	Do not perform excessive operation.
		relay, check the contact point visually.	Over voltage	Operate the electric chain hoist with the rated voltage.
			Over current due to over load	Use the electric chain hoist with a load less than the capacity.
Electric chain hoist does not operate.	Burnout or breakage of relay coil or contactor coil	Measure the resistance of relay coil or contactor coil. If it is infinity, replace the relay or the contactor.	Excessive inching or plugging operation (consecutive impression of start rush current)	Do not perform excessive operation.
			Over voltage	Operate the electric chain hoist with the rated voltage.
			Chattering due to low voltage (consecutive impression of start rush current)	Operate the electric chain hoist with the rated voltage.
	Damaged moving parts	Operate the Electromagnetic contactor by its manual operation part. Replace the contactor if it does not move smoothly. Check the miniature relay visually if it does not have damaged part.	Vibration, impact	Use the electric chain hoist avoiding the impact.

Fuse

Symptom	Cause	Action	Main factor	Countermeasure
Electric chain hoist does not operate. (Electromagnetic Contactor does not operate.)	Blown out	Check the conduction of the fuse. When no conduction, check the cause and then replace the fuse.	Short circuit of the control circuit, burnout of electrical part Over current due to defective operation of Electromagnetic contactor	Refer to the items related to the electrical part in failure. Refer to the items of Electromagnetic Contactor.

3

Barrier relay

Symptom	Cause	Action	Main factor	Countermeasure
Electric chain hoist does not stop.	Contact point welding for the relay output	If there is conduction between the relay contact points, replace the barrier relay.	Excessive inching or plugging operation	Do not perform excessive operation.
Electric chain hoist does not operate. (Electromagnetic contactor does not operate.)	Error in internal barrier relay circuitry	Press the push button and confirm that the appropriate output display illuminates.	Error in internal barrier relay circuitry	Replace the barrier relay.

Upper/Lower Limit Switch

Symptom	Cause	Action	Main factor	Countermeasure
Electric chain hoist does not operate. (Electromagnetic Contactor or VFD does not operate.)	Contact point fusing	Actuate the limit switch manually to check the conduction of the contact points. Replace the limit switch as a whole when no conduction.	Habitual use of the limit switch	Do not use the limit switch habitually.
	Breakage	Check the wiring. Repair or replace the limit switch as a whole if the limit switch has no conduction.	Vibration, impact	Use the electric chain hoist avoiding the impact.
	Moving part rusted shut (defective return action of the moving part)	Check the moving part of the limit switch such as actuator lever is not stiff. If it is stiff, remove the rust or replace the stiff part.	Leaving the electric chain hoist for a long time at the upper/lower limit.	Do not leave the electric chain hoist at the upper/lower limit.
Electric chain hoist does not stop at the upper/lower limit.	Contact point welding	Actuate the limit switch manually to check the conduction of the contact points. Replace the limit switch as a whole when it does not turn off.	Habitual use of the limit switch	Do not use the limit switch habitually.
	Moving part rusted shut	Check the moving part of the limit switch such as actuator lever is not stiff. If it is stiff, remove the rust or replace the stiff part.	No use for a long time, use in an environment with rich moisture	Check the electric chain hoist regularly.
	Incorrect wiring	Check the wiring in accordance with the wiring diagram. Perform the wiring correctly. If the wiring of the limit switch is correct, the cause is in the negative phase connection. Change two wires of the power line.	Incorrect wiring	Correct the wiring in accordance with the wiring diagram.

Push Button Switch

Symptom	Cause	Action	Main factor	Countermeasure
Electric chain hoist does not operate. (Electromagnetic Contactor does not operate.)	Emergency Stop button is pressed to its end and locked.	When the Emergency Stop button is pressed and locked, turn it clockwise to release the lock.	Forgot releasing the Emergency Stop button	Read "How to Operate the Push Button Switches" and use the electric chain hoist.
	Faulty switch unit	Check the conduction of the contact points. Replace the Push Button Switch if it has no conduction.	Vibration, impact	Use the electric chain hoist avoiding the impact.
	Breakage inside the switch	Check that the Pendant cord is connected to the switch unit correctly. Repair the cord if it has no conduction.	Vibration, impact	Use the electric chain hoist avoiding the impact.
	Loosened terminal screw inside the switch unit	Tighten the screw if loosened	Vibration, impact	Use the electric chain hoist avoiding the impact.
	Wire breakage of Pendant Cord	Check the conduction of the Pendant Cord. If it has no conduction, replace the cable, or the Pendant Cord as a set.	Damage of cable cover	Operate the electric chain hoist not to impede with other facility.
			External force applied on the cable due to improper attachment of the Strain relief cable	Attach the Strain relief cable securely. (Refer to the figures for Frequent Inspection, Push Button Switch, and Pendant Cord
The electric chain hoist does not operate as indicated.	Wrong wiring	Check the wiring in accordance with the wiring diagram. Perform the wiring correctly. If the wiring of the Push Button Switch is correct, the cause is in the negative phase connection. Change two wires of the power line.	Wrong wiring	Correct the wiring in accordance with the wiring diagram.
	Wrong affixing of N-E-S-W label	Affix the label in the correct direction.	Affixing the label in an improper direction	Affix the label correctly.
Electric chain hoist does not stop even if the Push Button is released	Defective return action of the switch unit	Replace the Push Button Switch if it does not operate smoothly.	Vibration, impact	Use the electric chain hoist avoiding the impact.

Electric shock

Symptom	Cause	Action	Main factor	Countermeasure
Electric shock when touching the body and	Improper grounding	Measure the grounding resistance. If it exceeds 10 Ω , perform grounding work.	Defective grounding work	Perform the grounding work securely.
Push Button Switch			Contact failure of the grounding wire	Connect the grounding wire securely without loosened screw
			Breakage of grounding wire	Layout the grounding wire to avoid the stress applied on it. (See the item of Power Cable and Push Button Switch.)
	Moisture in the pendant	Remove the moisture, dry the electric chain hoist and then use it.	Operation in wet environment	Avoid moisture and water contamination

Friction Clutch

• Do not adjust/disassemble the Friction Clutch.

Adjusting or disassembling the Friction Clutch may result in death or serious injury.

Prohibited

Symptom	Cause	Action	Main factor	Countermeasure
Unable to lift a load, or the load drifts after stopping.	Clutch engaged (normal)	Lighten the load to equal to or less than the capacity.	Over loading of hoist	Use the electric chain hoist at or less than rated capacity.
	Worn or damaged	Replace the Friction Clutch.	Friction Clutch engaged too often	Avoid overloading or overwinding hoist.
	Slip Clutch Disk		Approaching service life limit	Service before using.
	Change in mechanical characteristics of the Friction Clutch	nechanical d		Use standard Harrington Hoists oil.
		Â	WARNING	
		• Use Harrington Hoists sta Use of oil other than Harring serious injury due to the dro	gton Hoists genuine oil m	ay result in death or
			Leaving the hoist sit idle for a long periods of time	Do not leave idle for long periods of time
	Temperature too high inside gear box	Resume the operation after a cool down period. If it is still unable to lift a load, replace the Friction Clutch.	Used in a hot environment, or excessively use.	Avoid using in a hot environment or excessive use.

Hook

Symptom	Cause	Action	Main factor	Countermeasure
Widened Hook opening	Deformation of the Hook	Replace the Hook if the deformation exceeds the criteria.	Overload	Use the electric chain hoist with a load less than the capacity.
			Load attached to floor/ground	Ensure load is not attached to ground or floor. Be careful not to impede Hook with protruding object during lifting.
			Slinging a load at the tip of the Hook.	Sling a load at the center of the Hook
			Improper slinging	Angle formed by two slings must be 120 degrees or less.
			Use of a sling with a size improper to the Hook	Use the proper sling.
Twisted hanging of the Hook			Use of the Hook with the Load Chain wound on a load	Do not wind the Load Chain directly on a load.
Hook unable to swivel smoothly at the neck	Rusting shut or corrosion of Bearing	Swivel the Hook at the neck by hand. If it is difficult to swivel smoothly, overhaul or replace the Bearing.	Insufficient grease application, corrosion due to environment of use	Apply grease regularly. Use the sling to avoid the dipping of the Hook into chemicals.
	Damaged Bearing		Intrusion of dust	Be careful about the intrusion of foreign matter into the neck.

Symptom	Cause	Action	Main factor	Countermeasure
Hook Latch has come off	Deformation of the Hook	Replace the Hook if the deformation exceeds the criteria.	Overload	Use the electric chain hoist with a load less than the capacity.
			Load attached to floor/ground	Ensure load is not attached to ground or floor. Be careful not to impede Hook with protruding object during lifting.
			Use of a sling with a size improper to the Hook	Use the proper sling.
	Deformation and failure of the Hook Latch	Replace the Hook Latch if it has come off or is deformed.	Sling put on the Hook Latch	Do not put the sling on the Hook Latch.
Hook bent at the neck (shank)	Deformation or damage of the Hook at its neck	Replace the Hook bent at the neck	Lifting a load at the tip of the Hook	Sling a load at the center of the Hook
			Lateral pulling of the Hook	
Hook unable to swivel smoothly at the neck	Rusting shut or corrosion of Bearing	Swivel the Hook at the neck by hand. If it is difficult to swivel smoothly, overhaul or replace the Bearing.	Insufficient grease application, corrosion due to environment of use	Apply grease regularly. Use the sling to avoid the dipping of the Hook into chemicals.
	Damaged Bearing		Intrusion of dust	Be careful about the intrusion of foreign matter into the neck.

Symptom	Cause	Action	Main factor	Countermeasure
Twisted Load Chain	Bottom Hook Capsized	Return Bottom Hook to the original position to prevent capsizing.	Bottom Hook was Capsized during operation.	When using multi fall model hoist, check that the Hook is not capsized before use.
	Load Chain is twisted inside the main body of the chain hoist.	Remove Chain Guide A and the Load Chain, and reassemble.	Improper assembly	Assemble the electric chain hoist correctly.
Sudden activation of the Friction Clutch when lowering	Knot in the Load Chain to interference with the chain container	Confirm the chain capacity of the Chain Container. If insufficient, replace the Chain Container with a larger capacity.	Insufficient capacity Chain Container	When installing the chain hoist, confirm the lift and capacity of the Chain Container is acceptable for the application.
Hoist makes popping sound during operations	Worn or deformed Load Chain links	Inspect and measure of wire diameter of chain. Replace the Load Chain if is out of tolerance.	Operating without proper chain grease or inspections for extended amount of time.	Apply lubricant regularly.
		Be sure to apply lubricant to the linear a fire or arc. Otherwise it will result in fire.		ry out oiling work
		 Remove dust and moisture from the Load Cl and then apply lubricant. Application of lubrica affects the life of the Load Chain considerably. Apply the lubricant sufficiently. Use the followin genuine lubricant. Epinoc Grease AP (N)0 (Nippon Oil Corporation) Consistency No.0 (Industrial general Lower and remove all loads from the Load C portion of the Load Chain that engages the Lo area). After application of the lubricant lift/lower spread the lubricant on the Load Chain. 	nt ng lithium grease) chain. Apply the lubrica ad Sheave and the Idle er the electric chain hois	e Sheave (hatched st without load to
			Excessive inching operation Overload	Do not perform excessive operation Use the electric chain hoist with a load less than the capacity
			Pulling a load in an inclined direction	Do not pull a load in an inclined direction.

Symptom	Cause	Action	Main factor	Countermeasure
Popping sound	Abrasion of the Load Chain links	Measure the abrasion of wire diameter. Replace the Load Chain if it reaches at the abrasion limit.	Abrasion of Load Sheave, Idle Sheave	Refer to the item of Load Sheave, Idle Sheave.
	Elongation of pitch	Measure the sum of pitches of 5 links. Replace the Load Chain if this value exceeds the limit value.	Overload	Use the electric chain hoist with a load less than the capacity.
Irregular noise	Flaw and deformation of the Load Chain surface	Replace the Load Chain with apparent flaw or deformation.	Use of the Load Chain while the hook is capsized	When using multi fall model hoist, check that the Hook is not capsized before use.
			Use of the Load Chain as twisted	Assemble the electric chain hoist correctly. (See Disassembling/ Assembling Manual)
	Hit flaw on the Load Chain surface		Hit with other object strongly	Use the electric chain hoist carefully paying attention not to impede with other object.
Surface losing finish and discolored	Rusting and corrosion	Remove rust and apply oil. Replace the Load Chain if the rust and corrosion is apparent.	Run-out of oil	Apply lubricant regularly. Regarding the method for applying oil, refer to "A popping sound occurs" in the Symptoms column.
			Use of electric chain hoist exposed to rain	Store the electric chain hoist indoor or under the roof when not using.
			Influence of sea water and chemicals	Contact HARRINGTON for use in abnormal environments in advance. Use the electric chain hoist correctly within the scope guaranteed by the manufacturer.
Breakage of the Load Chain	Expiration of the service life	Check the Load Chain and replace it if exceeded the criteria.	Mechanical service life expiration	Handle the Load Chain correctly and perform the appropriate control including daily inspection and inspection.

Load Sheave, Idle Sheave

Symptom	Cause	Action	Main factor	Countermeasure
Popping sound	opping sound Abrasion of sheave pocket or flaw by the Load Chain out	Measure the thickness of the crest. Replace the Sheave if the thickness is less than the criteria.	Long hour operation without grease, expiration of service life	Apply lubricant regularly.
		e The Load Chain may be worn. Check also the Load Chain.	Excessive inching operation	Do not perform excessive operation.
	Worn part		Overload	Use the electric chain hoist with a load less than the capacity.
			Pulling a load in an inclined direction	Do not pull a load in an inclined direction.

Chain Guide A

Symptom	Cause	Action	Main factor	Countermeasure
Swinging of a load became larger than when purchasing	Abrasion of cross guide	Measure the standard dimension. Replace the cross guide if the standard dimension exceeds the criteria. The Load Chain may be worn. Check also the Load Chain.		Do not pull a load in an inclined direction.

Gears and Joints

Symptom	Cause	Action	Main factor	Countermeasure
Unable to lift a load.	Abrasion, Damage	Replace gear or joint if it is worn apparently or damaged	Long hour operation without oil	Keep the oil change cycle. (At least every 5 years)
				NING
			gear oil Use of c HARRIN may res	ARRINGTON genuine bil other than IGTON genuine oil ult in death or serious ue to the a drop of lifted
			Long hour operation without grease (motor joint)	Apply grease at periodic inspection.
Irregular motion	Partial abrasion or damage		Too many uses of the Friction Clutch	Avoid the overload.
			Habitual use of Upper/ Lower Limit Switch	Do not use Upper/ Lower Limit Switch habitually.

Bearing

Symptom	Cause	Action	Main factor	Countermeasure
Unable to lift a load.	Sticking, Breakage	Replace the bearing.	Use under hot environment or excessively frequent use	Avoid using under hot environment or excessively frequent use
Strange noise	Deterioration	Replace the bearing.	Use under hot environment or excessively frequent use	Avoid using under hot environment or excessively frequent use

Traveling motion of the Trolley (common for motorized / manual trolley)

Symptom	Cause	Action	Main factor	Countermeasure
Unable to travel due to slipping of wheel	Inclination of Travel Beam	Make sure that beam gradient is within 1 degree.	Improper installation of Travel Beam	Install the Travel Beam correctly.
Unable to travel due to slipping of wheel, or unable to travel in uniform motion	Oil attachment on running surface of the beam	Wipe off the attached foreign matter.	Use under the environment likely to attach foreign matter	Clean the Travel Beam regularly.
Sounds abrasion sound when running on a curved beam	Friction resistance between wheel and beam	Apply small amount of oil on the beam surface where noise generates.		
Unable to travel on the curved beam	Interference of the trolley and the curved beam	Make sure that the beam curvature is larger than the minimum turning radius.	Use of the curved beam of curvature less than minimum turning radius	Do not use the curved beam of curvature less than minimum turning radius
Unable to travel due to wheel floating	Pulling a load in an inclined direction (floating wheel)	Verify beam straightness. Inspect trolley wheels for wear.	Operating method	Use the electric chain hoist correctly.
Wheel unable to rotate	Defective gear engagement	Remove the stain and foreign matter on the wheel and the gear.	Ambient conditions, environment	Check regularly.
Meandering Strange noise	Wrong adjustment of collar	Check the number of collars and their assembled positions	Incomplete checking	Assemble correctly.
	Uneven abrasion of the wheel	Check the abrasion of the wheel	Traveling on curved beam or unevenness of running surface	Check regularly.
	Deformation of wheel	Check the distortion of wheel and damage of running surface	Excessively frequent collision with stopper or unevenness of running surface	Replace the wheel Use the electric chain hoist correctly.
	Deterioration of wheel bearing	Check if rolling noise sounds when the wheel is rotating.	Expiration of service life	Replace the wheel bearing.
	Deformation and abrasion of the beam	Check the abrasion and deformation of the beam.	Overload or expiration of service life	Replace the beam. Use the electric chain hoist correctly.

Troubleshooting (continued)

Traveling motion of the Trolley (only for motorized trol	ley)
--	------

Symptom	Cause	Action	Main factor	Countermeasure
Wheel unable to rotate	Locking of brake	Disassemble the motor cover. Remove rust and stains.	Ambient conditions, environment	Check regularly.
	Electric system failure (Refer to the items of Electric chain hoist)	(Refer to the items of	Electric chain hoist)	
Serpentine motion Strange noise	Abrasion of the side roller	Check the abrasion	Traveling on curved beam or expiry of service life	Check regularly.
	Abrasion of the Brake Pad	Check the abrasion of the Brake Pad	Expiry of service life	Check regularly.

Traveling motion of the Trolley (only for manual trolley)

Symptom	Cause	Action	Main factor	Countermeasure
Unable to pull the Hand Chain	Defective engagement of the Hand Wheel and the Hand Chain	Engage the Hand Chain with the Hand Wheel correctly.	Rapid operation	Replace the Hand Chain with abrasion or deformation.

Appendix A

This Appendix summarizes the information helpful for the use of HARRINGTON electric chain hoist, such as optional parts, technical materials and service network.

Optional Parts Product Structure and Names of Each Part Technical Material

- Hook Dimensions (for RNER2)
- Table of Lifting Load

Α

- Rated Motor Current
- Conversion Table between Lift/Travel/Speed (m/s"m/min)
- Clearance between Trolley and Applicable Beam
- Wiring Diagram of Dual Speed RNER2/RNER2G
- Wiring Diagram of Dual Speed RNER2M
- Applying Grease on Joint surface, Check Sheet for Daily Inspection, Check Sheet for Frequent Inspection

Check Sheet for Periodic Inspection

Technical Material (continued)

Optional Parts

Bumper: Stopper for Trolley RMR2

A shock absorber for collision (special for RMR2) Be sure to use the bumper when the trolley uses urethane wheel.



T-shape Cable Hanger: Attachment for power feeding

Code	Travel Beam width (inch (mm))	Hole pitch (inch (mm))	Parts
T-shape Cable Hanger 100	2.95 (75)	A : 2.09 (53)	
	3.94 (100)	B : 3.07 (78)	ptior
	4.92 (125)	C : 4.05 (103)	lo
	5.9 (150)	D : 5.04 (128)	
T-shape Cable Hanger 175	6.9 (175)	A : 6.02 (153)	



• Contact HARRINGTON when the Travel Beam width exceeds 6.9 inches (175 mm).

O Mounting Suspender Presser

- When using T-shape Cable Hanger, the suspender presser needs to be mounted to the trolley.
- Following holes to mount the suspender presser are worked on the main frame of the trolley. Mount the suspender presser with socket head bolts.
- Fix the cable support to the suspender presser with Chain Pin and split pin and mount the power cable.



Angle Cable Hanger: Accessory for power feeding

Code	Angle	Hole pitch
THLT and THLP	50×50	53
	65×65	66
	75×75	79



79

< THLT (for intermediate support >



< THLP (for Push Button Switch cord >



Product Structure and Names of Each Part





Technical Material

Hook Dimensions (for RNER2)



•Bottom Hook



Co	Code		Top Hook inches (mm)				Во	ttom Hool	(inches (r	nm)	-		
RNER2B	RNER2D	D	g	i	j	k	I	D	g	h	j	е	с
RNER2B-	RNER2D-	1.67	1.22	0.89	1.22	1.44	0.89	4.67	1.22	0.89	1.22	1.44	0.89
010LD	010LD	(42.5)	(31)	(22.5)	(31)	(36.5)	(22.5)	(42.5)	(31)	(22.5)	(31)	(36.5)	(22.5)
RNER2B-	RNER2D-	4.67	1.22	0.89	1.22	1.44	0.89	4.67	1.22	0.89	1.22	1.44	0.89
010SD	010SD	(42.5)	(31)	(22.5)	(31)	(36.5)	(22.5)	(42.5)	(31)	(22.5)	(31)	(36.5)	(22.5)
RNER2B-	RNER2D-	2.09	1.54	1.24	1.71	2.03	1.24	1.87	1.34	1.04	1.44	1.71	1.04
015SD	015SD	(53)	(39)	(31.5)	(43.5)	(51.5)	(31.5)	(47.5)	(34)	(26.5)	(36.5)	(43.5)	(26.5)
RNER2B-	RNER2D-	2.09	1.54	1.24	1.71	2.03	1.24	2.09	1.54	1.24	1.71	2.03	1.24
020CD	020CD	(53)	(39)	(31.5)	(43.5)	(51.5)	(31.5)	(53)	(39)	(31.5)	(43.5)	(51.5)	(31.5)
RNER2B-	RNER2D-	2.09	1.54	1.24	1.71	2.03	1.24	2.09	1.54	1.24	1.71	2.03	1.24
020LD	020LD	(53)	(39)	(31.5)	(43.5)	(51.5)	(31.5)	(53)	(39)	(31.5)	(43.5)	(51.5)	(31.5)
RNER2B-	RNER2D-	2.09	1.54	1.24	1.71	2.03	1.24	2.09	1.54	1.24	1.71	2.03	1.24
020SD	020SD	(53)	(39)	(31.5)	(43.5)	(51.5)	(31.5)	(53)	(39)	(31.5)	(43.5)	(51.5)	(31.5)
RNER2B-	RNER2D-	2.36	1.73	1.28	1.73	2.05	1.28	2.09	1.54	1.24	1.71	2.03	1.24
025SD	025SD	(60)	(44)	(32.5)	(44)	(52)	(32.5)	(53)	(39)	(31.5)	(43.5)	(51.5)	(31.5)
RNER2B-	RNER2D-	2.36	1.73	1.36	1.87	2.2	1.36	2.36	1.73	1.36	1.87	2.2	1.36
030CD	030CD	(60)	(44)	(34.5)	(47.5)	(56)	(34.5)	(60)	(44)	(34.5)	(47.5)	(56)	(34.5)
RNER2B-	RNER2D-	2.48	1.85	1.67	2.2	2.64	1.67	2.48	1.85	1.67	2.2	2.64	1.67
050LD	050LD	(63)	(47)	(42.5)	(56)	(67)	(42.5)	(63)	(47)	(42.5)	(56)	(67)	(42.5)

Table of Lifting Load

Capacity (t)	1	1.5	2	2.5	3	5
Lifting Load (t)	1.002	1.504	2.004	2.504	3.008	5.014

Note) Above figures are for the standard specification Hook for Electric Chain Hoist RNER2.

Rated Motor Current

Lifting motor

200V Class

		Rated Curren	t (A)	
Co	Motor	208-230V		
	output	60Hz		
RNER2B	RNER2D	(kW)	High speed	Low speed
RNER2B-010LD/RENR2B-010SD	RNER2D-010LD/RNER2D-010SD			
RNER2B-015SD/RNER2B-020CD	RNER2D-015SD/RNER2D-020CD	1.8/0.45	10.2	5
RNER2B-020LD	RNER2D-020LD			
RNER2B-020SD/RNER2B-025SD	RNER2D-020SD/RNER2D-025SD	3.5/0.875	18.7	8.1
RNER2B-030CD/RNER2B-050LD	RNER2D-030CD/RNER2D-050LD	3.5/0.875	10.7	0.1

	Motor	Rated Current (A)				
Code			38	0V	440-	460V
		(kW)	50	Hz	60	Hz
RNER2B	RNER2D		High speed	Low speed	High speed	Low speed
RNER2B-010LD/RENR2B-010SD RNER2B-015SD/RNER2B-020CD RNER2B-020LD	RNER2D-010LD/RNER2D-010SD RNER2D-015SD/RNER2D-020CD RNER2D-020LD	1.8/0.45	5.3	3.1	5.4	3.4
RNER2B-020SD/RNER2B-025SD RNER2B-030CD/RNER2B-050LD	RNER2D-020SD/RNER2D-025SD RNER2D-030CD/RNER2D-050LD	3.5/0.875	8.3	4.8	8.3	4.9

500V Class

Co	Motor	575V 60Hz			
	output				
RNER2B	RNER2D	(kW)	High speed	Low speed	
RNER2B-010LD/RENR2B-010SD RNER2B-015SD/RNER2B-020CD RNER2B-020LD	RNER2D-010LD/RNER2D-010SD RNER2D-015SD/RNER2D-020CD RNER2D-020LD	1.8/0.45	3.9	2.4	
RNER2B-020SD/RNER2B-025SD RNER2B-030CD/RNER2B-050LD	RNER2D-020SD/RNER2D-025SD RNER2D-030CD/RNER2D-050LD	3.5/0.875	6.4	3.6	

Traveling motor

200V Class

		Rated Current (A)		
Co	Code Motor 208-230V			230V
	output	60Hz		
RMR2B	RMR2D	(kW)	High speed	Low speed
RMR2B-010SD/RMR2B-020SD RMR2B-030SD/RMR2B-050SD	RMR2D-010SD/RMR2D-020SD RMR2D-030SD/RMR2D-050SD	0.59/0.15	2.9	3.0

400V Class

		Rated Current (A)			
Co	Motor	575V			
	output	60	Hz		
RMR2B	RMR2D	(kW)	High speed	Low speed	
RMR2B-010SD/RMR2B-020SD RMR2B-030SD/RMR2B-050SD	RMR2D-010SD/RMR2D-020SD RMR2D-030SD/RMR2D-050SD	0.59/0.15	1.3	1.1	

500V Class

	Motor	Rated Current (A)				
Cod	output	380	V	440-460V		
		(kW)	50Hz		60Hz	
RMR2B	RMR2D		High Low speed speed		High speed	Low speed
RMR2B-010SD/RMR2B-020SD RMR2B-030SD/RMR2B-050SD	RMR2D-010SD/RMR2D-020SD RMR2D-030SD/RMR2D-050SD	0.59/0.15	2.4	2.7	1.9	2.2

Conversion Table between Lift/Travel/Speed (m/s"m/min)

Converted value (m/s)	Conventional value (m/min)	Converted value (m/s)	Conventiona value (m/min)								
	//	0.067	4.0	0.133	8.0	0.200	12.0	0.267	16.0	0.333	20.0
0.002	0.1	0.068	4.1	0.135	8.1	0.202	12.1	0.268	16.1	0.335	20.1
0.003	0.2	0.070	4.2	0.137	8.2	0.203	12.2	0.270	16.2	0.337	20.2
0.005	0.3	0.072	4.3	0.138	8.3	0.205	12.3	0.272	16.3	0.338	20.3
0.007	0.4	0.073	4.4	0.140	8.4	0.207	12.4	0.273	16.4	0.340	20.4
800.0	0.5	0.075	4.5	0.142	8.5	0.208	12.5	0.275	16.5	0.342	20.5
0.010	0.6	0.077	4.6	0.143	8.6	0.210	12.6	0.277	16.6	0.343	20.6
0.012	0.7	0.078	4.7	0.145	8.7	0.212	12.7	0.278	16.7	0.345	20.7
0.013	0.8	0.080	4.8	0.147	8.8	0.213	12.8	0.280	16.8	0.347	20.8
0.015	0.9	0.082	4.9	0.148	8.9	0.215	12.9	0.282	16.9	0.348	20.9
0.017	1.0	0.083	5.0	0.150	9.0	0.217	13.0	0.283	17.0	0.350	21.0
0.018	1.1	0.085	5.1	0.152	9.1	0.218	13.1	0.285	17.1	0.352	21.1
0.020	1.2	0.087	5.2	0.153	9.2	0.220	13.2	0.287	17.2	0.353	21.2
0.022	1.3	0.088	5.3	0.155	9.3	0.222	13.3	0.288	17.3	0.355	21.3
0.023	1.4	0.090	5.4	0.157	9.4	0.223	13.4	0.290	17.4	0.357	21.4
0.025	1.5	0.092	5.5	0.158	9.5	0.225	13.5	0.292	17.5	0.358	21.5
0.027	1.6	0.093	5.6	0.160	9.6	0.227	13.6	0.293	17.6	0.360	21.6
0.028	1.7	0.095	5.7	0.162	9.7	0.228	13.7	0.295	17.7	0.362	21.7
0.030	1.8	0.097	5.8	0.163	9.8	0.230	13.8	0.297	17.8	0.363	21.8
0.032	1.9	0.098	5.9	0.165	9.9	0.232	13.9	0.298	17.9	0.365	21.9
0.033	2.0	0.100	6.0	0.167	10.0	0.233	14.0	0.300	18.0	0.367	22.0
0.035	2.1	0.102	6.1	0.168	10.1	0.235	14.1	0.302	18.1	0.368	22.1
0.037	2.2	0.103	6.2	0.170	10.2	0.237	14.2	0.303	18.2	0.370	22.2
0.038	2.3	0.105	6.3	0.172	10.3	0.238	14.3	0.305	18.3	0.372	22.3
0.040	2.4	0.107	6.4	0.173	10.4	0.240	14.4	0.307	18.4	0.373	22.4
0.042	2.5	0.108	6.5	0.175	10.5	0.242	14.5	0.308	18.5	0.375	22.5
0.043	2.6	0.110	6.6	0.177	10.6	0.243	14.6	0.310	18.6	0.377	22.6
0.045	2.7	0.112	6.7	0.178	10.7	0.245	14.7	0.312	18.7	0.378	22.7
0.047	2.8	0.113	6.8	0.180	10.8	0.247	14.8	0.313	18.8	0.380	22.8
0.048	2.9	0.115	6.9	0.182	10.9	0.248	14.9	0.315	18.9	0.382	22.9
0.050	3.0	0.117	7.0	0.183	11.0	0.250	15.0	0.317	19.0	0.383	23.0
0.052	3.1	0.118	7.1	0.185	11.1	0.252	15.1	0.318	19.1	0.385	23.1
0.053	3.2	0.120	7.2	0.187	11.2	0.253	15.2	0.320	19.2	0.387	23.2
0.055	3.3	0.122	7.3	0.188	11.3	0.255	15.3	0.322	19.3	0.388	23.3
0.057	3.4	0.123	7.4	0.190	11.4	0.257	15.4	0.323	19.4	0.390	23.4
0.058	3.5	0.125	7.5	0.192	11.5	0.258	15.5	0.325	19.5	0.392	23.5
0.060	3.6	0.127	7.6	0.193	11.6	0.260	15.6	0.327	19.6	0.393	23.6
0.062	3.7	0.128	7.7	0.195	11.7	0.262	15.7	0.328	19.7	0.395	23.7
0.063	3.8	0.130	7.8	0.197	11.8	0.263	15.8	0.330	19.8	0.397	23.8
0.065	3.9	0.132	7.9	0.198	11.9	0.265	15.9	0.332	19.9	0.398	23.9
										0.400	24.0

0.500 30.0 0.600 36.0

Clearance between Trolley and Applicable Beam

Motorized Trolley

motorized froncy											
				Cle	aran	ce betv	veen troll	ey and be	am (mi	m)	
	I-beam size (mm)		~1t ~2t		•						
					~2t		Single Double		~5		~5t
Н	В	t	Α	В	Α	В	Α	Α	В	Α	В
100	75	5	×	×	×	×	×	×	×	×	×
125	75	5.5	14	9.75	×	×	×	×	×	×	×
150	75	5.5	14	9.75	×	×	×	×	×	×	×
180	100	6	14	22	19	19.5	×	×	×	×	×
200	100	7	14	21.5	19	19	×	×	×	×	×
150	125	8.5	11	33.3	15	30.8	×	×	×	×	×
250	125	7.5	13	33.8	17	31.3	10.6	11.8	28.8	32	18.3
250	125	10	5.9	32.5	10	30	17.2	18.4	27.5	26	17
200	150	9	9.8	45.5	14	43	14.5	15.7	40.5	30	30
300	150	8	13	46	17	43.5	17.6	18.8	41	33	30.5
300	150	10	7.3	45	12	42.5	12	13.2	40	27	29.5
300	150	12	3.7	44.3	8.2	41.8	8.5	9.7	39.3	24	28.8
350	150	9	11	45.5	15	43	15.5	16.7	40.5	31	30
350	150	12	1.7	44	6.2	41.5	6.4	7.6	39	22	28.5
400	150	10	7.8	45	12	42.5	12.5	13.7	40	28	29.5
400	150	13	0.7	43.8	5.1	41.3	5.4	6.6	38.8	21	28.3
450	175	11	×	×	11	54.5	11.4	12.6	52	20	41.5
450	175	13	×	×	4.5	53.5	4.3	5.5	51	27	40.5
600	190	13	×	×	6.5	61	6.8	8	58.5	22	48
600	190	16	×	×	×	×	×	×	×	12	46.5



Manual Trolley

Δ

I-beam size Clearance between trolley and beam (mm)										
П-D	(mm)	ze			-	RT	SG			
	(1111)		~1t		~2t		~3t		~5t	
Н	В	t	Α	В	Α	В	Α	В	Α	В
100	75	5	21.1	11.0	×	×	×	×	×	×
125	75	5.5	19.5	10.75	×	×	×	×	×	×
150	75	5.5	19.5	10.75	×	×	×	×	×	×
180	100	6	19.9	23.0	25.6	18.5	×	×	×	×
200	100	7	19.9	22.5	25.6	18	×	×	×	×
150	125	8.5	16.7	34.25	22.4	29.75	24.1	27.25	×	×
250	125	7.5	18.2	34.75	23.9	30.25	25.6	27.75	35.2	20.25
250	125	10	11.6	33.5	17.3	29	19	26.5	28.6	19
200	150	9	15.6	46.5	21.2	42	22.9	39.5	32.5	32
300	150	8	18.6	47.0	24.3	42.5	26	40	35.6	32.5
300	150	10	13.0	46.0	18.7	41.5	20.4	39	30.5	31.5
300	150	12	9.5	45.25	15.2	40.75	16.9	38.25	26.4	30.75
350	150	9	16.6	46.5	22.2	42	23.9	39.5	33.5	32
350	150	12	7.5	45.0	13.1	40.5	14.8	38	24.4	30.5
400	150	10	13.5	46.0	19.2	41.5	20.9	39	30.5	31.5
400	150	13	6.4	44.75	12.1	40.25	13.8	37.75	23.4	30.25
450	175	11	12.4	58.0	18.1	53.5	19.7	51	29.3	43.5
450	175	13	5.3	57.0	11.0	52.5	12.7	50	22.3	42.5
600	190	13	7.8	64.5	13.5	60	15.2	57.5	24.8	50
600	190	16	×	×	3.4	58.5	5.1	56	14.7	48.5


Wiring Diagram of Dual Speed RNER2/RNER2G



Wiring Diagram of Dual Speed RNER2M



Check Sheet for Daily Inspection

Code	I	Capacity	Lot No.	Your CTRL No.	Installation date	Location	Inspection Certification valid thru
Electric Chain Hoist	RNER2						
Motorized Trolley	RMR2						

Electric Chain Hoist RNER2 Daily Inspection

Category	Check item	Check method	Criteria			Inspection date/result			
oategory				/	/	/	/	/	/
	Unauthorized modification	Visual inspection	No unauthorized modifications visible to the naked eye						
ance	Indication of nameplates and labels	Visual inspection	To have no peeled off. To be legible clearly.						
Appearance	Deformation and damage of each part of body	Visual inspection	To have no apparent deformation, damage, flaw, crack, rust or corrosion						
Apı	Cable damage	Visual inspection	No deterioration or damage on exterior covering						
	Bolts, nut, split pins	Visual inspection	To have no loosened bolts, nuts, and split pins that can be seen from exterior. To have no come-off.						
	Cleanliness	Visual inspection	No excessive buildup of dust or dirt						
	Elongation of pitch	Visual inspection	To have no apparent elongation						
.u	Abrasion of wire diameter	Visual inspection	To have no apparent abrasion						
Load Chain	Deformation, flaw, entanglement	Visual inspection	To have no apparent deformation, harmful flaw and entanglement						
oac	Rust, corrosion	Visual inspection	To have no apparent rust and corrosion						
Ľ	Twist	Visual inspection	To have no twisting due to capsized Bottom Hook of double type						
	Oiling Check of mark	Visual inspection	To be oiled adequately						
	Check of mark	Visual inspection	To have no error in indication and marked pitch						
	Stretched opening Abrasion	Visual inspection	To have no stretched opening						
yo	Deformation, flaw,	Visual inspection	To have no apparent abrasion To have no apparent deformation, harmful flaw, corrosion and						
Н	corrosion, rust	Visual inspection	rust						
Bottorr	Hook Latch motion	Visual inspection/ inspection by operation	To open/close smoothly						
Top Hook, Bottom Hook	Hook motion (swivel)	Visual inspection/ inspection by operation	To have no apparent gap between Hook and Bottom Yoke						
Тор	Idle Sheave motion	Visual inspection/ inspection by operation	Load Chain to move smoothly						
	Bottom Yoke	Visual inspection	To have no loosened bolt and nut						-
_	Chain spring	Visual inspection	To have no apparent permanent set						
Body Peripheral Part	Cushion rubber	Visual inspection	 To have no apparent permanent set To have no crack and peel off of rubber and steel plate 						
Pressure Resistant Containers	Condition around joint surfaces	Visual inspection	 To have no rust, corrosion, and damage To be clean To have no damage on paint To have no grease leakage 						
Push Button Switch	Switch body	Visual inspection	 To have no deformation, damage and loosened screw Indication to be legible clearly 						
rmance	Operational check	Press the push buttons to check the operation	 Load Chain to be wound smoothly Electric Chain Hoist operates in the same direction as that of the push button operation Motor to stop immediately when stopping the operation All operations to stop when Emergency Stop is pressed Electric Chain Hoist not to operate when pressing the push button while Emergency Stop is pressed Electric Chain Hoist to operate normally when canceling Emergency Stop 						
perfc			Brake to operate securely and Bottom Hook to stop immediately						
unction/perfc	Brake	Lifting/lowering operation with no load	(Guideline: Travel of the load chain is within 2 to 3 links.)						
Function/performance	Brake Limit switch	operation with no	(Guideline: Travel of the load chain is within 2 to 3 links.) Motor to stop automatically when operating the electric chain hoist to upper/lower limit						
Function/perfo		operation with no load Lifting/lowering operation with no	Notor to stop automatically when operating the electric chain						
Execution/perfo	Limit switch Strange noise	operation with no load Lifting/lowering operation with no load Lifting/lowering operation with no	Motor to stop automatically when operating the electric chain hoist to upper/lower limit						



• When any abnormality is observed during inspection, stop the use of electric chain hoist, indicate "FAILURE", and contact the qualified person or HARRINGTON for repair.

Decide the check items appropriate to the environment and operating conditions of the customer.

NOTE

Use of the product with abnormality may result in death or serious injury.

Motorized Trolley RMR2 Daily Inspection

■Check result : ○ Good, △To be replaced (adjusted) next inspection, ×Bad, Needs replacement (adjustment)

Cotogony	Check item	Check	Criteria		Inspe	ection o	date/res	sult	
Category	Check item	method	Criteria	/	/	/	/	/	/
0	Unauthorized modification	Visual Inspection	No unauthorized modifications visible to the naked eye						
Appearance	Indication of nameplates and labels	Visual inspection	To have no peeled off. To be legible clearly.						
Appe	Deformation and damage of each part	Visual inspection	 To have no apparent deformation and corrosion Frame to have no apparent deformation 						
	Bolts, nut, split pins	Visual inspection	To have no loosened bolts, nuts, and split pins that can be seen from exterior. To have no come-off.						
Pressure Resistant Containers	Condition around joint surface	Visual Inspection	 To have no rust, corrosion, and damage To be clean To have no damage on paint To have no grease leakage 						
Function/performance	Operational check	Traveling operation with no load	 All operations to stop when E-stop is pressed Electric Chain Hoist not to operate when pressing the push button while E-stop is pressed Electric Chain Hoist to operate normally when canceling E-stop 						
	Brake	Traveling operation with no load	When stopping the operation, brake to operate securely and motor to stop immediately						
Executed b	y Inspector								
Checked b	y Qualified perso	on							

Manual Trolley RTSG Daily Inspection

Category	Check item	Check	Criteria	Inspection date/result							
Category	Check item	method	Citteria	/	/	/	/	/	/		
ance	Indication of nameplates and labels	Visual inspection	To have no peeled off. To be legible clearly.								
Appearance	Deformation and damage of each part	Visual inspection	 To have no apparent deformation and corrosion Frame to have no apparent deformation 								
×	Bolts, nut, split pins	Visual inspection	To have no loosened bolts, nuts, and split pins that can be seen from exterior. To have no come-off.								
Function/ performance	Operational check	Traveling operation with no load	 To travel smoothly. To have no serpentine motion and vibration. 								

Executed by	Inspector			
Checked by	Qualified person			

Check Sheet for Frequent Inspection

A

Code		Capacity	Lot No.	Your CTRL No.	Installation date	Location	Inspection Certification valid thru
Electric Chain Hoist	RNER2						
Motorized Trolley	RMR2						

Electric Chain Hoist RNER2 Frequent Inspection

Category	Check item	Check method	Criteria	Inspection date/res					
Category	Check item	Check method	Citteria	/	/	/	/	/	/
Preceding Inspection	Daily inspection	Check the execution	When performing frequent inspection, also perform the daily inspection.						
Appearance	Bolts, nuts and splits pins	Visual inspection	To have no rust, corrosion on bolts, nuts and splits pins						
Load Chain	Elongation of pitch	Pitch measurement	Sum of pitches for 5 links must not exceed the limit value.						
O L	Abrasion of wire diameter	Diameter measurement	Not to exceed the limit value						
ok, K	Stretched opening	Measurement	Interval between embossed marks not to exceed the limit value						
Top Hook, Bottom Hook	Abrasion	Measurement	To have no abrasion exceeding the limit value (5 %)						
То В	Deformation, flaw, corrosion	Visual inspection	 To have no bending and twist To have no attached foreign matter such as weld splatter 						
Body Peripheral Part	Chain container	Visual inspection	 To be mounted securely To have no breakage, deformation and foreign matter Lift must be shorter than the length of the permissible capacity of the chain container 						
ontainers cations rollers, Motors)	Gaps in junction areas on surfaces	Visual inspection	No expanding gaps						
stant Conta ous Locatio (Controllε Boxes, Mo	Installation bolts	Visual inspection	Appropriate type, complete and tight To have no rust, corrosion						
Pressure Resistant Containers with Hazardous Locations Construction (Controllers, Barrier Relay Boxes, Motors)	Cable retraction opening	Visual inspection or inspection with tools	 No damage to the cable retraction opening No looseness in the cable holder installation area 						
Oil	OIL Leakage	Visual inspection	To have no leakage of gear oil from packings, oil seals or oil plugs						
	OIL plug	Visual inspection	To have no deterioration or damages.						
utton ch	Switch body	Visual inspection/ inspection by operation	 Operation buttons to move smoothly Emergency Stop button to be enabled to operate and cancel 						
Push Button Switch	Push Button Switch cord	Visual inspection	 To be fastened securely Pull down on the Pendant and ensure that Strain Relief Cable takes the force, not the Pendant cord. To have no damage 						
eding	Power cable	Visual inspection	 To have slack To have no damage To be connected securely 						
Power Feeding	Cable hanger	Visual inspection	 To have no damage To move with a small force To be mounted at equal spacing 						
	Messenger wire	Visual inspection	• To have no slack						
Function/ performance	Strange noise	Lifting/lowering operation with no load	 To have no humming noise from motor and scraping sound of the brake To have no popping sound of load chain from the chain guide 						

NOTE



• When any abnormality is observed during inspection, stop the use of electric chain hoist, indicate "FAILURE", and contact the qualified person or HARRINGTON for repair.

Use of the product with abnormality may result in death or serious injury.

Decide the check items appropriate to the environment and operating conditions of the customer.

Motorized Trolley RMR2 Frequent Inspection

■Check result : ○ Good, △To be replaced (adjusted) next inspection, ×Bad, Needs replacement (adjustment)

Cotogory	Check item	Check	Criteria		Ins	pectior	n date	result	
Category	Check item	method	Criteria	/	/	/	/	/	/
Preceding Inspection	Daily inspection	Check the execution	When performing frequent inspection, also perform the daily inspection.						
ance	Bolts, nuts and splits pins	Visual inspection	To have no rust, corrosion on bolts, nuts and splits pins						
Appearance	Travel beam (guider)	Visual inspection	To have apparent deformation and damage						
Ϋ́	Oiling	Visual inspection	To be oiled adequately						
Oil	OIL Leakage	Visual inspection	To have no leakage of gear oil from packings, oil seals or oil plugs						
Refer to check table of electric chain hoist RNER2 for electrical parts, push button switch, power feeding, electrical characteristics and Pressure Resistant Containers with Hazardous Locations Construction.									<u></u>
Executed b	Executed by Inspector								
Checked by	hecked by Qualified person								

Manual Trolley RTSG Frequent Inspection

		Check		Inspection date/result					
Category	Check item	method	Criteria	/	/	/	/	/	/
nce	Combination	Shake the hoist	Electric chain hoist to swing right and left swiftly						
Appearance	Travel beam (guider)	Visual inspection	To have apparent deformation and damage						
AF	Oiling	Visual inspection	To be oiled adequately						

Executed by	Inspector			
Checked by	Qualified person			

Check Sheet for Periodic Inspection

Code		Capacity	Lot No.	Your CTRL No.	Installation date	Location	Inspection valid thru	Certification
Electric Chain Hoist	RNER2							
Motorized Trolley	RMR2							

Electric Chain Hoist RNER2 Periodic Inspection (1/2)

	Check item	Check method	Criteria		Ir	nspectio	n date/i	esult	
Category	Check item	Check method	omena	/	/	/	1	/	/
Preceding Inspection	Daily inspection	Check the execution	When performing periodic inspection, also perform the daily inspection.						
Prec	Frequent inspection	Check the execution	When performing periodic inspection, also perform the frequent inspection.						
Top Hook, Bottom Hook	Bolts, nuts and splits pins	Visual inspection	To have no rust, corrosion on bolts, nuts and splits pins						
	Chain guide A	Visual inspection	 To have no apparent abrasion and damage To have no flaw due to hitting by Load Chain 						
	Chain spring	Visual inspection/ inspection by measurement	 To have no apparent permanent setting (deformation) Length of the chain spring to be longer than the criteria 						
al Part	Stopper	Visual inspection	Stopper must be mounted securely at the third link from the load chain end at no load side						
Body Peripheral Part	Limit lever	Visual inspection/ inspection by operation	 To have no deformation, damage and abrasion To move smoothly To be clean 						
Body F	Chain pin	Visual inspection/ inspection by measurement	To have no apparent deformation and flawNot to lower the criteria						
	Connection Yoke	Visual inspection/ inspection by measurement	 To have no apparent deformation, abrasion and damage The difference between the hole diameter in vertical and lateral to be within 0.5 mm 						
	Shaft retainer clip	Visual inspection	 To have no deformation, damage and abrasion To be mounted securely without looseness 						
Controllers,	Consistency between nameplate indication and operational environment	Check the operational environment against the nameplate indication.	The operational environment must conform with the nameplate indication as to hazardous location, temperature rating, gas type, dust type, etc.						
Pressure Resistant Containers with Hazardous Locations Construction (Controllers, Barrier Relay Boxes, Motors)	Condition of junction areas on surfaces	Remove the lid and check visually.	 No rust Clean No damage Liquid packing in good condition 						
ပိ	Unused lead wire	Visual inspection	Insulated						
ations otors)	Gasket (Motor)	Visual inspection	To have no damage. • Gasket in good condition						
dous Locations Boxes, Motors)	Grounding	Check with tools.	 The connection must be robust. The conductor cross-sectional area is sufficient. 						
Box D	Wiring	Visual inspection	Must be surely connected						
lers with Haza Barrier Relay	Electrical insulators	Visual inspection Check the fuse rating on the secondary side of the transformer in the control	Clean and dry. Must be 1A and 250V.						
tainer Ba	Cable retraction opening	box. Disassemble and check	No deterioration in packing						
nt Con	Moving parts on the limit shaft	Disassemble and check	 Diameter of limit lever pin not less than 15.95mm Inner diameter of sleeve not greater than 16.07mm 						
esista	Between the fan and the fan cover	Perform hoisting and lowering operations.	No rubbing noise between the fan and fan cover.						
ssure R	Certificate of conformity for barrier relay	Visual inspection	The barrier relay has a certificate of acceptance.						
Pre	Wiring inside the barrier relay box	Check if the wiring is correct.	Wiring must be the same as shown in the wiring diagrams.						

NOTE



• When any abnormality is observed during inspection, stop the use of electric chain hoist, indicate "FAILURE", and contact the qualified person or HARRINGTON for repair.

Decide the check items appropriate to the environment and operating conditions of the customer.

Use of the product with abnormality may result in death or serious injury.

Electric Chain Hoist RNER2 Periodic Inspection (2/2)

Category	ory Check item Check method Criteria		Critoria		Inspec	tion date	Inspection date/result							
Category	Check item	Check method	Criteria	/	/	/	/	/	/					
	Oil leakage	Visual inspection	 To have no oil leakage at packing, oil seal and oil plug To have no damage on the Packings, Oil seals or Oil plugs. 											
Ö Oil amount and stain		Visual inspection	 Oil is filled enough close to the oil check hole. Gear oil has viscosity but not stained. Even if the above standards are met, replace the oil at least every 5 years. 											
netic	Appearance	Visual inspection	 To have no loosened bolts and screws To have no flaw and damage 											
romag Brake	Gap	Measurement	The gap not to exceed the limit value											
Electror Br	Appearance Cap Gap Gap Hub and joint		 To have no deformation and abrasion Hub spring not to come off											
	Bearing	Visual inspection	 To have no apparent abrasion, flaw and damage To move smoothly 											
	Load gear, Gear B, Pinion Visual inspection		To have no apparent abrasion, deformation and damage											
Z	Friction clutch	Visual inspection	To have no apparent abrasion, deformation and flaw											
Driving Nut	Load sheave	Visual inspection/ inspection by measurement	 To have no apparent abrasion, deformation and damage To have no flaw on sheave pocket due to defective engagement The thickness of sheave pocket must not lower the criteria. 											
	Idle sheave Visual inspection/ inspection by measurement		 To have no apparent abrasion, deformation and damage To have no flaw on sheave pocket due to defective engagement The thickness of sheave pocket must not lower the criteria. 											
arts	Electrical parts	Visual inspection	 To have no damaged or burnt part To be mounted securely Even if the above standards are met, replace the oil at least every 5 years. 											
Electrical parts	Wiring	Visual inspection	 Wiring to be fixed to electrical parts securely Connector to be inserted securely To have no damaged or burnt part 											
ш	Intrusion or attachment of foreign matter	Visual inspection	To have no water drop or foreign matter such as dust inside											
<u>.0</u>	Source voltage	Measurement	To be supplied power within rated voltage \pm 10 %											
Electric Characteristic	Insulation resistance	Measurement	Insulation resistance to be higher than 5 $\ensuremath{\text{M}\Omega}$											
Ċ	Grounding resistance	Measurement	Source voltage of 10 ohms or less											
in / ince	Operational check	Lifting/lowering operation with a capacity	Perform inspection of the items on function/ performance of daily inspection and frequent inspection with no load, and then perform the inspection of the same items with a capacity.											
Function / Performance	Brake	Lifting/lowering operation with a capacity Visual inspection/ inspection by measurement	Stopping distance of lifting/lowering to be within 1 % of the lifting distance											

Executed by	Inspector			
Checked by	Qualified person			

Code		Capacity	Lot No.	Your CTRL No.	Installation date	Location	Inspection Certification valid thru
Electric Chain Hoist	RNER2						
Motorized Trolley	RMR2						

Motorized Trolley RMR2 Periodic Inspection

■Check result : ○ Good, △To be replaced (adjusted) next inspection, ×Bad, Needs replacement (adjustment)

Check item Daily inspection Frequent nspection Appearance Brake Pad Wheel Side roller Lifting shaft	method Check the execution Check the execution Visual inspection Measurement Visual inspection/inspection by measurement Visual inspection/inspection by measurement	Criteria When performing periodic inspection, also perform the daily inspection. When performing periodic inspection, also perform the frequent inspection. • To have no deformation, flaw and damage on the brake drum and motor cover • To have no deformation, flaw and damage on brake spring Abrasion to be less than limit value • To have apparent deformation and damage • Abrasion of outer diameter to be less than limit value	1			/	/	
Frequent nspection Appearance Brake Pad Wheel Side roller	execution Check the execution Visual inspection Measurement Visual inspection/ inspection by visual inspection/ inspection by	 daily inspection. When performing periodic inspection, also perform the frequent inspection. To have no deformation, flaw and damage on the brake drum and motor cover To have no deformation, flaw and damage on brake spring Abrasion to be less than limit value To have apparent deformation and damage 						
nspection Appearance Brake Pad Wheel Side roller	execution Visual inspection Measurement Visual inspection/ inspection by visual inspection/ inspection by	frequent inspection. To have no deformation, flaw and damage on the brake drum and motor cover To have no deformation, flaw and damage on brake spring Abrasion to be less than limit value To have apparent deformation and damage						
Brake Pad Wheel Side roller	Measurement Visual inspection/ inspection by measurement Visual inspection/ inspection by	drum and motor cover • To have no deformation, flaw and damage on brake spring Abrasion to be less than limit value • To have apparent deformation and damage						
Wheel Side roller	Visual inspection/ inspection by measurement Visual inspection/ inspection by	To have apparent deformation and damage						1
Side roller	inspection by measurement Visual inspection/ inspection by							
	inspection by							
₋ifting shaft	modouromont	To have no apparent deformation and damageAbrasion of outer diameter to be less than limit value						
	Visual inspection/ inspection by measurement	 To have no apparent deformation and damage Abrasion of outer diameter to be less than limit value 						
Side roller inspection to measureme Lifting shaft Visual inspect Suspender, Connection Yoke Visual inspect inspection to measureme Gear frame Visual inspect Visual inspect inspection to measureme Visual inspect Visual inspect		 To have no apparent deformation and damage Abrasion of outer diameter to be less than limit value 						
		To have no damage, breakage and grease leakage.						
Gears, motor shaft	Visual inspection	 To have no apparent abrasion, deformation and damage 						
Beam surface	Visual inspection	 To have no attachment of paint, oil and foreign matter To have no dust and powder due to abrasion 						
Deformation, abrasion	Visual inspection/ inspection by measurement	 To have no deformation of beam flange such as twist and shear drop To have no exceeding abrasion of beam surface 						
Beam fixing bolt	Visual inspection	To be mounted securely without looseness and come-off						
Stopper	Visual inspection	at the beam end						
Appearance	Visual inspection	To be connected securely without deformation and damage						
		for electrical parts, switch, power feeding, electrical characte	ristics an	d Pressure	e Resista	nt Conta	iners wit	.h
Dperational check	Traveling operation with a capacity Visual inspection/ inspection by measurement	Perform inspection of the items on function/performance of daily inspection with no load, and then perform the inspection of the same items with a capacity. • To travel smoothly without serpentine motion and vibration						
Brake	Traveling operation with a capacity Visual inspection/ inspection by measurement	 Stopping distance of traveling to be within 10 % of the traveling distance, when no swinging of a load 						
	Traveling operation with a capacity Visual inspection/ inspection by measurement	To have no irregular rotating noiseTo have no motor hamming or scraping noise of a brake						
Detable ab	eformation, rrasion eam fixing bolt opper opearance table of electric ations Construct perational eck	and	aam surfaceVisual inspection inspection by measurement• To have no dust and powder due to abrasioneformation, irasionVisual inspection by measurement• To have no deformation of beam flange such as twist and shear drop • To have no exceeding abrasion of beam surface • To have no exceeding abrasion of beam surface and shear drop • To have no exceeding abrasion of beam surface • To have no exceeding abrasion of beam surface • To have no exceeding abrasion of beam surface and shear drop • To have no exceeding abrasion of beam surface • To be mounted securely without looseness and come-off at the beam endopperVisual inspection Visual inspectionTo be mounted securely without looseness and come-off at the beam endoppearanceVisual inspection Visual inspectionTo be connected securely without deformation and damageoppearanceVisual inspection operation with a capacity Visual inspection / inspection / inspection / inspection by measurementPerform inspection of the items on function/performance of daily inspection with no load, and then perform the inspection of the same items with a capacity. • To travel smoothly without serpentine motion and vibrationakeTraveling operation with a capacity Visual inspection/ inspection by measurement• Stopping distance of traveling to be within 10 % of the traveling distance, when no swinging of a load • To have no irregular rotating noise • To have no motor hamming or scraping noise of a brake	am surace Visual inspection inspection by measurement • To have no dust and powder due to abrasion eformation, rasion Visual inspection/ inspection by measurement • To have no deformation of beam flange such as twist and shear drop eam fixing bolt Visual inspection • To have no exceeding abrasion of beam surface opper Visual inspection To be mounted securely without looseness and come-off at the beam end oppearance Visual inspection To be connected securely without deformation and damage oppearance Visual inspection To be connected securely without deformation and damage beration al eck Traveling operation with a capacity Visual inspection by measurement Perform inspection of the items on function/performance of dally inspection of the same items with a capacity. ake Traveling operation with a capacity Visual inspection by measurement • Stopping distance of traveling to be within 10 % of the traveling distance, when no swinging of a load range noise Traveling operation with a capacity Visual inspection/ inspection by measurement • To have no irregular rotating noise • To have no motor hamming or scraping noise of a brake	am sufrace Visual inspection • To have no dust and powder due to abrasion aformation, rasion Visual inspection by measurement • To have no deformation of beam flange such as twist and shear drop asm fixing bolt Visual inspection inspection by measurement • To have no exceeding abrasion of beam surface opper Visual inspection To be mounted securely without looseness and come-off at the beam end oppearance Visual inspection To be connected securely without deformation and damage oppearance Visual inspection To be connected securely without deformation and damage table of electric chain hoist RNER2 for electrical parts, switch, power feeding, electrical characteristics and Pressure ations Construction. Perform inspection of the items on function/performance of daily inspection of the same items with a capacity. berational eck Traveling operation with a capacity Visual inspection/ inspectio	am sufrace Visual inspection • To have no dust and powder due to abrasion aformation, rasion Visual inspection by measurement • To have no deformation of beam flange such as twist and shear drop am fixing bolt Visual inspection measurement • To have no exceeding abrasion of beam surface am fixing bolt Visual inspection To be mounted securely without looseness and come-off opper Visual inspection To be connected securely without looseness and come-off oppearance Visual inspection To be connected securely without deformation and damage oppearance Visual inspection To be connected securely without deformation and damage table of electric chain hoist RNER2 for electrical parts, switch, power feeding, electrical characteristics and Pressure Resista actions Construction. berational eck Traveling operation with a capacity Visual inspection/ inspection/ inspection/ inspection/ inspection by measurement Perform inspection of the items on function/performance of daily inspection with no capacity. ake Traveling operation with a capacity Visual inspection/ inspection by measurement • Stopping distance of traveling to be within 10 % of the traveling distance, when no swinging of a load range noise Traveling operation with a capacity Visual inspection by • To have no irregular rotating noise • To have no motor hamming or scraping noise of a brake	am surface Visual inspection To have no dust and powder due to abrasion To have no deformation of beam flange such as twist and shear drop To have no exceeding abrasion of beam surface To be mounted securely without looseness and come-off To be mounted securely without looseness and come-off To be connected securely without looseness and come-off To be connected securely without deformation and damage To be connected securely without deformation and damage To be connected securely without deformation and damage Taveling Perform inspection of the items on function/performance of daily inspection of the same items with a capacity. To raveling operation with a capacity Visual inspection by measurement Araveling Stopping distance of traveling to be within 10 % of the traveling distance, when no swinging of a load Stopping distance, when no swinging of a load Traveling operation with a capacity Visual inspection/ inspection by measurement To have no irregular rotating noise To have no motor hamming or scraping noise of a brake To have no motor hamming or scraping noise of a brake To have no motor hamming or scraping noise of a brake To have no motor hamming or scraping noise of a brake To have no motor hamming or scraping noise of a brake To have no motor hamming or scraping noise of a brake To have no motor hamming or scraping noise of a brake To have no motor hamming or scraping noise of a brake To have no motor hamming or scraping noise of a brake To have no motor hamming or scraping noise of a b	am surface Visual inspection/ inspection by measurement • To have no deformation of beam flange such as twist and shear drop • To have no deformation of beam surface formation, rrasion Visual inspection/ visual inspection • To have no exceeding abrasion of beam surface aam fixing bolt Visual inspection To be mounted securely without looseness and come-off opper Visual inspection To be mounted securely without looseness and come-off opperarance Visual inspection To be connected securely without deformation and damage table of electric chain hoist RNER2 for electrical parts, switch, power feeding, electrical characteristics and Pressure Resistant Containers wit ations Construction. rearational eck Traveling operation with a capacity Visual inspection/ inspection by measurement Perform inspection of the items on function/performance of daily inspection with no load, and then perform the inspection by measurement rraveling operation with a capacity Visual inspection/ inspection with a capacity Visual inspection by measurement • Stopping distance of traveling to be within 10 % of the traveling distance, when no swinging of a load rraweling operation with a capacity Visual inspection by inspection by • To have no irregular rotating noise • To have no motor hamming or scraping noise of a brake

Executed by	Inspector			
Checked by	Qualified person			

Α



• When any abnormality is observed during inspection, stop the use of electric chain hoist, indicate "FAILURE", and contact the qualified person or HARRINGTON for repair.

NOTE

Decide the check items appropriate to the environment and operating conditions of the customer.

Use of the product with abnormality may result in death or serious injury.

Manual Trolley RTSG Periodic Inspection

Catogory	Check item	Check method	Criteria		nspec	tion da	ate/res	ult	
Category	Check item	Check method	Criteria	/	/	/	/	/	/
nent	Wheel	Visual inspection/ inspection by measurement	 To have no apparent deformation and damage Abrasion of outer diameter to be less than limit value 						
Body Component	Lifting shaft	Visual inspection/ inspection by measurement	 To have no apparent deformation and damage Abrasion of outer diameter to be less than limit value 						
Bc	Suspender	Visual inspection/ inspection by measurement	 To have no apparent deformation and damage Abrasion of outer diameter to be less than limit value 						
E	Beam surface Visual inspection		 To have no attachment of paint, oil and foreign matter To have no dust and powder due to abrasion 						
Travel Beam	Deformation, abrasion	Visual inspection/ inspection by measurement	 To have no deformation of beam flange such as twist and shear drop To have no exceeding abrasion of beam surface 						
	Beam fixing bolt	Visual inspection	To be mounted securely without looseness and come-off						
	Stopper	Visual inspection	To be mounted securely without looseness and come-off at the beam end						
Function / Performance	Operational check	Traveling operation with a capacity Visual inspection/ inspection by measurement	Perform inspection of the items on function/ performance of daily inspection with no load, and then perform the inspection of the same items with a capacity.						
Func	Strange noise Strange noise Reasurement		Perform inspection of the items on function/ performance of daily inspection with no load, and then perform the inspection of the same items with a capacity.						

Executed by	Inspector			
Checked by	Qualified person			



Contact HARRINGTON for replacement components

Mandatory Otherwise it may result in injury







Contact HARRINGTON for replacement components.

Mandatory Otherwise it may result in injury.

Appendix B

This Appendix summarizes special service considerations for the HARRINGTON RNER series electric chain hoists.

Special Service Considerations Disassembly Reassembly Application of Grease Hardware Torque

В

Disassembly

1. Disassemble electrical components in the control box (common to hoists and trolleys)



- (1) Remove the socket bolts (For Hoist, Trolley 8 Pieces Each) from the controller cover and remove the controller cover.
 - Note: Handle with care to avoid scratches or dents on the joint surface between the cover and box.
 - If scratches or dents are caused on the joint surface, the explosion-proof function will be affected, and the product will not be usable.
- (2) After removing the lead wire and connector connected to the panel from the bushing attached to the controller box, remove the navel connector(4 pieces) to secure the panel, and then remove the panel.

For the hoist, continue below.

- (3) The limit switch lead wire is connected to the panel van, so remove the coupler from this wire.
- (4) Remove the socket bolts (3) that secure the limit switch.



2. Disassembly to replace electrical components and cables in the connection box (common to hoists and trolleys)



- (1) Remove the socket bolt (For Hoist, Trolley 6 Pieces Each) from the panel terminal cover and remove the panel terminal cover.
 - Note: Handle with care to avoid scratches or dents on the cover and box joints.
 - If scratches or dents are made on the joints, the explosion-proof function will be affected, and the product will not be usable.
- (2) After disconnecting the lead wire connected to the terminal block from the bushing attached to the controller box and the lead wire connected to the terminal block from the cable ground, remove the navel connection (4 pieces) fixing the terminal block and remove the terminal block.
- (3) Only the (2) part (Entry item) of the cable gland cross section is left in the panel terminal box, and the other cable gland components are removed in order from the (9) part side.
 - Note:(2) Never loosen the entry item. The panel terminal box screws are damaged and cannot be used.

(2) If you remove the parts (6) from the cable, the parts (1) and (3) to (5) will be disconnected along with the cable.

CABLE GLAND COMPONENTS

- 1. Compound
- 2. Entry Item
- 3. Compound Tube
- 4. Spacer
- 5. "O" Ring
- 6. Main Item
- 7. Skid Washer
- 8. Outer Seal
- 9. Outer Seal Nut

3. Disassembly to replace the motor cable (common to hoists and trolleys)



- (1) Remove the terminal cover socket bolt (For Hoist, Trolley 8 Pieces Each) and remove the terminal cover.
- Note: Handle with care to avoid scratches or dents on the cover and box joints.
- If scratches or dents are made on the joints, the explosion-proof function will be affected, and the product will not be usable.
- (2) After removing the lead wire connected to the terminal block from the bushing attached to the terminal block and the lead wire connected to the terminal block from the cable ground, remove the navel connegi (2 pieces) that secure the terminal block and remove the terminal block.

After this, remove the cable in the same manner as described in 2 (3).

4. Disassembly to Replace the Barrier Relay/Oscillator Cable



- (1) Remove the socket bolts (6) of the Barrier relay cover and remove the Barrier relay cover.
 - Note: Handle the cover carefully to avoid scratches or dents on the joint surface of the cover and box.
 - If scratches or dents are caused on the joint surface, the explosion-proof function will be affected, and the product will not be usable.
- (2) After removing the lead wire connected to the Barrier relay from the cable ground, remove the three pieces that secure the Barrier relay, and then remove the Barrier relay.
- Next, remove the cable in the same manner as described in 2 (3)

Reassembly

5. Check the bonding surface of the pressure vessel and apply grease

*Pressure vessels include: Controller box/cover, Panel terminal box/cover, Terminal box/cover, Barrier relay box/cover

(1) Inspection method and treatment of joint surface of pressure vessel Table 1: Confirmation and treatment of joint surface of pressure vessel

Items	Check method	Actions	Action to be taken in case of failure
absence of corrosion	Visual observation	If rust is found, remove it	Replace parts when there is too much rust or dirt to wipe off with
be spotless	Visual observation	 If there is dirt, remove it 	a cloth
absence of scratches or dents	Visual observation Dimensional measurement	 If there are scratches, replace the parts. If there are dents exceeding 1.6 mm in diameter and 1.6 mm in depth, replace parts. 	If it is difficult to determine, a field evaluation by an Authority Having Jurisdiction (AHJ) should be conducted.

(2) Apply grease to the joint surfaces of pressure vessels to prevent corrosion according to the instructions below.

Applying Grease on Joint Surfaces

Joint surfaces must be applied with grease to avoid rusting or corrosion according to the following procedure.

Type of Grease to be applied

Recommended Grease: Shell Gadus S2 V100 3

When using other equivalent grease, it must comply with the following conditions.

- · To be Soap-thickened mineral oil based grease
- Not to harden because of aging
- Not to contain an evaporating solvent
- · Not to cause corrosion of the aluminum joint surfaces
- Not to contain metal particles
- · Consistency to be NLGI 3, or equivalent
- Allowable temperature range to be -20 to +135 °C
- Not to deteriorate non-metal material parts
- · Not to contain extreme-pressure additive

Application Process

Apply grease according to the following process.

- Wipe the Joint surfaces with a cloth to remove foreign matters including old grease already applied
- Intersperse small amount of grease as recommended between bolt holes (applying on either surface out of two facing surfaces is acceptable)
- · Spread thin layer of grease on the surface except for bolt holes
- Remove grease squeezed out from surface before attaching cover (remove it including inside of bolt holes)
- Wipe grease squeezed out from joint surface after fastening bolts

Portion of Grease to be Applied

A) Following Joint surfaces shall be applied with grease at periodic inspections, or at any chance to separate the joints.

- Hoisting part:
- 1) Hoisting controller box and Hoisting terminal box
- Flat surface between Controller box and Controller cover
- Flat surface between Terminal box and Terminal cover
- 2) Barrier relay box
- Flat surface between Barrier relay box and Barrier relay cover

3) Hoisting motor

- Flat surface between Terminal box and Terminal cover
- Flat surface and cylindrical surface between Motor frame and Motor bracket
- Flat surface and cylindrical surface between Motor frame and Motor cover Traversing part:
- 1) Motorized trolley controller box and Motorized trolley terminal box
- · Flat surface between Controller box and Controller cover
- · Flat surface between Traversing terminal box and Traversing terminal cover

2) Traversing motor

- Flat surface between Terminal box and Terminal cover
- Flat surface between Motor frame and Gear case
- · Flat surface between Gear case and Bearing cover
- · Flat surface between Motor frame and Motor cover

B) Following Joint surfaces shall be applied with grease at any chance to separate the joints. Hoisting part:

1) Hoisting controller box and Hoisting terminal box

• Flat surface between Controller box and Terminal box

2) Hoisting motor

• Flat surface between Motor frame and Terminal box

Traversing part:

- 1) Motorized trolley controller box and Motorized trolley terminal box
- Flat surface between Controller box and Traversing terminal box
- 2) Traversing motor
- 6. Assembling Cables and Cable Grounds
 - (1) Terminal Processing of Cables

The cable to be replaced is peeled, the lead wire terminal is machined, and the lead wire mark band is installed.

7. Assembly procedure

The basic assembly procedure is the reverse of the disassembly procedure.

The basic order is as follows.

1) Installation of electrical components (Limit Switch, Panel, Contactor, Terminal Strip, etc.) in the pressure vessel

2) Installation of cable ground (cable) to each pressure vessel

3) Wiring to electrical components

4) Installing the pressure vessel cover

Table 2: Socket bolts, cable gland tightening torque.

Component	Size	Tightening torque (N · m)
Socket bolt. (for Controller box, Panel terminal box)	M8	28
Socket bolt. (for Barrier relay cover, Terminal box)	M6	12
Cable gland	3/4NPT	30

(1) Installation of electrical components in the pressure vessel

Reinstall limit switches, panels, contactors, terminal strips, and leads. Note: Be careful of incorrect wiring and pinched leads.

- (2) Installing the Cable Ground (Cable)
 - 1) After potting the cable gland according to paragraph 6. (2), only the (2) Entry item is removed from the cable assembly.
 - 2) After inserting the cable lead into the (2) Entry item originally attached to the box, the (6)
 - Main item is tightened to the (2) Entry item. (Tightening torque: 30 Nm)
 - 3) Tighten (9) Outer seal nut to (6) Main item.(tightening torque: 30 Nm)



(3) Installing the pressure vessel cover

Combine the pressure vessel cover in a box, taking care not to damage the joints of the oiled pressure vessel cover and not to allow dust, etc., to adhere to it.

- (4) Tightening the pressure vessel cover
- Tightening the pressure vessel cover with a tightening torque that matches the size of the socket bolt (see Table 2). Tighten the bolts in sequence starting at the middle of the cover in a criss-cross pattern.

Confirmation After Assembly

8. Confirmation of pressure vessel joint surface

Using a 0.04 mm thickness gauge, apply the thickness gauge to the total length of the joint surface of each cover and confirm that the gauge does not enter the joint surface above the reference value in Table 3.

Table 3: Allowable insertion depths for gauges

Joint surface check area	Reference value
Panel terminals cover joint surface	Less than 3.2 mm
Joint surface of Controller box cover and Barrier	0mm (gauge must not be inserted)
relay cover	

Note: If the thickness gauge enters the joint surface above the above reference value, the pressure vessel cannot be reused, so replace the pressure vessel.

This page intentionally left blank

This page intentionally left blank

WARRANTY

Buyer must notify HHI in writing within sixty (60) days of discovery of any alleged defect, if within the applicable warranty period.

All products sold by HHI are warranted to be free from defects in material and workmanship from date of shipment by HHI for the following periods:

- 1 year Electric and Air Powered Hoists (excluding (N)ER2 Hoists and EQ/SEQ Hoists), Powered Trolleys, Powered Tiger Track Jibs and Gantries, Crane Components, Below the Hook Devices, Spare / Replacement Parts
- 2 years Manual Hoists & Trolleys, Beam Clamps
- 3 years (N)ER2 Hoists, EQ/SEQ Hoists, (T)EM/(T)SEM hoists, RNER2 Hoists, and RY Hoists
- 5 years Manual Tiger Track Jibs and Gantries, Hoist Motor Brakes for TNER, EQ/SEQ, (T)EM/(T)SEM, and RY
- 10 years (N)ER2 Brake, TNER Hoist Motor Brake, Tiger Track Workstation Cranes and Monorails

The product must be used in accordance with manufacturer's recommendations and must not have been subject to abuse, lack of maintenance, misuse, negligence, or unauthorized repairs or alterations.

Should any defect in material or workmanship occur during the above time period in any product, as determined by HHI's inspection of the product, HHI agrees, at its discretion, either to replace (not including installation) or repair the part or product free of charge. For customers in the U.S., delivery shall be made F.O.B. HHI's place of business. For international customers, delivery shall be made FCA HHI place of business, United States of America (Incoterms 2010).

No warranty claim will be honored without a valid proof of purchase. Customer must obtain a Return Goods Authorization as directed by HHI or its published repair center prior to shipping product for warranty evaluation. An explanation of the complaint must accompany the product. Product must be returned freight prepaid. Upon repair, the product will be covered for the remainder of the original warranty period. Replacement parts installed after the original warranty period will only be eligible for replacement (not including installation) for a period of one year from the installation date. If it is determined there is no defect, or that the defect resulted from causes not within the scope of HHI's warranty, the customer will be responsible for the costs of returning the product.

HHI DISCLAIMS ANY AND ALL OTHER WARRANTIES OF ANY KIND, EXPRESSED OR IMPLIED, AS TO THE PRODUCT'S MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. HHI WILL NOT BE LIABLE FOR DEATH, INJURIES TO PERSONS OR PROPERTY OR FOR INCIDENTAL, CONTINGENT, SPECIAL OR CONSEQUENTIAL DAMAGES, LOSS OR EXPENSE ARISING IN CONNECTION WITH THE USE OR MISUSE OF THE PRODUCTS, REGARDLESS OF WHETHER THE DAMAGE, LOSS OR EXPENSE RESULTS FROM ANY ACT OR FAILURE TO ACT BY HHI, WHETHER NEGLIGENT OR WILLFUL, OR FROM ANY OTHER CAUSE.

W



Harrington Hoists, Inc. 401 West End Avenue Manheim, PA 17545

www.harringtonhoists.com

Toll Free: 800-233-3010 Phone: 717-665-2000 Fax: 717-665-2861

© HARRINGTON HOISTS, INC. ALL RIGHTS RESERVED

RNER2BDOM-ENG